User Manual

aceline

Toner Cartridge AM-W1360A

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you products and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the product, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Installation Instructions

	Remove the black protective film from the cartridge
	Shake the cartridge 5–6 times, as shown in the figure on the left
	Remove the sealing tape by gently pulling the tab
	Firmly insert the cartridge into the printer
	Close the printer cover

Troubleshooting Guide

- This cartridge uses a chip that does not display the toner level. If the print becomes faint, check the amount of toner remaining in the cartridge.
- After installing a new cartridge, a message may appear on the printer screen stating that the product may be non-genuine. To resolve this issue, refer to the printer's user manual.

Safety Precautions

- Select the correct paper type and thickness for printing. Do not use damaged, excessively thick paper, or paper with staples, as this may damage the photoconductor drum and cause white lines, distorted characters, or a gray background in prints.
- During the first prints with a new cartridge, some defects may occur (faint or overly saturated colors, streaks, etc.). If such issues arise, print 10 consecutive pages. After this, the print quality will normalize.
- Environmental requirements: Cartridge installation must be performed at an ambient temperature of 10 °C to 30 °C and a relative humidity of 20–80%. Failure to comply with these requirements may significantly degrade print quality. If the cartridge has been stored outside the acceptable temperature range for an extended period, leave it, along with the printer, in the required conditions for 2 hours before resuming printing.
- Do not touch the photoconductor drum with your hands and do not expose it to direct sunlight. This may reduce the drum's lifespan and cause print defects.
- When printing on special media, use the manual paper feed and the nearest output tray. This will reduce the paper path through the printer and prevent paper jams.
- When replacing the cartridge, clean the cartridge compartment of dust and small debris using a dry, soft cloth. To prevent faint colors during printing, it is recommended to periodically wipe the electronic sensor contact in the cartridge compartment with a special alcohol wipe for electronics.
- When a low toner indicator appears, remove the cartridge and shake it. This will allow you to print approximately 40–50 more pages.
- This product is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety. Do not allow children to play with the product.
- This product is not intended for commercial use.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- The device does not require installation or permanent mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported under dry conditions.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 15 months
Service Life: 24 months

For the up-to-date list of authorized service centers, please visit: https://www.dns-shop.ru/service-center/

Additional Information

Manufacturer: ZHUHAI JIALIANXIN IMAGING PRODUCTS CO., LTD. 2/3/4F, No.1 Jiaxin Technology Building, No.2 Dingwan Nine Road, Sanzao Town, Jinwan District, Zhuhai City, Guangdong Province, P.R. China.

Made in China.

The production date is indicated on the packaging.

v.1