KENSHI

User Manual

Mobile phone

Senior 321

Contents

Intended Use....3
Safety Precautions....3
Maintenance....4
Connecting to Other Devices....4
Emergency Call....4
Rechargeable Battery Guidelines (Li-pol/Li-ion)....5
Device Diagram....9
Specifications....10
Getting Started....11
Powering On and Off....13
Network Connection....13
Outgoing Calls....14
Main Menu....14
Contacts....16
Camera....17
Multimedia....18
My Files....20
Phone Settings....20
Audio Player....25
Organizer....26
PC Connection....27
Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal....28
Warranty Information....29
Additional Information....30

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The mobile phone is intended for making and receiving phone calls, as well as sending and receiving text messages via cellular network.

Safety Precautions

Road Safety

- Never use a mobile phone while driving a vehicle.
- Use a headset for making calls.

Aircraft Safety

Do not use the phone while on board an aircraft. Mobile network signals may interfere with the navigation system.

Turning Off the Phone in Hazardous Areas

Turn off the phone in areas with potentially explosive atmospheres or in areas where flammable materials are present (for example, at gas stations, fuel depots, and chemical plants).

Compliance with Special Regulations

Comply with the phone usage rules in hospitals and other public places. Please note that the phone may interfere with medical equipment (for example, hearing aids).

Water Resistance

The phone is not waterproof. Protect it from moisture.

Maintenance

Never attempt to disassemble or repair the phone yourself. This must be performed by a qualified technician. Failure to comply with this condition will void the warranty.

Connecting to Other Devices

Before connecting the phone to any device, carefully read the corresponding instructions. Never connect any equipment to the phone that is not intended for this purpose.

Emergency Call

To make an emergency call, ensure that the phone is turned on and is within the network coverage area of a service provider, and that the call function is active. Dial the emergency number 112 in the same way as you dial a regular phone number, then press the call key. Explain to the emergency operator where you are and what has happened.

Rechargeable Battery Guidelines (Li-pol/Li-ion)


Dear Customer, please note that this device uses a lithium-based rechargeable battery as its power source. Please carefully read the information below to help extend the life of your battery and prevent undesirable consequences during its operation.

Battery Capacity and Charge-Discharge Cycles

During prolonged storage and use, the rechargeable battery (hereinafter referred to as «the battery») tends to lose its charge and capacity. After 300 charge-discharge cycles (approximately one year of device use), the battery capacity may decrease to 80% of its nominal value. After 400 charge-discharge cycles, the battery capacity may decrease to 60% of its nominal capacity. Partial capacity reduction within these limits and time frames is natural battery wear and is not considered a defect.

Natural Battery Wear

The battery loses charge even when stored separately from the device. The self-discharge rate is approximately 5% per month. Due to their design, batteries are not durable and constantly degrade regardless of whether they are in use. This degradation accelerates at higher temperatures and when the charge level deviates from the «optimal» storage level, which is generally considered to be 40%. In other words, if the battery is not in use, it is advisable to keep the charge level between 40% and 50%.



Use Only the Original Charger

The battery's charge and discharge capability is controlled by its built-in Battery Management System (BMS) . Forced «fast charging» modes using external chargers for Li-ion batteries are strictly not recommended, as charge and discharge currents are limited.

Li-ion batteries do not have a so-called «memory effect» You can start charging or discharging the battery from any charge level.

Most devices have charge and discharge limits—the controller may prevent the battery charging if, for example, the charge is already above 90%. It will also prevent the battery from fully discharging, protecting the cells from damage. Even if the device is powered by the electrical grids, the Li-ion battery should undergo a full charge/discharge cycle at least once a month (until the «low battery» warning appears).

Never let the battery discharge completely. A Li-ion battery degrades quickly if stored in a discharged state for a prolonged period. If this happens, charge it immediately.
If the battery remains in a discharged state for two weeks or more, irreversible capacity loss occurs in the cells, which will ultimately lead to battery failure.

Observe the Temperature Requirements

Batteries must be stored in a charged state at temperatures between +15 °C and +35 °C with normal humidity. Batteries do not perform well prolonged operation in very high (above +40 °C) or very low (below -10 °C) ambient temperatures. Do not leave the battery in direct sunlight.


Do Not Disassemble, Burn, or Use Damaged Batteries

Under no circumstances should you attempt to disassemble the battery or charge its individual cells. For repair or maintenance, please contact an authorized service center.
Puncturing or crushing the cells can cause an internal short circuit, leading to fire and explosion. Melting of lithium due to high temperatures can also cause an explosion. If the seal is broken, water or condensed atmospheric moisture can enter the cell, potentially triggering a reaction that releases hydrogen and causes a fire. You can check the current battery status using the battery indicator, which is available on almost all devices (please check its location and operation method at the time of purchase).

CAUTION

- Be careful — damaged batteries may release harmful substances.
- If the battery is replaceable (removable), and you discover problems with its performance, contact a service center (see the warranty period in the warranty information). If the battery is built-in (an integral part of the device), the warranty applies to the device itself. You should also contact a service center. The sooner you bring a malfunctioning battery in for repair, the more likely it can be restored with minimal cost.
- Battery operating time depends on many other factors, and the actual operating time may differ from the stated value.
- Rechargeable batteries have a limited number of charge cycles and may eventually need replacement (see the limited warranty conditions for the battery in the warranty information). Battery operating time depends on the usage mode and settings.

Device Diagram



1. Flashlight.
2. Earpiece.
3. Volume keys.
4. Screen.
5. Navigation key.
6. Flashlight switch.
7. Left function key.
8. Call key.
9. Keypad.
10. Type-C connector.
11. Audio jack.
12. Microphone.
13. End call key / Power key.
14. «OK» key.
15. Right function key.
16. Lock key.
17. Camera.
18. «SOS» key.
19. Speaker.

Specifications

- Model: Senior 321.
- Trademark: KENSHI.
- Dimensions: 148 × 63.7 × 15.6 mm.
- Screen size: 3.36″.
- Display resolution: 240 × 320.
- FM Radio support.
- Camera: 2 MP.
- Internal storage: 64 MB*.
- N SIM cards: 2.
- SIM format: 2 NanoSIM.
- IP code: IPX0.
- Battery: Li-Ion, 3,7 V, 2500 mAh.
- Protection class: III.
- Audio jack: mini Jack 3.5 mm.
- Charging port type: USB Type-C.
- Charger (Power adapter) specifications:
  - Input: 100–240 V ~ 50–60 Hz.
  - Output: 5 V ⎓ 0.5 A.
  - Cable length: 0.8 m.
  - Cord type: X.
  - Protection class: II.
- Scope of application: Domestic.
- Package Contents: Device, docking station, battery, charger, user manual.

Bluetooth radio frequency specifications

- Wireless standard: IEEE 802.15.1.
- Frequency range: 2402–2483.5 MHz.
- Transmitter power: 10 mW.

*A memory card is required for data storage.

Getting Started

SIM Cards and Memory Card

The SIM card contains important information such as your phone number, PIN code (personal identification number), PIN2 code, PUK code (personal unblocking code for the PIN), PUK2 code (personal unblocking code for the PIN2), IMSI (International Mobile Subscriber Identity), network information, contact details from your phone book, and text messages.

After turning off the phone, wait a few seconds before inserting or removing the SIM card. Handle the SIM card with extreme care, as both the card itself and its contacts can easily be scratched or bent.

Caution: This device supports only Nano-SIM cards (see figure). Using incompatible SIM cards may damage the card or the device, as well as corrupt the information stored on the card.



The memory card is a removable storage device inside the phone. Use only compatible microSD memory cards with this device. Other types of memory cards do not fit the microSD card slot and are not compatible with this device.

Keep the phone, its accessories, as well as the SIM card and memory card out of reach of children.

Installing SIM Cards and Memory Card

1. Before installing the SIM card and memory card, be sure to turn off the device and disconnect it from the charger.
2. Open the back cover of the phone by prying it at the notch in the lower left part of the device.
3. Remove the battery.
4. Fully insert the SIM cards so that the cut corner aligns with the corresponding side of the SIM card slot, and the gold-colored contacts are facing down.
5. Insert the memory card into the slot with the contacts facing down.
6. Reinstall the battery.
7. Carefully close the back cover.

Access Codes

The phone and SIM card may have multiple passwords designed to ensure security and prevent unauthorized use of the device. When prompted, enter the password, then press the confirmation key. When entering an incorrect password, press the right function key to delete the incorrect password before entering a new one.

Phone Lock

The phone lock password is used to prevent unauthorized use of the device. The default password is **1234**.
After locking the phone, you will be required to enter the password to unlock it in order to use various device functions.

PIN Code

The PIN code (personal identification number consisting of 4–8 digits) is used to prevent unauthorized access to your SIM card. The PIN code is provided with the SIM card by the mobile network operator.
If the PIN code verification function is activated, you will be required to enter this PIN code every time you turn on the phone.
Caution: After three consecutive incorrect PIN entries, the SIM card becomes blocked. The SIM card can be unblocked using the PUK code.

PUK Code

The PUK code (Personal Unblocking Key, 8 digits) is required to restore a blocked SIM card and is provided with the SIM card by your mobile service provider.
If an incorrect PUK code is entered 10 times in a row, the SIM card will be permanently locked. After this, you will need to contact your mobile network operator to replace the SIM card.

Powering On and Off

To turn the phone on or off, press the Power key. If prompted, enter the PIN code when powering on.

Network Connection

After inserting the SIM card and turning on the phone, the device automatically searches for an available network. After that, the phone enters active mode. The name of the network being used will be displayed on the screen, and you will be able to make outgoing calls and receive incoming ones.

Outgoing Calls

Dial the desired number and press the Call key.

Using a Headset

After connecting the headset, the phone automatically switches to voice profile support mode.

Main Menu

Messages

This menu allows you to read, compose, send, and save text messages.
Received messages are saved in the **Inbox** folder. Unsent messages are saved in the **Outbox** folder. Pre-saved but unsent messages are located in the **Drafts** folder.
The **Sent** folder contains sent messages, provided that the save sent messages function is enabled in the settings. Enabling/disabling the save sent messages function is configured in ***Menu > Messages > Message Settings > Save Sent Message***.
The **Templates** folder contains text message templates. You can use pre-recorded templates for replies or create your own text message variants.

Composing and Sending a Message

1. Select ***Menu > Messages > Write Message***.
2. Enter the message text. You can use ready-made reply templates by selecting ***Options > Insert Template***.
3. To send the message, select ***Options > Send***.
4. Enter one or more phone numbers in the **Contacts** field.
5. If you do not want to send the message at this time, you can save the composed message as a draft. Select ***Options > Save***. The saved message will be located in the **Drafts** folder.

Viewing and Replying to a Message

1. To view a received message, select ***Menu > Messages > Inbox***.
2. To reply to a message, open it and select ***Options > Reply***.
3. Enter the message text. You can use ready-made reply templates by selecting ***Options > Insert Template***.
4. To send the message, select ***Options > Send***.

Forwarding a Message

1. Open the view of the message you want to forward.
2. Select ***Options > Forward***.
3. To send the message, select ***Options > Send***.
4. Enter one or more phone numbers in the **Contacts** field.

Deleting a Message

1. Highlight the message you want to delete in the **Inbox**, **Outbox**, **Drafts**, or **Sent** folder. If you want to delete multiple messages, select ***Options > Mark multiple***.
2. Select ***Options > Delete***.
3. After confirming your choice, the message will be deleted.

Call Log

Registration of missed, outgoing, and incoming calls is only possible if the cellular network provides this service, and the phone is turned on and within the cellular network coverage area.

- To view call information, select ***Menu > Call Log > Missed/Outgoing/Incoming > Options > View.***
- To call a previously registered number, select ***Menu > Call Log > All calls/Missed/Outgoing/Incoming > Options > Call.***

- To send a text message to a previously registered number, select ***Menu > Call Log > All calls/Missed/ Outgoing/Incoming > Options > Send Message***.
- To add a previously registered number to the blacklist, select ***Menu > Call Log > All calls/Missed/Outgoing/ Incoming > Options > Add to Blacklist***.
- To add a previously registered number to the whitelist, select ***Menu > Call Log > All calls/Missed/Outgoing/ Incoming > Options > Add to Whitelist***.
- To clear all call logs, select ***Menu > Call Log > Clear call log***.
- To view the duration of recent calls, select ***Menu > Call Log > Call duration***.

Contacts

Names and phone numbers (contacts) can be saved in the phone memory and SIM card memory.
In the phone memory, you can assign two numbers to one contact.
In the SIM card memory, you can assign one phone number to each contact.

Search Contact

Select ***Menu > Contacts > Search***. Scroll through the contact list or enter the first letters of the name you want to find.

Add Contact

Names and phone numbers are saved in the selected memory. To save a name and phone number, select ***Menu > Contacts > Add Contact***.

Copy Contacts

To copy contacts from the phone memory to the SIM card and vice versa, select ***Menu > Contacts > Options > Copy***.

Delete Contacts

To delete contacts from the phone memory or SIM card, select ***Menu > Contacts > Options > Delete***.
To delete multiple contacts, select ***Menu > Contacts > Options > Mark multiple***.

Speed Dial

To assign a phone number to a speed dial key, select ***Menu > Contacts > Options > Contact Settings > Speed Dial*** and highlight the desired speed dial key.

Camera

The built-in camera allows you to take photos and record video clips.
Note: This function works only when a memory card is installed in the phone.
To take photos, select **Snapshot** by pressing the central «**OK**» key.
Open ***Menu > Camera > Options*** and select one of the functions:

- ***Video Camera/Camera*** — switch between Video Camera/Camera shooting modes.
- ***Photos*** — view taken photos.
- ***Camera Settings > EV*** — adjust the exposure level.
- ***Camera Settings > Anti-flicker*** — select the frequency (50–60 Hz) to reduce flickering in shots.
- ***Camera Settings > Timer*** — delay shooting by 5/10/15 seconds.
- ***Image Settings > Resolution*** — select the photo resolution.
- ***Image/Video Settings > Photo/Video quality*** — select the photo/video shooting quality.
- ***Effects*** — adjust various color effects during video shooting.
- ***Restore default settings*** — restore the camera's default settings.

Multimedia

Gallery

This menu is used to work with JPG images located on the memory card.
Open ***Menu > Gallery > Options*** and select one of the functions:

- ***Use as*** — set the selected file as the home screen wallpaper or as the power on/off animation.
- ***Rename*** — change the image file name.
- ***Delete*** — delete the selected image file.
- ***Mark multiple*** — delete, copy, move, or send the selected files.
- ***Details*** — view information about the image file.

Video Camera

Turns on the phone's video camera. The functions are similar to the **Camera** section.

Video Player

The phone has a built-in video player designed for viewing video clips in AVI format located on the memory card.
The video player is controlled by the following keys:

- ***Central «OK» key*** — play/pause playback.
- ***Up key*** — switch playback mode to fullscreen / half-screen.
- ***Down key*** — stop playback.
- ***Right key / press and hold right key*** — skip to next video clip / fast forward current video clip.
- ***Left key / press and hold left key*** — skip to previous video clip / rewind current video clip.
- ***# key*** — increase volume.
- **** key*** — decrease volume.

Voice Recorder

The phone allows you to record speech.
Open ***Menu > Multimedia > Voice Recorder > Options*** and select one of the functions:

- ***New recording*** — start the voice recorder.
- ***List*** — list of previously made recordings.
- ***Settings > Save location*** — select the recording storage location: memory card / phone.
- ***Settings > Audio quality*** — select the audio recording file format.

FM Radio

Open ***Menu > FM Radio > Options*** and select one of the functions:

- ***Channel list*** — view the list of found radio stations.
- ***Manual input*** — enter a custom radio frequency.
- ***Auto search*** — search and save new radio stations.
- ***Settings > Background playback*** — allows you to use other phone functions without interrupting the radio listening.
- ***Settings > Audio quality*** — select the playback quality (Low, High).
- ***Settings > Save location*** — select the storage location for radio recordings.
- ***Record*** — activate the recording function.
- ***File list*** — view and play made recordings.

My Files

This menu section is available only when a compatible microSD memory card is connected.

Open ***Menu > My Files > Options*** and select one of the functions:

- ***Send*** — send the file via Bluetooth.
- ***New folder*** — create a new folder on the memory card.
- ***Rename*** — rename or copy a folder or file.
- ***Delete*** — delete the selected file or folder.
- ***Sort by*** — sort files by Name / Type / Time / Size.
- ***Mark multiple*** — delete, copy, move, or send multiple folders or files.
- ***Copy*** — copy the selected item.
- ***Move*** — move the selected item.
- ***Delete all files*** — delete all files in the folder.
- ***Details*** — information about the file size and creation date.

Phone Settings

Call Settings

Open ***Menu > Settings > Call Settings*** and select one of the functions:

- ***SIM Card Settings*** — in this menu, you can select which SIM cards will be active.
- ***SIM1/SIM2 Settings > Call waiting*** — enable/disable the function that allows you to accept a second incoming call.
- ***SIM1/SIM2 Settings > Call rejection*** — forward incoming calls under various conditions.
- ***SIM1/SIM2 Settings > Call barring*** — block incoming and outgoing calls under various conditions.

- ***SIM Card Settings > Answer with SIM1*** — when this function is activated, all outgoing calls and message sending will be made from the SIM card installed in the first slot (i.e., the mode for selecting which SIM card to use for outgoing calls and messages will be disabled).
- ***More > Blacklist*** — view and add numbers to the blacklist, as well as configure the Blacklist function.
- ***More > Whitelist*** — view and add numbers to the whitelist, as well as configure the Whitelist function.
- ***More > Auto call recording*** — enable automatic recording of phone calls.
  Note: This function works only when a memory card is connected.
- ***More > Auto redial*** — the phone makes several attempts to reconnect to the subscriber in case of an unsuccessful call.
- ***More > Call duration reminder*** — periodically reminds you of the current call duration.
- ***More > Reject with SMS*** — when rejecting an incoming call, you are prompted to send a text message to the rejected number.
- ***More > Answer mode*** — select the answer mode: auto answer with a headset and/or using any key.

User Profiles

Various phone parameters are combined into profiles (modes) that allow you to customize the phone's sound signals for different situations and operating conditions.

Open ***Menu > Profiles > Options*** and select one of the functions:

- ***Activate*** — activate the selected profile.
- ***Customize*** — customize the selected profile. Select the parameter whose value you want to change, and make the necessary changes.
- ***Reset*** — reset the profile's custom settings to default values.

Phone Settings

Open ***Menu > Settings > Phone*** and select one of the functions:

- ***Time and Date*** — change the time, date, as well as the time and date format.
- ***Scheduled power on/off*** — set the automatic power on/off of the phone at a specified time.
- ***Menu language*** — select the phone language.
- ***Input method*** — select the default message input method.
- ***Display settings*** — screen settings: Wallpaper, Screen/ Keypad light, Display date/SIM cards on the home screen.
- ***Shortcut keys*** — change the functions of the navigation keys.
- ***Airplane mode*** — in this mode, all wireless communication functions will be disabled.

Display Settings

Open ***Menu > Settings > Display Settings*** and select one of the functions:

- ***Wallpaper*** — set the home screen wallpaper.
- ***Screen light*** — set the screen brightness and the time it stays on.
- ***Keypad light*** — set the keypad backlight duration.
- ***Show date and time*** — enable/disable the display of time and date on the home screen.
- ***Always-on display*** — enable/disable the always-on screen mode.
- ***Show SIM cards*** — enable/disable the display of connected SIM cards on the home screen.

Security Settings

Open ***Menu > Settings > Security*** and select one of the functions:

- ***SIM1/SIM2 Protection > Change PIN*** — change the SIM card PIN code.
- ***Power-on password request > Phone lock*** — set a password when turning on the phone.
- ***Power-on password request > Change password*** — change the password used when turning on the phone.
- ***Keypad lock with power key*** — enable the function to lock the keypad when briefly pressing the phone's power on/off key.
- ***Auto keypad lock*** — set the time after which the phone will be automatically locked (Off / 15 sec / 30 sec / 1 min / 5 min).
- ***Data protection > Data protection*** — set a password for specific phone sections (Messages, calls, contacts, my files, keypad).
- ***Data protection > Change password*** — change the password used to restrict the selected phone section.

Emergency Calls

In this menu, you can configure the emergency call. To make an emergency call, press and hold the SOS button located on the back of the phone. The phone will send an emergency message and start calling the specified contacts. If the first emergency contact does not answer, the phone will sequentially dial the other listed contacts. An alarm signal can also be enabled.

Open ***Menu > Settings > Emergency Calls*** and select one of the functions:

- ***Status*** — enable or disable the emergency call function.
- ***Contacts*** — list of emergency contacts (maximum 5 contacts).
- ***Message*** — enable/disable the sending of an emergency message, as well as the template for it. The default text is: «I need help urgently!».
- ***Emergency alert*** — enable or disable the alarm siren.

Restore Settings

Reset all user settings and restore the default settings.

Note: the password for resetting user settings is **1234**.

Audio Player

The phone has a built-in music player designed for playing audio files in AAC, MP3, and WAV formats located on the memory card.

The music player is controlled by the following keys:

- ***Central «OK» key*** — play/pause playback.
- ***Up key*** — switch the audio file repeat mode: repeat one / repeat all / repeat off.
- ***Down key*** — switch the playback mode: sequential / shuffle.
- ***Right key / press and hold right key*** — skip to next track / fast forward current track.
- ***Left key / press and hold left key*** — skip to previous track / rewind current track.
- ***# key*** — increase volume.
- **** key*** — decrease volume.

Gallery

This menu is used to work with JPG images located on the memory card.

Open ***Menu > Gallery > Options*** and select one of the functions:

- ***Use as*** — set the selected file as the home screen wallpaper or as the power on/off animation.
- ***Rename*** — change the image file name.
- ***Delete*** — delete the selected image file.
- ***Mark multiple*** — delete, copy, move, or send the selected files.
- ***Details*** — view information about the image file.

Organizer

Operator Menu

This menu allows you to access the services portal provided by the network operator. The name and content of this menu are entirely determined by the set of available services. For more information about the sections of this menu, contact your mobile network operator.

Alarm

The phone can sound alarm signals at a specified time.
Open ***Menu > Alarm > Edit*** and select one of the functions:

- ***Status*** — enable or disable the selected alarm profile.
- ***Time*** — set the alarm activation time.
- ***Repeat mode*** — select the alarm frequency: once, weekly, or on selected days.
- ***Tone*** — set your own alarm melody from the memory card.

Calculator

The built-in calculator allows you to perform basic arithmetic operations. To enter a decimal point, press «**#**».

Calendar

The calendar provides monthly date viewing.

Time Zone

View the current time in different time zones.

Stopwatch

A function for measuring time intervals.

Bluetooth

This device is compatible with Bluetooth version 3.0 devices and allows you to connect a headset, download or transfer files. Bluetooth wireless technology provides communication with other compatible Bluetooth devices located within a range of up to 10 m.

Open ***Menu > Bluetooth*** and select one of the functions:

- ***Power*** — enable or disable the Bluetooth function.
- ***Visibility*** — select how the phone is displayed on other Bluetooth devices.
- ***My devices*** — search and connect any Bluetooth devices within the phone's range.
- ***Bluetooth name*** — change the displayed device name.

Games

The device supports two games: F1 Racing and Snake.

PC Connection

When connecting the phone to a compatible computer using a data cable, you can use your phone's memory card as a USB disk, which will allow you to transfer files from the memory card to the computer and vice versa.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Mobile phone

Warranty Period: 12 months.
Service Life: 24 months.

Included battery and charger

Warranty Period: 6 months.
Service Life: 12 months.

Other included accessories

Warranty Period: 3 months.
Service Life: 6 months.

For the up-to-date list of authorized service centers, please visit: https://www.dns-shop.ru/service-center/


Additional Information

Manufacturer: Yibin Boway Intelligence technology Co., LTD. No.27 Xinggang Road West Section, YiBin Port economic and technological development Zone,YiBin City, Sichuan Province, China

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.



Production date (mm.yyyy): _____v.1

