AJAZZ 黑爵

# 黑爵轻奢AC100系列机械键盘

AJAZZ AC100 SERIES MECHANICAL KEYBOARD

使用前请仔细阅读产品手册，以确保您能够正确使用该款机械键盘，同时产品具备多种模组功能与技巧，希望您能够轻松愉快地享受，更多操作技巧请关注黑爵官方微信公众号。

## 目 录 CATALOG


AC100 中文 1-5
AC100 English 6-10
AC100 PRO 中文 11-21
AC100 PRO English 22-32
AC100 MAX 中文 33-43
AC100 MAX English 44-54


## AC100标准光轴

### 一、基本参数

产品名称：A一一

产品型号：黑爵AC100

净重/毛重/包装重量：0.82/1.4/1.5kg

键盘规格：键数104键(US)/105键(ISO)

产品尺寸：436.0x135.0x20mm

产品质量：≈1200g

电池容量：4000mAh

单键寿命：5000万次

产品材料：ALU+ABS

键帽材料：PBT五面热升华

接触方式：3pin

支持系统：Windows Vista/XP/7/8/10/11, Mac

### 二、指示灯说明

1. Caps lock大写指示灯：

按下CAPS键后大写字母输入时常亮，再次按下熄灭。

2. Win锁指示灯：

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

3. Num指示灯：

按下NUM键后小键盘数字输入状态，再次按下NUM键后小键盘方向键输入状态。

### 三、多媒体组合键说明

| 组合键 | 说明 | Mac系统 | 组合键 | 说明 | Mac系统 |
|---|---|---|---|---|---|
| Fn+F1 | 静音锁定 | 静音锁定 | Fn+F7 | 播放/暂停 | 播放/暂停 |
| Fn+F2 | 音量减小 | 音量减小 | Fn+F8 | 下一曲 | 下一曲 |
| Fn+F3 | 音量增大 | 音量增大 | Fn+F9 | 停止 | 停止 |
| Fn+F4 | 静音 | 静音锁定 | Fn+F10 | 浏览器 | 静音锁定 |
| Fn+F5 | 播放/暂停 | 播放/暂停 | Fn+F11 | 计算器 | 音量减小 |
| Fn+F6 | 上一曲 | 上一曲 | Fn+F12 | 个人收藏 | 音量增大 |
| Fn+ESC | Scroll | | | | |

### 四、模式及组合键说明

1.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

2.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

3.Win键锁定/解锁

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

4.恢复出厂设置

按住Fn+ESC键3秒，键盘灯光闪烁3次，恢复出厂设置成功。

5.灯光模式切换

按Fn+Home键，灯光模式循环切换。

6.灯光亮度调节

按Fn+↑键，灯光亮度增加；按Fn+↓键，灯光亮度减小。

7.灯光速度调节

按Fn+→键，灯光速度增加；按Fn+←键，灯光速度减小。

8.灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

9.单色灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

10.灯光关闭

按Fn+Delete键，灯光关闭。

11.灯光开启

按Fn+Delete键，灯光开启。

12.恢复默认设置

按住Fn+Delete键3秒，键盘灯光闪烁3次，恢复默认设置成功。

### 五、电量显示及设置说明

充电指示灯：

Fn+Caps Lock键为电池电量

Fn+Win锁为充电状态

Fn+Esc键为电量显示

Fn+Del键为开启键盘唤醒，再按取消唤醒

Fn+PgUp键为键盘唤醒灯效

Fn+PgDn键为键盘唤醒灯色

Fn+↑键为键盘唤醒灯亮度

Fn+↓键为键盘唤醒灯速

### 六、多媒体组合键说明

| 组合键 | 说明 | Mac系统 | 组合键 | 说明 | Mac系统 |
|---|---|---|---|---|---|
| Fn+F1 | 静音锁定 | 静音锁定 | Fn+F7 | 播放/暂停 | 播放/暂停 |
| Fn+F2 | 音量减小 | 音量减小 | Fn+F8 | 下一曲 | 下一曲 |
| Fn+F3 | 音量增大 | 音量增大 | Fn+F9 | 停止 | 停止 |
| Fn+F4 | 静音 | 静音锁定 | Fn+F10 | 浏览器 | 静音锁定 |
| Fn+F5 | 播放/暂停 | 播放/暂停 | Fn+F11 | 计算器 | 音量减小 |
| Fn+F6 | 上一曲 | 上一曲 | Fn+F12 | 个人收藏 | 音量增大 |

### 七、键盘驱动安装说明

1.驱动安装前请先将键盘连接电脑

2.双击打开驱动安装文件

3.驱动安装完成后，即可使用键盘的自定义功能

## AC100 RBG版

### 一、基本参数

产品名称：A一一

产品型号：黑爵AC100

净重/毛重/包装重量：0.82/1.4/1.5kg

键盘规格：键数104键(US)/105键(ISO)

产品尺寸：436.0x135.0x20mm

产品质量：≈1200g

电池容量：4000mAh

单键寿命：5000万次

产品材料：ALU+ABS

键帽材料：PBT五面热升华

接触方式：3pin

支持系统：Windows Vista/XP/7/8/10/11, Mac



### 二、指示灯说明

1. Caps lock大写指示灯：

按下CAPS键后大写字母输入时常亮，再次按下熄灭。

2. Win锁指示灯：

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

3. Num指示灯：

按下NUM键后小键盘数字输入状态，再次按下NUM键后小键盘方向键输入状态。

### 三、多媒体组合键说明

| 组合键 | 说明 | Mac系统 | 组合键 | 说明 | Mac系统 |
|---|---|---|---|---|---|
| Fn+F1 | 静音锁定 | 静音锁定 | Fn+F7 | 播放/暂停 | 播放/暂停 |
| Fn+F2 | 音量减小 | 音量减小 | Fn+F8 | 下一曲 | 下一曲 |
| Fn+F3 | 音量增大 | 音量增大 | Fn+F9 | 停止 | 停止 |
| Fn+F4 | 静音 | 静音锁定 | Fn+F10 | 浏览器 | 静音锁定 |
| Fn+F5 | 播放/暂停 | 播放/暂停 | Fn+F11 | 计算器 | 音量减小 |
| Fn+F6 | 上一曲 | 上一曲 | Fn+F12 | 个人收藏 | 音量增大 |

### 四、模式及组合键说明

1.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

2.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

3.Win键锁定/解锁

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

4.恢复出厂设置

按住Fn+ESC键3秒，键盘灯光闪烁3次，恢复出厂设置成功。

5.灯光模式切换

按Fn+Home键，灯光模式循环切换。

6.灯光亮度调节

按Fn+↑键，灯光亮度增加；按Fn+↓键，灯光亮度减小。

7.灯光速度调节

按Fn+→键，灯光速度增加；按Fn+←键，灯光速度减小。

8.灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

9.单色灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

10.灯光关闭

按Fn+Delete键，灯光关闭。

11.灯光开启

按Fn+Delete键，灯光开启。

12.恢复默认设置

按住Fn+Delete键3秒，键盘灯光闪烁3次，恢复默认设置成功。

### 五、电量显示及设置说明

充电指示灯：

Fn+Caps Lock键为电池电量

Fn+Win锁为充电状态

Fn+Esc键为电量显示

Fn+Del键为开启键盘唤醒，再按取消唤醒

Fn+PgUp键为键盘唤醒灯效

Fn+PgDn键为键盘唤醒灯色

Fn+↑键为键盘唤醒灯亮度

Fn+↓键为键盘唤醒灯速

### 六、多媒体组合键说明

| 组合键 | 说明 | Mac系统 | 组合键 | 说明 | Mac系统 |
|---|---|---|---|---|---|
| Fn+F1 | 静音锁定 | 静音锁定 | Fn+F7 | 播放/暂停 | 播放/暂停 |
| Fn+F2 | 音量减小 | 音量减小 | Fn+F8 | 下一曲 | 下一曲 |
| Fn+F3 | 音量增大 | 音量增大 | Fn+F9 | 停止 | 停止 |
| Fn+F4 | 静音 | 静音锁定 | Fn+F10 | 浏览器 | 静音锁定 |
| Fn+F5 | 播放/暂停 | 播放/暂停 | Fn+F11 | 计算器 | 音量减小 |
| Fn+F6 | 上一曲 | 上一曲 | Fn+F12 | 个人收藏 | 音量增大 |

## AC100 MAX版

### 一、基本参数

产品名称：A一一

产品型号：黑爵AC100MAX

净重/毛重/包装重量：0.82/1.4/1.5kg

键盘规格：键数104键(US)/105键(ISO)

产品尺寸：436.0x135.0x20mm

产品质量：≈1200g（无旋钮）/≈1250g（有旋钮）

电池容量：4000mAh（无旋钮）/4800mAh（有旋钮）

单键寿命：5000万次

产品材料：ALU+ABS+PC

灯光效果：RGB三区域灯效

键帽材料：ABS键帽

接触方式：3pin

支持系统：Windows Vista/XP/7/8/10/11, Mac



### 二、指示灯说明

1. Caps lock大写指示灯：

未按大写灯，无键盘显示；按完整的大写后，键盘显示。

2. Win锁指示灯：

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

3. Num指示灯：

按下NUM键后小键盘数字输入状态，再次按下NUM键后小键盘方向键输入状态。

### 三、多媒体组合键说明

| 组合键 | 说明 | Mac系统 | 组合键 | 说明 | Mac系统 |
|---|---|---|---|---|---|
| Fn+F1 | 静音锁定 | 静音锁定 | Fn+F7 | 播放/暂停 | 播放/暂停 |
| Fn+F2 | 音量减小 | 音量减小 | Fn+F8 | 下一曲 | 下一曲 |
| Fn+F3 | 音量增大 | 音量增大 | Fn+F9 | 停止 | 停止 |
| Fn+F4 | 静音 | 静音锁定 | Fn+F10 | 浏览器 | 静音锁定 |
| Fn+F5 | 播放/暂停 | 播放/暂停 | Fn+F11 | 计算器 | 音量减小 |
| Fn+F6 | 上一曲 | 上一曲 | Fn+F12 | 个人收藏 | 音量增大 |

### 四、模式及组合键说明

1.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

2.有线模式/蓝牙1模式/蓝牙2模式/2.4G模式

切换方法：开关机状态下，按住Fn+1/2/3/4键3秒，进入相应模式，切换成功后灯光有闪烁提示。

3.Win键锁定/解锁

按下Win锁键后键盘进入锁定状态，再次按下Win锁键后键盘恢复正常状态。

4.恢复出厂设置

按住Fn+ESC键3秒，键盘灯光闪烁3次，恢复出厂设置成功。

5.灯光模式切换

按Fn+Home键，灯光模式循环切换。

6.灯光亮度调节

按Fn+↑键，灯光亮度增加；按Fn+↓键，灯光亮度减小。

7.灯光速度调节

按Fn+→键，灯光速度增加；按Fn+←键，灯光速度减小。

8.灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

9.单色灯光颜色调节

按Fn+Insert键，灯光颜色循环切换。

10.灯光关闭

按Fn+Delete键，灯光关闭。

11.灯光开启

按Fn+Delete键，灯光开启。

12.恢复默认设置

按住Fn+Delete键3秒，键盘灯光闪烁3次，恢复默认设置成功。

### 五、电量显示及设置说明

充电指示灯：

Fn+Caps Lock键为电池电量

Fn+Win锁为充电状态

Fn+Esc键为电量显示

Fn+Del键为开启键盘唤醒，再按取消唤醒

Fn+PgUp键为键盘唤醒灯效

Fn+PgDn键为键盘唤醒灯色

Fn+↑键为键盘唤醒灯亮度

Fn+↓键为键盘唤醒灯速

## AC100 MAX Version

### 1.Product Specifications

Product name: A一一

Product model: AC100 MAX

Product weight: ≈1200g (without knob) /≈1250g (with knob)

Product size: 436.0x135.0x20mm

Battery capacity: 4000mAh (without knob) /4800mAh (with knob)

Single key life: 50 million times

Product material: ALU+ABS+PC

Lighting effects: RGB three-zone lighting effects

Key material: ABS keys

Contact method: 3pin

Compatible systems: Windows Vista/XP/7/8/10/11, Mac

### 2.Indicator Light Description

1. Caps lock uppercase indicator light:

The indicator light is on when the uppercase letter is entered, and off when the uppercase letter is not entered.

2. Win lock indicator light:

The indicator light is on when the Win lock is locked, and off when the Win lock is unlocked.

3. Num indicator light:

The indicator light is on when the numeric keypad is in numeric input mode, and off when the numeric keypad is in direction key input mode.

### 3.Multimedia Key Combination Description

| Key combination | Description | Mac system | Key combination | Description | Mac system |
|---|---|---|---|---|---|
| Fn+F1 | Mute Lock | Mute Lock | Fn+F7 | Play / Pause | Play / Pause |
| Fn+F2 | Volume down | Volume down | Fn+F8 | Next track | Next track |
| Fn+F3 | Volume increase | Volume increase | Fn+F9 | Stop | Stop |
| Fn+F4 | Mute | Mute Lock | Fn+F10 | Browser | Mute Lock |
| Fn+F5 | Play / Pause | Play / Pause | Fn+F11 | Calculator | Volume down |
| Fn+F6 | Previous track | Previous track | Fn+F12 | My computer | Volume increase |
| Fn+ESC | Scroll | | | | |

### 4.Mode Switching Instructions

1. Wired mode/Bluetooth 1 mode/Bluetooth 2 mode/2.4G mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the pairing mode. After the pairing is successful, the Esc key light is always on. After the pairing fails, the Esc key light flashes quickly to enter the auto pairing mode. After the connection is successful, the light returns to normal lighting effect.

2. Wired mode/Bluetooth 1 mode/Bluetooth 2 mode/2.4G mode

Switching method: Short press the Fn key combination to switch the BT channel. The light of the Esc key flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect.

Note: When the Fn key is pressed, the current channel is displayed. If the current connection is BT channel 3 (BT3), the Win key flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect. When the Fn key is pressed, the Win key displays a green light.

3. Win lock switch

Press the Win lock key to lock the key, and press it again to unlock.

4. Num indicator light:

Press to toggle between numeric keypad and direction keypad.

### 5. Light Switching Key Combination Description

Fn + ↑: Backlight brightness increases; Fn + ↓: Backlight brightness decreases.

Fn + →: Light speed increases; Fn + ←: Light speed decreases.

Fn + Home: Switch lighting effects.

Fn + Insert: Switch the color of the lighting effects.

Fn + Delete: Turn off the lighting effects.

Fn + Delete for 3 seconds: Restore factory settings.

### 6. Multimedia Key Combination Description

| Key combination | Description | Mac system | Key combination | Description | Mac system |
|---|---|---|---|---|---|
| Fn+F1 | Mute Lock | Mute Lock | Fn+F7 | Play / Pause | Play / Pause |
| Fn+F2 | Volume down | Volume down | Fn+F8 | Next track | Next track |
| Fn+F3 | Volume increase | Volume increase | Fn+F9 | Stop | Stop |
| Fn+F4 | Mute | Mute Lock | Fn+F10 | Browser | Mute Lock |
| Fn+F5 | Play / Pause | Play / Pause | Fn+F11 | Calculator | Volume down |
| Fn+F6 | Previous track | Previous track | Fn+F12 | My computer | Volume increase |
| Fn+ESC | Scroll | | | | |

### 7. Power Display and Setting Instructions

Charging indicator: When charging, the Fn+Caps Lock key lights up.

Fully charged status: When fully charged, the Fn+Win key lights up.

Battery level display: Fn+Esc key.

Turn on/off keyboard wake-up: Fn+Del key.

Wake-up light effect switching: Fn+PgUp key.

Wake-up light color switching: Fn+PgDn key.

Wake-up light brightness adjustment: Fn+↑ key.

Wake-up light speed adjustment: Fn+→ key.

### 8. Lighting Effect Description

Turn on/off lighting effects: Fn+Home key.

Switch lighting effects: Fn+Home key.

Lighting effect brightness adjustment: Fn+↑ key to increase brightness, Fn+↓ key to decrease brightness.

Lighting effect speed adjustment: Fn+→ key to increase speed, Fn+← key to decrease speed.

Lighting effect color switching: Fn+Insert key.

Restore factory settings: Fn+Delete key.

### 9. Light Switching Key Combination Description

Fn + ↑: Backlight brightness increases; Fn + ↓: Backlight brightness decreases.

Fn + →: Light speed increases; Fn + ←: Light speed decreases.

Fn + Home: Switch lighting effects.

Fn + Insert: Switch the color of the lighting effects.

Fn + Delete: Turn off the lighting effects.

Fn + Delete for 3 seconds: Restore factory settings.

### 10. Multimedia Key Combination Description

| Key combination | Description | Mac system | Key combination | Description | Mac system |
|---|---|---|---|---|---|
| Fn+F1 | Mute Lock | Mute Lock | Fn+F7 | Play / Pause | Play / Pause |
| Fn+F2 | Volume down | Volume down | Fn+F8 | Next track | Next track |
| Fn+F3 | Volume increase | Volume increase | Fn+F9 | Stop | Stop |
| Fn+F4 | Mute | Mute Lock | Fn+F10 | Browser | Mute Lock |
| Fn+F5 | Play / Pause | Play / Pause | Fn+F11 | Calculator | Volume down |
| Fn+F6 | Previous track | Previous track | Fn+F12 | My computer | Volume increase |
| Fn+ESC | Scroll | | | | |

### 11. Power Display and Setting Instructions

Charging indicator: When charging, the Fn+Caps Lock key lights up.

Fully charged status: When fully charged, the Fn+Win key lights up.

Battery level display: Fn+Esc key.

Turn on/off keyboard wake-up: Fn+Del key.

Wake-up light effect switching: Fn+PgUp key.

Wake-up light color switching: Fn+PgDn key.

Wake-up light brightness adjustment: Fn+↑ key.

Wake-up light speed adjustment: Fn+→ key.

### 12. Lighting Effect Description

Turn on/off lighting effects: Fn+Home key.

Switch lighting effects: Fn+Home key.

Lighting effect brightness adjustment: Fn+↑ key to increase brightness, Fn+↓ key to decrease brightness.

Lighting effect speed adjustment: Fn+→ key to increase speed, Fn+← key to decrease speed.

Lighting effect color switching: Fn+Insert key.

Restore factory settings: Fn+Delete key.

### 13. Restore Default Settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

## AC100 Single mode single light version

### 1.Product Specifications

Product brand: AJAZZ

Product model: AC100

Transmission method: USB wired

Interface type: Separate Type-C interface

Product size: 436.0x135.0x20mm

Product weight: ≈1200g

Lighting effects: Single light (28 lighting effects)

Key travel: 3.5±0.4mm

Key material: ABS keys

Contact method: Gasket structure

Compatible systems: Windows Vista/XP/7/8/10/11, Mac

### 2.Indicator Light Description

2.1. Caps lock switch indicator light:

Press Caps Lock to turn on uppercase, press again to restore lowercase.

2.2. Lock Win indicator light:

Press the Win lock to lock the key, and press it again to unlock.

2.3. Num indicator light:

Press Num Lock to switch between numeric keypad and direction keypad.

### 3. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 4. Mode Switching Instructions

4.1. Wired mode/2.4G mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the pairing mode. After the pairing is successful, the Esc key is always on. After the pairing fails, the Esc key flashes quickly to enter the auto pairing mode. After the connection is successful, the light returns to normal lighting effect.

4.2. Wired mode/2.4G mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect.

Note: When the Fn key is pressed, the current channel is displayed. If the current connection is BT channel 3 (BT3), the Win key flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect. When the Fn key is pressed, the Win key displays a green light.

4.3. Win lock switch

Press the Win lock key to lock the key, and press it again to unlock.

4.4. Restore factory settings

Press and hold the Fn+Esc keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

4.5. Lighting effect switching

Press Home key to switch lighting effects.

4.6. Lighting effect brightness adjustment

Press the Fn+↑ key to increase the brightness, and press the Fn+↓ key to decrease the brightness.

4.7. Lighting effect speed adjustment

Press the Fn+→ key to increase the speed, and press the Fn+← key to decrease the speed.

4.8. Lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.9. Single-color lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.10. Turn off lighting effects

Press the Fn+Delete keys to turn off the lighting effects.

4.11. Turn on lighting effects

Press the Fn+Delete keys to turn on the lighting effects.

4.12. Restore default settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

### 5. Light Switching Key Combination Description

Fn + ↑: Backlight brightness increases; Fn + ↓: Backlight brightness decreases.

Fn + →: Light speed increases; Fn + ←: Light speed decreases.

Fn + Home: Switch lighting effects.

Fn + Insert: Switch the color of the lighting effects.

Fn + Delete: Turn off the lighting effects.

Fn + Delete for 3 seconds: Restore factory settings.

### 6. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 7. Power Display and Setting Instructions

Charging indicator: When charging, the Fn+Caps Lock key lights up.

Fully charged status: When fully charged, the Fn+Win key lights up.

Battery level display: Fn+Esc key.

Turn on/off keyboard wake-up: Fn+Del key.

Wake-up light effect switching: Fn+PgUp key.

Wake-up light color switching: Fn+PgDn key.

Wake-up light brightness adjustment: Fn+↑ key.

Wake-up light speed adjustment: Fn+→ key.

### 8. Lighting Effect Description

Turn on/off lighting effects: Fn+Home key.

Switch lighting effects: Fn+Home key.

Lighting effect brightness adjustment: Fn+↑ key to increase brightness, Fn+↓ key to decrease brightness.

Lighting effect speed adjustment: Fn+→ key to increase speed, Fn+← key to decrease speed.

Lighting effect color switching: Fn+Insert key.

Restore factory settings: Fn+Delete key.

### 9. Restore Default Settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

## AC100 RBG Version

### 1.Product Specifications

Product brand: AJAZZ

Product model: AC100 PRO

Transmission method: USB wired+2.4G+BT 5.1

Interface type: Separate Type-C interface

Product size: 436.0x135.0x20mm

Product weight: ≈1220g

Battery capacity: 4000mAh

Single key life: 50 million times

Product structure: Gasket structure

Lighting effects: RGB three-zone lighting effects

Key layout: 104 keys

Contact method: Hot-swappable

Compatible systems: Windows Vista/XP/7/8/10/11, Mac

### 2.Indicator Light Description

2.1. Caps lock switch indicator light:

Press Caps Lock to turn on uppercase, press again to restore lowercase.

2.2. Lock Win indicator light:

Press the Win lock to lock the key, and press it again to unlock.

2.3. Num indicator light:

Press Num Lock to switch between numeric keypad and direction keypad.

### 3. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 4. Mode Connection Instructions

4.1. BT connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the pairing mode. After the pairing is successful, the Esc key is always on. After the pairing fails, the Esc key flashes quickly to enter the auto pairing mode. After the connection is successful, the light returns to normal lighting effect.

4.2. 2.4G connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect.

Note: When the Fn key is pressed, the current channel is displayed. If the current connection is BT channel 3 (BT3), the Win key flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect. When the Fn key is pressed, the Win key displays a green light.

4.3. Win lock switch

Press the Win lock key to lock the key, and press it again to unlock.

4.4. Restore factory settings

Press and hold the Fn+Esc keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

4.5. Lighting effect switching

Press Home key to switch lighting effects.

4.6. Lighting effect brightness adjustment

Press the Fn+↑ key to increase the brightness, and press the Fn+↓ key to decrease the brightness.

4.7. Lighting effect speed adjustment

Press the Fn+→ key to increase the speed, and press the Fn+← key to decrease the speed.

4.8. Lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.9. Single-color lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.10. Turn off lighting effects

Press the Fn+Delete keys to turn off the lighting effects.

4.11. Turn on lighting effects

Press the Fn+Delete keys to turn on the lighting effects.

4.12. Restore default settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

### 5. Light Switching Key Combination Description

Fn + ↑: Backlight brightness increases; Fn + ↓: Backlight brightness decreases.

Fn + →: Light speed increases; Fn + ←: Light speed decreases.

Fn + Home: Switch lighting effects.

Fn + Insert: Switch the color of the lighting effects.

Fn + Delete: Turn off the lighting effects.

Fn + Delete for 3 seconds: Restore factory settings.

### 6. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 7. Power Display and Setting Instructions

Charging indicator: When charging, the Fn+Caps Lock key lights up.

Fully charged status: When fully charged, the Fn+Win key lights up.

Battery level display: Fn+Esc key.

Turn on/off keyboard wake-up: Fn+Del key.

Wake-up light effect switching: Fn+PgUp key.

Wake-up light color switching: Fn+PgDn key.

Wake-up light brightness adjustment: Fn+↑ key.

Wake-up light speed adjustment: Fn+→ key.

### 8. Lighting Effect Description

Turn on/off lighting effects: Fn+Home key.

Switch lighting effects: Fn+Home key.

Lighting effect brightness adjustment: Fn+↑ key to increase brightness, Fn+↓ key to decrease brightness.

Lighting effect speed adjustment: Fn+→ key to increase speed, Fn+← key to decrease speed.

Lighting effect color switching: Fn+Insert key.

Restore factory settings: Fn+Delete key.

### 9. Restore Default Settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

## AC100 PRO 中文

### 1.Product Specifications

Product brand: AJAZZ

Product model: AC100 PRO

Transmission method: USB wired+2.4G+BT 5.1

Interface type: Separate Type-C interface

Product size: 436.0x135.0x20mm

Product weight: ≈1220g

Battery capacity: 4000mAh

Single key life: 50 million times

Product structure: Gasket structure

Lighting effects: RGB three-zone lighting effects

Key layout: 104 keys

Contact method: Hot-swappable

Compatible systems: Windows Vista/XP/7/8/10/11, Mac

### 2.Indicator Light Description

2.1. Caps lock switch indicator light:

Press Caps Lock to turn on uppercase, press again to restore lowercase.

2.2. Lock Win indicator light:

Press the Win lock to lock the key, and press it again to unlock.

2.3. Num indicator light:

Press Num Lock to switch between numeric keypad and direction keypad.

### 3. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 4. Mode Connection Instructions

4.1. BT connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the pairing mode. After the pairing is successful, the Esc key is always on. After the pairing fails, the Esc key flashes quickly to enter the auto pairing mode. After the connection is successful, the light returns to normal lighting effect.

4.2. 2.4G connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect.

Note: When the Fn key is pressed, the current channel is displayed. If the current connection is BT channel 3 (BT3), the Win key flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect. When the Fn key is pressed, the Win key displays a green light.

4.3. Win lock switch

Press the Win lock key to lock the key, and press it again to unlock.

4.4. Restore factory settings

Press and hold the Fn+Esc keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

4.5. Lighting effect switching

Press Home key to switch lighting effects.

4.6. Lighting effect brightness adjustment

Press the Fn+↑ key to increase the brightness, and press the Fn+↓ key to decrease the brightness.

4.7. Lighting effect speed adjustment

Press the Fn+→ key to increase the speed, and press the Fn+← key to decrease the speed.

4.8. Lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.9. Single-color lighting effect color switching

Press the Fn+Insert key to switch the color of the lighting effects.

4.10. Turn off lighting effects

Press the Fn+Delete keys to turn off the lighting effects.

4.11. Turn on lighting effects

Press the Fn+Delete keys to turn on the lighting effects.

4.12. Restore default settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

### 5. Light Switching Key Combination Description

Fn + ↑: Backlight brightness increases; Fn + ↓: Backlight brightness decreases.

Fn + →: Light speed increases; Fn + ←: Light speed decreases.

Fn + Home: Switch lighting effects.

Fn + Insert: Switch the color of the lighting effects.

Fn + Delete: Turn off the lighting effects.

Fn + Delete for 3 seconds: Restore factory settings.

### 6. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 7. Power Display and Setting Instructions

Charging indicator: When charging, the Fn+Caps Lock key lights up.

Fully charged status: When fully charged, the Fn+Win key lights up.

Battery level display: Fn+Esc key.

Turn on/off keyboard wake-up: Fn+Del key.

Wake-up light effect switching: Fn+PgUp key.

Wake-up light color switching: Fn+PgDn key.

Wake-up light brightness adjustment: Fn+↑ key.

Wake-up light speed adjustment: Fn+→ key.

### 8. Lighting Effect Description

Turn on/off lighting effects: Fn+Home key.

Switch lighting effects: Fn+Home key.

Lighting effect brightness adjustment: Fn+↑ key to increase brightness, Fn+↓ key to decrease brightness.

Lighting effect speed adjustment: Fn+→ key to increase speed, Fn+← key to decrease speed.

Lighting effect color switching: Fn+Insert key.

Restore factory settings: Fn+Delete key.

### 9. Restore Default Settings

Press and hold the Fn+Delete keys for 3 seconds, the keyboard backlight will flash 3 times, and the restore default settings is successful.

## AC100 PRO English

### 1.Product Specifications

Product brand: AJAZZ

Product model: AC100 PRO

Transmission method: USB wired+2.4G+BT 5.1

Interface type: Separate Type-C interface

Product size: 436.0x135.0x20mm

Product weight: ≈1220g

Battery capacity: 4000mAh

Single key life: 50 million times

Product structure: Gasket structure

Lighting effects: RGB three-zone lighting effects

Key layout: 104 keys

Contact method: Hot-swappable

Compatible systems: Windows Vista/XP/7/8/10/11, Mac

### 2.Indicator Light Description

2.1. Caps lock switch indicator light:

Press Caps Lock to turn on uppercase, press again to restore lowercase.

2.2. Lock Win indicator light:

Press the Win lock to lock the key, and press it again to unlock.

2.3. Num indicator light:

Press Num Lock to switch between numeric keypad and direction keypad.

### 3. Multimedia Key Combination Description

| Key combination | Description | Key combination | Description |
|---|---|---|---|
| Fn+F1 | Mute(Mute Lock) | Fn+F7 | Play / Pause |
| Fn+F2 | Volume down | Fn+F8 | Next track |
| Fn+F3 | Volume increase | Fn+F9 | Stop |
| Fn+F4 | Mute | Fn+F10 | Browser |
| Fn+F5 | Play / Pause | Fn+F11 | Calculator |
| Fn+F6 | Previous track | Fn+F12 | My computer |
| Fn+ESC | Scroll | | |

### 4. Mode Connection Instructions

4.1. BT connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the pairing mode. After the pairing is successful, the Esc key is always on. After the pairing fails, the Esc key flashes quickly to enter the auto pairing mode. After the connection is successful, the light returns to normal lighting effect.

4.2. 2.4G connection mode

Switching method: Short press the Fn key combination to switch the BT channel. The Esc key light flashes slowly and enters the reconnection state. If the reconnection is successful, the light returns to normal lighting effect.

Note: When the Fn key is pressed, the current