ATK GEAR

ATK × QK Hex80 User Manual

Models:ATK× QK Hex80

HEX80 Quick Start Guide

Keymap



Caps Lock:
White (ON), Syncs with backlight (OFF).

Win Lock:
Red (LOCKED), Syncs with lighting (UNLOCKED).

Scroll Lock:
White (ON), Syncs with backlight (OFF).

Profile Key :
LED indicator shows the active profile color for 1s after pressing.
Profiles can be customized through the web configurator.

LED1:
Cycle backlight effects.

LED2:
Cycle logo lightbar effects.

Product Specification

Packaging Contents:
Carrying Case ×1/ Hex80 Keyboard×1/Accessory Kit×1/User Manual ×1
Compliance Certificate ×1

Complimentary Accessories:
Backup Switches ×4/USB Cable ×1/Keycap & Switch Puller ×1

Dimensions:
357×136.5×35 mm (Excluding rubber feet)

Front Height:
18 mm with 7° typing angle (Excluding rubber feet)

Connection & Configuration

Keyboard Connection:
Connect your keyboard to your device using the included USB-C to USB -A cable. The keyboard lights will illuminate when successfully connected.
·For optimal performance, calibrate all keys through the ATK HUB Web Configurator before initial use.
·The keyboard needs to be connected to a USB 3.0 port to ensure stable power supply and optimal product performance.

Web Configurator:
Visit HUB.ATK.STORE to access all keyboard features, including custom key mapping, macro configuration, and other advanced functions.

Important Notice

This device contains Hall effect sensors and magnetic components. Please keep it away from magnetic objects to ensure normal operation.

FN Combination Shortcut Keys

FN +	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
WIN Functions	Screen Brightness -	Screen Brightness +	Home	Email	Calculator	Media Player	Previous Track	Play/ Pause	Next Track	Mute	Volume -	Volume +
MAC Functions	Screen Brightness -	Screen Brightness +	Mission Control	Spotlight Search		Screenshot	Previous Track	Play/ Pause	Next Track	Mute	Volume -	Volume +

Delete	Lwin	WIN
Toggle NKRO /6KRO	Hold 3s: Factory Reset	Lock Windows Key

Fn + C

Toggle Win/Mac mode switch L-win and L-alt, change fn layers to offer system compatibility

Hex80

ATK GEAR × qc

HEX80 使用说明

键位说明



SCROLL指示灯：
开为白色，关为跟随灯效变化

CAP指示灯：
大写为白色，小写跟随灯效变化

锁WN指示灯：
锁住时为红色，没锁时跟随灯效变化

FILE键：
一键切换配置文件，灯条显示对应颜色1秒后恢复原灯效，您可以在驱动中自由设置配置文件

LED1键：
切换背光灯灯效

LED2键：
切换左右LOGO灯条灯效

产品规格

包装内清单： 键盘包x1/键盘本体x1/配件袋x1/使用说明x1/合格证x1保修卡x1
赠送清单： 备用轴x4/数据线x1/双拔器x1
键盘尺寸： 357*136.5*35MM(不含脚垫)
键盘前高： 18MM 坡度:7°(不含脚垫)

产品驱动

键盘连接：
使用本产品USB线材连接至键盘Type-C接口以及设备端USB-A接口，键盘灯光亮起则连接成功。
• 第一次使用本产品前，建议在网页驱动 **ATK HUB** 重新校准键盘按键，以达到最佳使用状态。
• 将键盘有线连接至USB3.0接口，以保证键盘的供电稳定及产品性能。

下载驱动：
自定义按键、宏编辑、快速触发和下载驱动，请访问 **HUB.ATK.PRO** 或扫描二维码。

注意事项

注意：
键盘内含霍尔传感器、磁力组件，使用本产品时请远离含磁物体以保证正常工作。

FN组合功能

Fn +	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12	Mute	Delete	Win
win功能	亮度-	亮度+	主页	邮件	计算器	播放器	上一曲	播放/暂停	下一曲	静音	音量-	音量+	切换全键无冲/6 键无冲	长按 3s 恢复出厂设置	锁 WIN
mac功能	亮度-	亮度+	控制台	聚焦搜索		截图	上一曲	播放/暂停	下一曲	静音	音量-	音量+			

Fn + C
切换 win/mac 模式，调换win和alt位置，并且适配FN组合快捷键功能。

Hex80

ATK GEAR × dc