




Xerox® Phaser® 3020


Xerox® WorkCentre® 3025



Xerox® Phaser® 3020




Xerox® WorkCentre® 3025 BI




Xerox® WorkCentre® 3025 NI

1




2

2.1



2.2




3


3.2

3.1

3.3




4




5

6x



6



7

