


Toner Cartridge • Cartouche de toner • Cartuccia toner • Tonermodul • Cartucho de tóner • Cartutx de tòner
Cartucho de toner • Tonercassette • Färgpulverkassett • Fargepulverkassett • Tonerpatron • Värikasetti
Тонер-картридж • Kazeta s tonerem • Wkład toneru • Festékkazetta • Cartuş cu toner • Toner Kartuşu • Κασέτα γραφίτη

Xerox® VersaLink® C400

Color Printer • Imprimante couleur • Stampante a colori • Farbdrucker • Impressora de color • Impressora de color
Impressora em cores • Kleurenprinter • Färgskrivare • Fargeskriver • Farveprinter • Väritulostin • Цветной принтер
Barevná tiskárna • Drukarka kolorowa • Színes nyomtatók • Imprimantă color • Renkli Yazıcı • Έγχρωμος εκτυπωτής


Xerox® VersaLink® C405

Color Multifunction Printer • Imprimante multifonctions couleur • Stampante multifunzione a colori • Farb-Multifunktionsdrucker
Impressora multifunción de color • Impressora multifunció d'impressió en color • Impressora multifuncional em cores
Multifunctionele kleurenprinter • Flerfunktionskrivare (färg) • Flerfunksjonell fargeskriver • Multifunktiyonel farveprinter
Värimonitoimitulostin • Многофункциональный цветной принтер • Barevná multifunkční tiskárna • Kolorowa drukarka wielofunkcyjna
Színes többfunkciós nyomtató • Echipament multifuncțional color • Renkli Çok Fonksiyonlu Yazıcı • Έγχρωμος πολυλειτουργικός εκτυπωτής




Xerox® VersaLink® C400 Xerox® VersaLink® C405


1




2



3




4




5

5



6



7

