aceline

User Manual

Speakers 2.0
ASP220

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you products and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the product, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.


Intended Use

Speakers are sound reproduction devices designed to connect to a personal computer, laptop, or other devices serving as an audio source, provided that the appropriate audio jacks are available.

Safety Precautions

- To avoid electric shock, do not disassemble or open the device housing. Do not attempt to repair it yourself. Any device maintenance must be performed only by qualified specialists at an authorized service center.
- Do not allow speaker wires (including grounded ones) to short-circuit with each other, the amplifier housing, or the ground, as this will damage the amplifier's output stages.
- Disconnect the device from the power supply if it will not be used for an extended period.
- When disconnecting the device from the power supply, grasp only the insulated part of the plug. Do not pull the cord.
- Do not touch the device with wet hands.
- Protect the device from foreign objects entering the housing or any of its openings. Ensure that needles, hairpins, coins, and other small items, as well as insects, do not get inside the device.
- Protect the device from water and any liquids, moisture, extreme temperatures, dust, and dirt.
- Do not install the device in rooms with high humidity and dust levels. Do not place containers with liquids (vases, glasses, bottles, etc.) on or in the immediate vicinity of the device.
- Protect the device from overheating. Do not place it near powerful heat sources (heating appliances, etc.), and do not expose it to direct sunlight or open flames.
- This device is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety. Do not allow children to play with the device.
- Do not use benzene-containing substances, alcohols, or solvents to clean the device, as they may damage the device and its painted surface. Use exclusively a soft, dry cloth for cleaning the device.
- Use the device only for its intended purpose.
- If the device stops functioning or functions improperly, immediately discontinue its use and contact a service center.
- This device is not intended for commercial use.

Device Diagram



1. Power control knob.
2. Microphone audio output.
3. Power indicator.
4. Headphone audio output.
5. Volume control knob.
6. USB power supply connector.
7. Microphone audio jack connector (3.5 mm).
8. Headphone audio jack connector (3.5 mm).

Operating Instructions

1. Position the speakers symmetrically relative to the listener at a distance of at least one meter.
2. Slight image distortion may occur on highly sensitive monitors and TVs, so install the speakers at a distance from these devices.
3. Connect the device's USB connector to the USB port of a computer/laptop or a power supply.
4. Connect the device's audio cable to the audio jack of the signal source (player, smartphone, tablet, PC, etc.).

Troubleshooting Guide

Issue	Possible cause	Solution
Device does not turn on	Device is not connected to the power supply or is connected incorrectly	Check the device's connection to the power supply
No sound or sound is too quiet	Volume control knob is set to the lowest volume	Adjust the volume control knob
	Audio signal source is connected incorrectly	Connect the signal sources correctly
Sound distortion	High amplitude of the input signal	Adjust the volume directly on the signal source to an optimal level, and also adjust the speaker volume

Specifications

- Model: ASP220.
- Trademark: Aceline.
- Power: 2 × 2 W.
- Volume control knob.
- Wired connection type: 3.5 mm.
- Headphone output port.
- Microphone output port.
- USB power supply.
- Scope of application: Domestic.

Package Contents

- Speakers (2 pcs).
- User manual.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- The device does not require installation or permanent mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported under dry conditions.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 12 months
Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:
https://www.dns-shop.ru/service-center/

Additional Information

Manufacturer: SHENZHEN FENGMINGYI TECHNOLOGY CO. LTD.
1–3 Building, ShengTong Industry Area, ZhangKengJing, Shenzhen, Guangdong, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy):_____v.1

aceline