

aceline

User Manual

Office Desk
Basic 130

Intended Use

The office desk is designed to provide comfortable working conditions.





Safety Precautions

- Use the product only for its intended purpose.
- Do not exceed the maximum load capacity.
- Assemble the product strictly in accordance with the provided user manual. Although the product can be assembled by a non-professional, if you have the slightest doubts about your abilities, please contact professional furniture assemblers.
- Avoid direct exposure of the furniture to sunlight. Prolonged direct light on certain areas may cause discolouration compared to other areas that receive less exposure.
- Extreme heat or cold, as well as sudden temperature changes, can seriously damage the furniture or its parts.
- The furniture must not be placed closer than one meter to heat sources or heating appliances.
- Do not place hot objects (irons, hot dishes, etc.) on the furniture, and avoid prolonged exposure to heating radiation (light from powerful lamps, microwave emitters, etc.).
- Avoid prolonged conditions of extreme humidity or dryness, and especially their periodic alternation. Over time, such conditions may affect the integrity of the furniture and its parts. If such conditions occur, it is recommended to ventilate the room frequently and use dehumidifiers or humidifiers as necessary to normalise humidity levels.
- Do not place the furniture near damp or wet walls or objects.
- It is not recommended to stand on the furniture, jump, or subject it to excessive dynamic loads.
- It is recommended to periodically check the tightness of screw connections and retighten them if necessary.
- Under no circumstances allow the furniture to be exposed to aggressive liquids (acids, alkalis, solvents, etc.), products containing such liquids, or their vapors.
- Dust should be removed from the surface of the product with a dry, soft cloth.


Specifications

- Model: Basic 130.
- Trademark: Aceline.
- Maximum load capacity: 15 kg.
- Dimensions (W×D×H): 1300 × 730 × 750 mm.
- Desktop material: Laminated chipboard (LDSP).
- Scope of application: Domestic.

Assembly Instructions

1. Side panel	494 × 728 mm	1 pc.
2. Side panel	494 × 728 mm	1 pc.
3. Crossbar	1200 × 300 mm	1 pc.
4. Desktop	1300 × 730 mm	1 pc.
5. Confirmat screw plugs		4 pcs
6. Nails 1.2 × 25 mm		8 pcs
7. Furniture glides		4 pcs
8. Confirmat screws		4 pcs
9. Hex key for confirmat screws		1 pc.
10. Dowel		4 pcs
11. Cam lock fitting		5 pcs

Tools required for assembly




Cam lock assembly description


1. The cam bolt is screwed into the pre-drilled hole of the panel.
2. The cam lock is inserted into the hole in the adjoining panel.
3. The parts are joined together and secured by turning the cam lock.

Note: Before assembly, carefully read this user manual and check the completeness of the hardware. The packaging and padding material can be used as a protective base during assembly. Perform the assembly on a flat, rigid surface.

Cam Lock Assembly



Confirmat Screw Assembly



Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- The installation and mounting conditions for the device are described in the «Assembly Instructions» section of this user manual.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 36 months

Service Life: 36 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: «MEBEL-KOMPLEKS» LLC.

3-A Komintern Street, Kstovo, Kstovsky District, Nizhny Novgorod Oblast, Russia.
Made in Russia.

This product meets the requirements of Technical Regulation of the Customs Union TR CU 025/2012 "On the Safety of Furniture Products".

Declaration of Conformity Number: EAЭС N RU Д-РУ.PA08.B.56850/23

Validity period: from 11.10.2023 to 10.10.2028.

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

The production date is indicated on the packaging.



aceline