Office Chair
Aceline CSO B

Intended Use

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The chair is designed to provide comfortable working conditions.

Safety Precautions

- If delivered during the cold season (at air temperatures below 0 °C), allow the product to acclimate to room temperature for 2 hours before assembly to avoid cracks in plastic and malfunctions in the gas cylinder.
- Chairs must be operated in a well-ventilated room at an air temperature of at least +10 °C and a relative humidity of 60–70%.
- Strictly follow the assembly sequence specified in the accompanying user manual.
- The maximum load on the seat must not exceed 120 kg.
- Avoid direct sunlight, placement near heating appliances, damp or cold walls to prevent deterioration of appearance and performance (stains, leather burning, wear of upholstery material).
- The fastenings of the chair components (backrest, armrests) require regular inspection. Tighten the screws if necessary.
- Do not stand on the seat of the chair, as this may cause it to tip over and result in injury.
- For cleaning, use a dry or slightly damp cotton cloth or sponge. When using cleaning agents, test them on a small inconspicuous area first to ensure they do not cause stains. Do not use organic solvents.
- Before first use, check the functionality of all mechanisms.
- When using the chair in close proximity to heating appliances, its surface must be protected from heat during operation. The temperature of the furniture components must not exceed +40 °C.
- Do not use the chair near open flames.
- During operation, avoid water or other liquids coming into contact with the floor-touching parts of the furniture.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- The installation and mounting conditions for the chair are described in the «Assembly» section of this user manual.
- The product must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The product must be transported in a dry place.
- The product requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the product must be carried out in accordance with local legislation.
- Upon expiration of the product's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If product damage is detected, immediately contact an authorized service center or dispose of the product.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 24 months.
Service Life: 36 months.

For the up-to-date list of authorized service centers, please visit:
https://www.dns-shop.ru/service-center/

Additional Information

Manufacturer: LLC «BUREAUCRAT».
Uglovaya Street, Property 2/1, Building 1, Chekhov, Moscow Oblast, 142305, Russia.



Made in Russia.

This product meets the requirements of Technical Regulation of the Customs Union TR CU 025/2012 «On the Safety of Furniture Products».

Declaration of Conformity Number: ЕАЭС N RU Д-RU.PA02.B.25571/23.
Validity period: From 07.03.2023 to 06.03.2028.


Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

The production date is indicated on the packaging. v.1

1  1 pc.	2  1 pc.	3  1 pc.	4  1 pc.	5  1 pc.	6  1 pc.
7  1 pc.	8 1 pc.	9  5 pcs	10  1 pc.	11  M6 x 25 mm bolt 4 pcs	12  M6 x 20 mm bolt 4 pcs
13  M6 flat washer 4 pcs	14  M6 spring washer 4 pcs	15 1 pc.	16  1 pc.	17  M6 x 30 mm bolt 2 pcs	


Note: Parts No. 15 and No. 16 are packaged with Part No. 6.

Step 1




Note: Step 1 – Remove the protective cap from the gas lift cylinder (if present).


Step 2





Assembly of Position No. 6



Step 3










Chair Adjustment



Specifications

- Model: CSO B.
- Trademark: Aceline.
- Weight limit: 120 kg.
- Upholstery material: Fabric.
- Filler material: Foam.
- Base material: Plastic.
- Chair height: 1000–1140 mm.
- Backrest height: 560 mm.
- Chair depth: 590–610 mm.
- Armrest height: 210 mm.
- Seat height: 440–580 mm.
- Seat width: 480 mm.
- Width with armrests: 575 mm.
- Seat depth: 375–395 mm.
- Base diameter: 560 mm.
- Tilt mechanism: Spring-screw backrest tilt mechanism.
- Weight: 8,45 kg.
- Scope of application: Domestic