

aceline

User Manual

Wired Keyboard
Tusk

Dear Customer,

Thank you for choosing our products.

We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The keyboard is an input device designed for typing text and issuing commands to the computer.

Safety Precautions

- Do not make any modifications to the device's design.
- To prevent short circuits, do not allow the device to come into contact with any liquids, and do not place open containers of liquid near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety. Do not allow children to play with the device.

Operating Instructions

1. Turn off your computer or laptop.
2. Connect the keyboard's USB cable to a USB port on your computer.
3. Turn on your computer. No driver is required — the keyboard will install automatically once connected.

Features

The keyboard has 19 keys with Anti-ghosting support (Q, A, Z, W, S, X, E, D, C, B, Space, ↑, ↓, ←, →, Tab, Alt, Ctrl, left Shift).

- FN + F1–F12 Shortcuts for Extended Functions:
 - FN + F1 — Launch the default media player.
 - FN + F2 — Increase volume.
 - FN + F3 — Decrease volume.
 - FN + F4 — Mute.
 - FN + F5 — Stop.
 - FN + F6 — Previous track.
 - FN + F7 — Play/pause.
 - FN + F8 — Next track.
 - FN + F9 — Launch email client.
 - FN + F10 — Open web browser.
 - FN + F11 — Lock keyboard.
 - FN + F12 — Calculator.
- Use FN + W to toggle between WASD and ↑↓←→ in games.
- FN + Win: Locks the Windows key.
- Change the backlight mode by pressing FN + .
- Turn the backlight on/off by pressing the .
- Adjust the backlight brightness using FN + Page Up/Page Down.

Specifications

- Model: Tusk.
- Trademark: Aceline.
- Power supply: 5 V = 300 mA.
- Backlight: Rainbow.
- Housing material: Plastic.
- Anti-ghosting keys.
- Key mechanism: Membrane.
- Total number of keys: 104.
- Numeric keypad: Yes.
- Connection: Wired.
- Cable length: 1.6 m.
- Dimensions (W × D × H): 458 × 184 × 36 mm.
- Weight: 665 g.
- Scope of application: Domestic.

Package Contents

- Device.
- User manual.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 12 months

Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: Huizhou Power 3 Electronical Technology Co., Ltd.

Changbu Village, Xinxu Town, Huiyang District, Huizhou City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1

