aceline

User Manual

Curling Iron
HC-2500S

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The curling iron is designed for curling and styling hair.

Safety Precautions

- Before connecting the device to the power supply, ensure that your home power supply voltage matches its technical specifications.
- Do not use the device near water. Do not use the device in the bathroom, shower, swimming pool, or other rooms with high humidity. Proximity to water poses a risk, even if the device is turned off.
- Disconnect the device from the power supply after use.
- This device is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety.
- Do not allow children to play with the device.
- Use the device only for its intended purpose specified in this manual.
- Do not leave the plugged-in device unattended.
- To avoid voiding the free warranty service, use only original accessories with the device.
- Do not wrap the power cord around the device.
- Allow the device to cool down before storing it.
- Exercise caution when using the device, as it can become very hot. Hold the device only by the handle and avoid contact with the skin.
- Always place the device on a heat-resistant, stable, flat surface. Hot heating plates must not come into contact with the surface or other flammable materials.
- Prevent the power cord from coming into contact with the hot parts of the device.
- Keep the turned-on device away from flammable objects and materials.
- Do not cover the device before it has cooled down (e.g., with a towel or clothing).
- Use the styling device only on dry hair. Do not handle the device with wet hands.
- The heating plates must be kept clean. Regularly clean them from dust. Do not use the device together with styling products.
- Do not use the device if a malfunction occurs or the cord is damaged.
- For device inspection or repair, contact only an authorized service center. Repair performed by an unqualified person may lead to extremely dangerous situations for the user.
- This device is not intended for commercial use.

Device Diagram



1. Clamping plate.
2. Power indicator.
3. «On/Off» switch.
4. Swivel cord.
5. Device housing.
6. Heating element.

Specifications

- Model: HC-2500S.
- Trademark: Aceline.
- Power: 35 W.
- Power supply: 220–240 V, 50 Hz.
- Coating: Ceramic-tourmaline.
- Heating element diameter: 25 mm.
- Maximum heating temperature: 200 °C.
- Power indication.
- Swivel cord.
- Hanging loop.
- Power cord length: 1.8 m.
- Protection class: II.
- IP code: IPX0.
- Cord type: Y.
- Scope of application: Domestic.

Package Contents

- Device.
- User manual.

Operating Instructions

Before curling, ensure that the hair is dry, clean, and free of any traces of mousse, hairspray, hair conditioner, etc.

1. Connect the device to the power supply.
2. Turn on the device by moving the switch to the corresponding position (the power indicator will light up).
3. Allow the device to heat up for five minutes.
4. Separate a strand of hair, place it between the heating plates, and twist it.
5. Hold the device for up to 20 seconds depending on the hair length and texture, as well as the desired curl style.
6. Lower the device below the curled section and repeat this procedure.
7. After curling, style only completely cooled hair.
8. After use, turn off the device and disconnect it from the power supply.

CAUTION!

- Do not touch the heating element during operation to avoid burns.
- Do not scratch the heating element with sharp objects.
- Do not wash the device, and do not use abrasive products or solvents. Wipe it with a dry cloth after use.
- After use, leave the device on a heat-resistant surface until it cools down completely.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 24 months
Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:
https://www.dns-shop.ru/service-center/

Additional Information

Manufacturer: YUYAO ELITE ELECTRICAL APPLIANCE CO., LTD.
NO.11, CHANGQING ROAD, FENGNAN VILLAGE, YANGMING STREET, YUYAO CITY, ZHEJIANG PROVINCE, P.R. CHINA.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1

aceline