

H6

GAMING HEADPHONES



Contents

Intended Use	3
Safety Precautions	3
Device Diagram	4
Connecting to Windows	5
Connecting to macOS	6
Operating Instructions	7
Specifications	9
Package Contents	9
Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal	9
Warranty Information	10
Additional Information	10

Wired Headphones

ARDOR GAMING H6

User Manual

Dear Customer,

Thank you for your trust!

Our team fully shares your passion for computer games, which is why we put all our efforts into making your gaming experience unforgettable with our accessories for gamers. Wishing you new victories and the brightest impressions ahead!


Intended Use

The headphones are a device for personal listening to music, speech, or other audio signals.

Safety Precautions

- This device is not intended for commercial use.
- This device is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety. Do not allow children to play with the device.
- Do not make any modifications to the device's design. This device contains no user-serviceable parts.
- To prevent short circuits, do not allow the device to come into contact with any liquids, and do not place open containers of liquid near it.
- To avoid hearing damage, use the headphones only at safe volume levels.
- Lower the volume before you start listening, then adjust it as needed.
- Wear the headset according to the «L» and «R» markings on the headband — «L» for the left ear, «R» for the right.
- When using headphones in noisy environments, there is a tendency to increase the volume. However, for safety, we recommend keeping the volume at a level that still allows you to hear ambient sounds.
- At excessively high volumes, sound may be audible to people around you. Adjust the volume so as not to disturb others.
- Do not drop or strike the headphones, as this may cause damage.
- Do not use harsh detergents or oils to clean the device. Wipe the headphones with a dry cloth.
- Store the headphones on a table or a dedicated stand.
- Protect the headphones from direct sunlight, heat sources, and dust.
- Do not use the headphones in areas with high temperature or humidity, and do not place them on an unstable, inclined, or heavily vibrating surface.

Device Diagram



1. Headband
2. Ear cushions
3. RGB backlight
4. Detachable microphone
5. Microphone indicator
6. USB cable
7. Equalizer mode switch
8. Surround sound on/off button
9. Volume control buttons
10. Microphone switch

Connecting to Windows

Setting Up the Headphones

1. Connect the headset to your computer using the USB cable.
2. Right-click the speaker icon in the bottom-right corner of the screen. Then select «Open Sound settings» — «Sound Control Panel» — «Playback».
3. Select the headphones as the default device. During audio playback, the bars next to the device name will turn green and start moving. If the bars do not change color or move after playing audio, increase the volume, or restart your computer and reconnect the headphones.
4. To adjust the headphone volume, right-click the speaker icon, then select «Open Sound settings». Move the overall volume slider to the desired position. You can also adjust the volume using the corresponding buttons on the device.

Setting Up the Microphone

1. After connecting the headset to your computer, right-click the speaker icon in the bottom-right corner of the screen. Then select «Open Sound settings» — «Sound Control Panel» — «Recording».
2. Select the headphones as the default device.
3. Say something into the microphone — the bars next to the device name will turn green and start moving. If the bars do not change color or move, restart your computer and reconnect the headphones, making sure the microphone is firmly inserted into the corresponding jack on the headset and that the microphone switch is set to «On».
4. To adjust the microphone volume, double-click the device name, then open the «Levels» tab and move the slider to the desired position.

Connecting to macOS

CAUTION! If your computer only has a USB-C port, you will need an adapter (not included) to connect the headset. Connect the adapter to the computer first, then connect the headset to the adapter.

Setting Up the Headphones

1. Connect the headset to your computer using the USB cable.
2. Go to «System Settings» — «Sound».
3. Open the «Output» tab and select the headset as the default audio output device.
4. Adjust the headphone volume by moving the slider to the desired position. You can also adjust the volume using the corresponding buttons on the device.

Setting Up the Microphone


1. Go to «System Settings» — «Sound».
2. Open the «Input» tab and select the headset as the default audio input device.
3. Say something into the microphone — the input level indicators should start moving. If the indicators do not move, try the following:
 - Restart your computer and reconnect the headphones.
 - Check that the microphone is fully inserted into the headset.
 - Make sure the headset's microphone switch is set to «On».
4. Adjust the microphone volume by moving the slider to the desired position.

Note


- If your computer fails to detect the headset, restart the computer and reconnect the headphones.
- If your computer detects the headset but no sound plays, check that the system volume and the in-app volume are turned on.
- For Windows 10: If your computer detects the headset but no sound plays, open «Windows Settings» — «Privacy» — «Microphone» and set the toggle under «Allow apps to access your microphone» to «On». Then restart your computer.
- If the backlight turns on after connecting the headset, this does not guarantee that sound will play through the headphones. Make sure you have selected the correct audio output device, unmuted the sound, and adjusted the volume.

Operating Instructions


1. Connect the headphones to your computer (see the previous section).
2. Adjust the headband.
3. If needed, attach the microphone, making sure the arrow on the sticker aligns with the arrow on the headset.



4. Position the microphone about 2–3 cm below your mouth, at a 30–45 degree angle — this helps avoid picking up excess background noise.



5. To turn the microphone on/off, set the corresponding switch to «On» / «Off». A red indicator means the microphone is off.




6. To enable surround sound mode for a more immersive listening experience, press the corresponding button — it will light up. Press it again to exit this mode.



7. To select your preferred sound profile, press the equalizer mode switch:

- «Movie» mode (balanced sound effects).
- «Gaming» mode (emphasis on deep bass).
- «Music» mode (emphasis on high frequencies).



Specifications

- Model: H6 Black
- Trademark: ARDOR GAMING
- Frequency range: 20–20,000 Hz
- Sensitivity: 110 dB
- Impedance: 32 Ω
- Cable length: 2.3 m
- Ear cushion diameter: 80 mm
- Driver diameter: 50 mm
- Power supply: 5 V – 1 A

Package Contents

- Device
- User manual

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 24 months

Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: Zhaoqing Hejia Electronics Co., Ltd.

1st Floor, Huaxing woolen building, Waijing Industrial Village, No.6 Duanzhou 3rd Road, Zhaoqing, Guangdong Province, China

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1





LEARN MORE:

ARDOR-GAMING.COM
[VK.COM/ARDOR_GAMING](https://vk.com/ARDOR_GAMING)

