

User Manual

Hair Dryer
DHD-210

DEXP

Dear Customer,

Thank you for choosing our products.

We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The hair dryer is designed for drying and styling hair at home.

Safety Precautions

- Before plug in, make sure that the voltage of your home power source corresponds to the devices specifications. Plug the device only into a grounded outlet.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.
- Do not use the device near sources of water or other liquids. Never place the device under running water or immerse it in water. Do not touch the device with wet hands.
- Do not use the device outdoors.
- Do not use the device near flammable gases, liquids, or materials. Do not use aerosol sprays while operating the device.
- Never leave the device unattended while in use.
- Immediately disconnect the device from the power supply in the event of a malfunction. Do not turn on the device if there is visible damage, or if the power cord or plug is damaged.
- Do not disassemble the device yourself to avoid electric shock. This device contains no user-serviceable parts. Maintenance and repairs should only be performed by qualified technicians at an authorized service center.
- Do not pull or move the device by the cord. Do not bend or wrap the cord around the device. Also ensure the power cord does not bend over the edge of the countertop or come into contact with hot surfaces or sharp edges.
- Use only the accessories supplied with the device.
- Place the device only on heat-resistant, stable, and flat surfaces. Ensure that the hot parts do not come into contact with any flammable materials.
- Be cautious when handling the device, as some parts may become extremely hot during operation. Hold the device only by the handle and avoid contact of hot parts with skin.
- Never cover the device (e.g., with a towel or clothing) while it is still hot.
- Always disconnect the device from the power source before cleaning or during an extended period of non-use.
- Never insert foreign objects into the air inlet or outlet vents. Clean them regularly to prevent clogging.
- Ensure that hair does not enter the air inlet vents.

- This device is not intended for commercial use.


Specifications

- Model: DHD-210.
- Trademark: DEXP.
- Power supply: 220–240 V ~ 50–60 Hz.
- Power: 1800 W.
- Power cord length: 2.1 m.
- Number of speed settings: 2.
- Number of temperature settings: 2.
- Overheat protection: Yes.
- Ionization: Ion generator.
- Protection class: II.
- Cord type: Y.
- IP code: IPX0.
- Scope of application: Domestic.

Package Contents

- Hair dryer
- Concentrator nozzle.
- User manual.

Device Diagram



1. Housing.
2. Concentrator nozzle.
3. Cold air button.
4. Power/temperature mode switch.
5. Air intake grille.
6. Handle.
7. Power cord.

Operating Instructions

1. Before use, ensure your hands are completely dry.
2. Plug the hair dryer into a power outlet and set the power/temperature switch to the desired position:
 - I — Warm air.
 - II — Hot air.
3. If gentle drying and styling are required, turn on the cold air function using the corresponding button.
4. After use, set the power/temperature switch to the off position and unplug the device from the power outlet.

Cleaning and Maintenance

- Always unplug the device from the power outlet before cleaning and ensure it has cooled down.
- Wipe the device housing with a soft, slightly damp cloth, then wipe it with a dry cloth.
- Regularly remove dust and debris from the ventilation openings using a soft brush (not included).

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 24 months

Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: Yueli Group Co., Ltd.

No.999 Kaifa East Road, Zhouxiang Town, Cixi City, Ningbo City, Zhejiang Province, P.R.China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.



Production date (mm.yyyy): _____ V.1

