

User Manual

Wireless Charging Device
IET15WWC-3

DEXP

Contents

Intended Use.....	3
Safety Precautions	3
Specification	5
Package Contents.....	5
Device Diagram	6
Operating Instructions.....	7
Charging.....	7
Charging Indication.....	7
Display Control	7
Clock Setting	8
Alarm Setting.....	8
Alarm Control.....	9
Night Light	9
Troubleshooting Guide.....	9
Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal	11
Additional Information	12

Dear Customer,

Thank you for choosing our products.

We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The device is designed for wireless charging of mobile devices from an AC power source.

Safety Precautions

- Make sure the devices you are charging support wireless charging and are compatible with this charger.
- Do not place any objects between the phone and the charging surface, or inside the case in the charging area (e.g., metal objects, magnets, bank/access cards, etc.), as they may block wireless charging.
- Do not use the device near sources of water or other liquids. Never place the device under running water or immerse it in water.
- Do not use the device near heat sources or expose it to direct sunlight.
- Keep a distance of at least 20 cm between the charger and implanted medical devices (e.g., pacemakers) to avoid possible interference.
- Before cleaning the device, make sure it is disconnected from the power supply. Wipe the device with a soft, dry cloth.
- Protect the device from impacts, drops, vibrations, and other mechanical stress.

- Use the power adapter only within the specified output parameters. Using an adapter with incorrect specifications may cause the device to malfunction or become damaged.
- Do not disassemble the device yourself to avoid electric shock. This device contains no user-serviceable parts. Maintenance and repairs should only be performed by qualified technicians at an authorized service center.
- This device is not intended for commercial use.
- Do not use the device if it is damaged, or if the cable or connector is damaged.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.
- If overheating occurs during charging, charging may stop. In this case, remove the device from the charger, allow it to cool down, and then try again.

Specification


- Model: IET15WWC-3.
- Trademark: DEXP.
- Power supply (input):
 - $9\text{ V} = 2\text{ A}$;
 - $12\text{ V} = 1.5\text{ A}$.
- Power supply (output):
 - $5\text{ V} = 1\text{ A}$;
 - $7.5\text{ V} = 1\text{ A}$;
 - $9\text{ V} = 1.12\text{ A}$;
 - $9\text{ V} = 1.66\text{ A}$.
- USB Type-A power input: $5\text{ B} = 1,5\text{ A}$.
- Output power:
 - Phone charging area: 5 W ; 7.5 W ; 10 W ; 15 W
 - Headphones/phone charging area: 5 W
 - Apple Watch charging area: 2.5 W
- Battery type: CR2032.
- Power connector type: USB Type-C.
- Compatibility: smartphones and earbuds with wireless charging function, Apple Watch.
- IP code: IPX0.
- Wireless charging standard: Qi.
- LCD clock.
- Scope of application: Domestic.

Note: Apple, iPad, iPad Air, iPad Pro, iPod touch, iPhone, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.

Package Contents

- Charging device.
- USB Type-C cable.
- User manual.

Device Diagram



1. Phone charging area.
2. Apple Watch charging area.
3. USB Type-C power input and USB Type-A charging connector.
4. Display.
5. LED indicator.
6. Phone/headphone charging area.
7. Power button / night light brightness control.
8. Night light.
9. Power button / display brightness control.
10. Clock/alarm setting button.
11. Time decrease button.
12. Time increase button.
13. LED indicator on/off button.

Operating Instructions

Charging

1. Connect the charger to the power supply using a power adapter (not included) and the USB Type-C cable. The indicator light will flash once and then turn off — the device will enter standby mode.
2. Place the device you want to charge on the appropriate charging area and make sure it is positioned evenly — charging will start automatically.

CAUTION: For stable charging, place the device in the center of the charging area.

3. After charging is complete, remove the device from the charging area.

Charging Indication

- During phone charging on the phone charging area, the indicator light will glow. When charging a watch and wireless earbuds, as well as when charging a phone on the phone/earbuds charging area, the indicator light does not glow.
- If necessary, the indicator can be turned off using the « ✱ » button.

Display Control

- After connecting the device to power, the display is on by default.
- If necessary, the display brightness can be adjusted, or the display can be turned off completely, by pressing the «ON/OFF» button. To turn the display back on, press this button again.

CAUTION: When the display is turned off, the set alarm is also disabled.

Clock Setting

After connecting to power, the device defaults to displaying the current time, and the « ⌚ » indicator lights up.

Note: The display shows time only in 12-hour format.

To set the current time:

1. Press and hold the «M» button for 3 seconds — the indicator « ⌚ » and the hour value will start flashing.
2. Set the current hour using the « Δ » and « ▽ » buttons.
3. Press the «M» — the minute value will start flashing. Set the current minutes using the « Δ » and « ▽ » buttons.
4. To save the settings, press the «M» button.

Note: The device is equipped with a CR2032 battery, which is used to save time settings when external power is disconnected. The battery compartment is located on the bottom of the device.

Alarm Setting

To set the alarm time:

1. Press and hold the «M» button for 1 second — the indicator « ⌚ » and the hour value will start flashing.
2. Set the alarm hour using the « Δ » and « ▽ » buttons.
3. Press the «M» — button — the minute value will start flashing. Set the minutes using the « Δ » and « ▽ » buttons.
4. To save the settings, press the «M» button. After setting, the alarm will sound at the set time daily.

Alarm Control

- After setting the alarm time, press and hold the «  » button for 3 seconds to turn the alarm on, and the «  » button to turn it off.
- When the alarm is on, the indicator «  » appears on the display; when it is off, the indicator turns off.
- When the alarm sounds, the signal lasts for 5 minutes and then turns off automatically. To turn off the signal manually, press any button.

Night Light

The device is equipped with a night light function. To turn it on/off and adjust brightness, press the «  » button.

Troubleshooting Guide

Issue	Possible cause	Solution
The device does not charge	The device is not positioned correctly on the charging area	Place the device evenly in the center of the charging area
	The device does not support wireless charging	Make sure the device you are charging supports wireless charging
The indicator is on, but the phone is not charging	The phone's wireless charging module is faulty	Contact an authorized service center for phone diagnostics

Issue	Possible cause	Solution
The device heats up during charging	During wireless charging, the charger and the device being charged may warm up slightly due to the nature of power transfer	Slight warming is normal. If overheating occurs, remove the device from the charger and allow it to cool down
Charging is interrupted or unstable	The power adapter is insufficient or the power supply is unstable	Use a power adapter that supports fast charging
	The device is not positioned correctly on the charging area	Place the device evenly in the center of the charging area

Note: If the issue persists after following the above recommendations, contact an authorized service center.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- Upon expiration of the service life of batteries supplied with the device, do not dispose of them with other household waste. Batteries must be disposed of in accordance with local waste recycling regulations to prevent potential environmental harm resulting from uncontrolled waste disposal.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 12 months / **Service Life:** 12 months

For the up-to-date list of authorized service centers, please visit: <https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer:

Dongguan Tuozecheng Electronic Technology Co., Ltd.
Room 203, Building 2, No. 11, Gaobu Zhenxing North Road,
Gaobu Town, Dongguan City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.



Production date (mm.yyyy): _____ v.1

