# User Manual

## Wired Keyboard
## Omni

DEXP

## Dear Customer,

Thank you for choosing our products.
We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

### Intended Use

The keyboard is an input device designed for typing text and issuing commands to the computer.

### Safety Precautions

- Do not make any modifications to the device's design.
- To avoid a short circuit, do not expose the device to any liquids, and do not place open containers of liquid near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.

### Specifications

- Model: Omni White, Omni Black.
- Trademark: DEXP.
- Power supply: 5 V ⎓ 300 mA.
- Base material: ABS-plastic.
- RGB backlighting, 18 backlight modes.
- Total number of keys: 97.
- Anti-Ghosting technology.
- Switches: RUBY.
- Connection interface: USB.
- Gasket mount: Yes.
- Switch lifespan: Up to 50 million keystrokes.
- Cable length: 1.8 m.
- Keyboard dimensions: 391 × 141 × 42 mm.
- Weight: 730 ± 5 g.
- Compatibility: Windows.
- Scope of application: Domestic.
- Package contents: keyboard, USB cable, user manual, keycap puller, blister pack with keycaps.

## Operating Instructions

1. Connect the device to a USB connector on your computer using the cable.
2. Wait for the hardware installation wizard to complete on your computer.
3. The device is ready for use.

## Key Combinations

| | |
|---|---|
| FN+F1 | Music |
| FN+F2 | Decrease volume |
| FN+F3 | Increase volume |
| FN+F4 | Mute / Unmute |
| FN+F5 | Stop playback |
| FN+F6 | Previous track |
| FN+F7 | Play / Pause |
| FN+F8 | Next track |
| FN+F9 | Email |
| FN+F10 | Home page |
| FN+F11 | This PC |
| FN+12 | Calculator |
| FN+↑ | Increase backlight brightness |
| FN+↓ | Decrease backlight brightness |
| FN+← | Decrease backlight speed |
| FN+→ | Increase backlight speed |
| FN+ ⊞ | Lock Windows key |
| FN+\ | Change backlight mode (18 modes) |
| FN+Enter | Change backlight color |
| FN+X | Turn backlight on / off |
| FN+W | Swap arrow keys with WASD |
| FN+ESC | Reset to factory settings |
| FN+~ | Set custom backlight mode |
| FN+1 | Custom backlight mode 1 |
| FN+2 | Custom backlight mode 2 |
| FN+3 | Custom backlight mode 3 |
| FN+PU | HOME |
| FN+PD | END |
| FN+DEL | SCrLc |
| Volume control | Turn left — decrease volume;<br>turn right — increase volume;<br>press — mute / unmute |

## Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

## Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

**Warranty Period:** 12 months
**Service Life:** 24 months

**For the up-to-date list of authorized service centers, please visit:** https://www.dns-shop.ru/service-center/

## Additional Information

**Manufacturer:** SHENZHEN YUANYICHANG TECHNOLOGY CO., LTD.
Building B, No.60, Zhuang Village Road, Xiner Industrial Park, Xinqiao Street, Bao'an District, Shenzhen City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1

