Scales SC-905, SC-992

User Manual

Dear Customer,

Thank you for choosing our products.
We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.


Intended Use

The scales are designed for measuring human body weight in domestic conditions.

Safety Precautions

- Protect the device from any liquids, extremely high and low temperatures, and direct sunlight.
- If the device malfunctions, try replacing the battery. If the problem persists, contact an authorized service center. Do not attempt to disassemble or repair the device yourself.
- Step onto the scales smoothly, without leaning forward, backward, or to the sides.
- Distribute your weight evenly; do not lean on one leg.
- Never jump while standing on the scales.
- Step onto the scales only with bare, dry feet. Otherwise, the readings will be inaccurate, and you may slip.
- Clean the device with a slightly damp cloth. Do not use gasoline or other harsh chemicals to clean the device.
- Remove the batteries from the scales if they will not be used for an extended period.

Device Diagram



1. Display.
2. Unit selection button.
3. Battery compartment.

Operating Instructions

1. Install 3 AAA batteries into the battery compartment on the back of the device.
2. Press the button on the back of the device to select the desired unit of measurement: kilograms or pounds.
3. Place the scales on a flat, hard surface.
4. Turn on the scales by gently tapping the platform with your foot.
5. The screen will light up, and after a few seconds, the value «0.0» will appear.
6. Step onto the scales. Stand in the center of the platform for accurate readings. Within a few seconds, you will see your weight on the screen.
7. The scales will automatically turn off 10 seconds after you step off.

System Message Codes

- «Lo»: The battery is low. It is recommended to replace the batteries with new ones.
- «Err»: The scales are overloaded. Remove the weight immediately to prevent device damage.

Specifications

Model	SC-905	SC-992
Trademark	DEXP	
Device dimensions	300 × 300 × 21 mm	280 × 280 × 21 mm
Screen size	72 × 25.2 mm	
Glass thickness	5 mm	
Platform material	Tempered glass	
Maximum load	180 kg	
Accuracy	100 g	
Battery type	3 × AAA	
Auto shut-off	After 10 seconds	
Scope of application	Domestic	
Overload indication		
Low battery indication		
Rubber feet		

Package Contents

- Scales.
- AAA batteries (3 pcs).
- User manual.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- Upon expiration of the service life of batteries supplied with the device, do not dispose of them with other household waste. Batteries must be disposed of in accordance with local waste recycling regulations to prevent potential environmental harm resulting from uncontrolled waste disposal.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 36 months
Service Life: 36 months

For the up-to-date list of authorized service centers, please visit:
https://www.dns-shop.ru/service-center/

Additional Information

Manufacturer: Ningbo Putian Information Industry Co., Ltd.
Industrial Development Zone, Ditan, Yuyao, Ningbo City, Zhejiang Province, China.

Made in China.

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.



Production date (mm.yyyy):_____v.1