

Wired Keyboard Wind User Manual

DEXP

Dear Customer,

Thank you for choosing our products.

We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

The keyboard is an input device designed for typing text and issuing commands to the computer.

Safety Precautions

- Do not make any modifications to the device's design.
- To avoid a short circuit, do not expose the device to any liquids, and do not place open containers of liquid near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.

Specifications

- Model: Wind.
- Trademark: DEXP.
- Power supply: 5 V = 1 A.
- Operating current: ≤ 200 mA.
- IP code: IPX0.
- Keyboard type: Wired.
- Material: ABS plastic.
- Total number of keys: 108.
- Key backlight: RGB.
- Cable length: 1.8 m.
- Compatibility: Windows.
- Dimensions: 441 × 144 × 40 mm.
- Weight: 687 g ± 10 g.
- Scope of application: Domestic.
- Package contents: Keyboard, USB-C – USB-A cable, user manual.

Operating Instructions

Getting Started

- Connect the device to a USB connector on your computer using the cable.
- Wait for the hardware installation wizard to complete on your computer.
- The device is ready for use.

Key Combinations

Fn + F1	Media
Fn + F2	Decrease volume
Fn + F3	Increase volume
Fn + F4	Mute/Unmute
Fn + F5	Previous track
Fn + F6	Next track
Fn + F7	Play/Pause
Fn + F8	Stop playback
Fn + F9	Home
Fn + F10	Mail
Fn + F11	My Computer
Fn + F12	Favorites
Fn + Win	Lock Windows key
Fn + W	Switch arrow keys and WASD functions
Fn + INS/HOME/PGUP/DEL/END	Switch backlight modes
Fn + PGDN	Turn backlight on/off
Fn + ↑	Increase backlight brightness
Fn + ↓	Decrease backlight brightness

Fn + ←	Decrease backlight speed
Fn + →	Increase backlight speed

Keys with Anti-Ghosting Technology

Tab, Q, W, E, R, T, Capslock, A, S, D, F, G, Shift-L, Z, X, C, V, B, M, Ctrl-L, Alt-L, Space, ↑ (Up), ↓ (Down), ← (Left), → (Right).

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 12 months

Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: SHENZHEN YUANYICHANG TECHNOLOGY CO., LTD.

Building B, No.60, Zhuang Village Road, Xiner Industrial Park, Xinqiao Street, Bao'an District, Shenzhen City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

