

 Keychron

Q3 HE 8K Magnetic Switch Keyboard 

Fully Assembled Version

Keyboard

1x Fully Assembled Keyboard

Including

1x Aluminum Case

1x PCB

1x Aluminum Plate

1x Sound Absorbing Foam

1x Latex Bottom Pad


1x Bottom Case Acoustic Foam

16x Gaskets (12 Installed and 4 in the Box)

5 sets x Stabilizers

1 set x Keycaps (PBT Double-shot)

1 set x Magnetic Switches



Cable

1x Type-C Cable


1x Type-A to Type-C Adapter

Tools

1x Keycap & Switch Puller

1x Screwdriver


1x Hex Key



Quick Start Guide


If you are a Windows user, please find the appropriate keycaps in the box, then follow the instructions below to find and replace the following keycaps.

Mac / Windows




1 Switch To The Right System

Please make sure the system toggle on the top left corner has been switched to the same system as your computer's operating system.




2 The Backlight

Press **fn + Q** to change the lighting effect




Press **fn + tab** to turn the backlight on/off




3 Adjust The Backlight Brightness

Press fn + W to increase the backlight brightness




Press fn + S to decrease the backlight brightness




4 Adjust The Backlight Speed

Press fn + T to increase the light effect speed



Press fn + G to decrease the light effect speed



5 The Keychron Launcher App


Please visit launcher.keychron.com to access the Keychron online launcher app. This app enables users to remap keys, adjust key actuation points, assign multiple commands to a single key, enter game controller mode, and more. If it cannot recognize your keyboard, please reach our support to get instruction.




*The online launcher app can only run on the latest version of Chrome, Edge, and Opera browsers yet.

6 The Layers

There are four layers of key settings on the keyboard. The layer 0 and layer 1 are for the Mac system. The layer 2 and layer 3 are for the Windows system.




If your system toggle is switched to Mac, then the layer 0 will be activated.



If your system toggle is switched to Windows, then the layer 2 will be activated. Remember that if you are using it in Windows mode, please make changes to the layer 2 instead of the top layer (the layer 0). This is a common mistake people are making.



7 Factory Reset & Firmware Update



Troubleshooting? Don't know what's going on with the keyboard?

Factory reset your keyboard

1. Power on your keyboard.
2. Press and hold fn + J + Z (for 3 seconds). The keyboard backlight will flash in red quickly for 3 seconds, indicating that the keyboard has been reset.

Flash your keyboard firmware

1. Visit launcher.keychron.com to open the online Launcher web app.
 2. Plug in the power cable.
 3. Find the 'Firmware Update' tab on the left side of the Launcher and connect your keyboard with it.
 4. Follow the instructions on the Launcher and complete the firmware update.
- *Step-by-step guide, search the keyword "firmware" on keychron.com.

8 Warranty




The keyboard is highly customizable and easy to be rebuilt. If anything goes wrong with any of the keyboard components of keyboard during the warranty period, we will only replace the defective parts of the keyboard, not the whole keyboard.



Q3 HE 8K MAGNETIC SWITCH KEYBOARD SPECIFICATIONS

Specifications	
Layout	TKL
Switch type	Magnetic
Width	137 mm
Length	365.17 mm
Back height	31.30 mm (without keycaps) 44.93 mm (with keycaps installed)
Front height	20.60 mm (without keycaps) 30.22 mm (with keycaps installed)
Keyboard feet height	1.24 mm
Angle	5.26 degree


Q3 HE 8K MAGNETIC SWITCH KEYBOARD OVERVIEW




- ① Knob
- ② Caps Lock Indicator
- ③ Three-Position Switch
- ④ Win Mac (OS Toggle)
- ⑤ Type-C Port

DEFAULT KEY LAYOUT:

LAYER 0: This layer will be activated when your keyboard's system toggle is switched to Mac.




LAYER 2: This layer will be activated when your keyboard's system toggle is switched to Windows.



LWin = Left Windows LAlt = Left Alt RWin = Right Windows RAlt = Right Alt RCl = Right Ctrl

LAYER 3: This layer will be activated when your keyboard's system toggle is switched to Windows and press the fn/MO(3) key.



KEY DESCRIPTION

Key Description		Key Description		Key Description	
Scr-	Screen Brightness Decrease	RGBMd-	RGB Mode Previous	MCTl	Mission Control
Scr+	Screen Brightness Increase	Hue+	Hue Increase		
Bright-	Backlight Decrease	Hue-	Hue Decrease		
Bright+	Backlight Increase	RGB SPI	RGB Speed Increase		
Prvs	Previous	RGB SPD	RGB Speed Decrease		
Play	Play/Pause	MO(1)	Layer 1 will be activated when holding this key		
Next	Next	MO(3)	Layer 3 will be activated when holding this key		
Mute	Mute	Sat+	Saturation Increase		
Vol-	Volume Decrease	Sat-	Saturation Decrease		
Vol+	Volume Increase	NKRO	N-key rollover		
RGB Toggle	Turn Backlight on/off	File	File Explorer		
RGBMd+	RGB Mode Next	LPad	LaunchPad		

LED STATUS OVERVIEW

LED Location	Function	Status
Caps Lock Indicator	Caps Lock	Enable Caps Lock - Static White Disable Caps Lock - Light Off

BACKLIGHT SETTING

Short press key combination "fn" + "tab" or "fn" + "knob (press)" to turn the backlight on/off.

Short press key combination "fn" + "Q" / "fn" + "A" to switch between different types of lighting effects.

3-POSITION PROFILE SWITCH / 3-POSITION POLLING RATE SWITCH DEFAULT FUNCTION

The 3-position switch is used to switch between profiles (Profile 1/ Profile 2/Profile 3).

Profile switching is only available via the physical toggle switch. The Launcher software allows editing settings within a profile but does not support switching between profiles.

CUSTOMIZABLE OPTION

The toggle switch can be reprogrammed via the Launcher software to control either Profiles (Profile 1/2/3) or Polling Rate (1K/2K/8K). The keyboard's default polling rate is 8K. If configured for polling rate, each switch position can be customized individually in the Launcher (supports: 0.125K, 0.25K, 0.5K, 1K, 2K, 2K, 8K).

*Custom configurations are retained after power-off.

FACTORY RESET

The switch defaults back to Profile mode (Profile 1 / Profile 2 / Profile 3), and polling rate resets to 8K.

OS TOGGLE

1 – MAC/iOS

Switch the toggle to Mac/iOS when the keyboard is connected to a Mac or iOS operating system.

2 – WINDOWS/ANDROID

Switch the toggle to Windows/Android when the keyboard is connected to a Windows or Android operating system.

**When using the Windows/Android mode,   keys are used for "Windows" and "Alt" functions.*

Third-party input tools are not compatible with the keyboard.

Due to compatibility, versions, brands and drivers of Windows/Android OS, functions of third-party input tools may be affected while using the keyboard. Please make sure your operating system and drivers are up to date.

Certain multimedia keys or function keys do not work.

Functions of certain multimedia keys may be disabled due to compatibility, versions, brands, and drivers of devices.

*Multimedia keys: 

Function keys: 

Safety Precaution:

Keep the product, accessories and packaging parts out of the reach of children to prevent any accidents and choking hazards.

Always keep the product dry to avoid corrosion.

Do not expose the product to extreme temperatures below -10°C(14°F) or above 50°C(122°F) to preserve the lifespan of the keyboard.

Keychron, Inc.

Dover, DE 19901, United States

Find us at:

<https://www.keychron.com>

support@keychron.com

 @keychron

 @keychron

 @keychronMK

Designed by Keychron

Made in China

 Keychron

Q3 HE 8K 磁轴键盘 旋钮版本

完全组装版本

键盘

1x 已组装成品键盘

包盒

1x 铝合金金属外壳

1x PCB

1x 铝定位板

1x PCB与定位板夹心吸音泡棉

1x 乳胶底垫


1x 底壳吸音泡棉

16x Gaskets缓冲垫(12个缓冲垫已安装在键盘本体、4个放置在包装内部)

5套PCB卫星轴

1套键帽(PBT材质-双色注塑)

1套磁轴



线材

1x Type-C 接口线材


1x Type-A to Type-C 转接头

工具

1x 拔轴键器

1x 十字螺丝刀


1x 内六角螺丝刀



快速上手指南


如果你是Windows用户,请在包装盒里找到如下的键帽,用拔键器拔下键盘上的对应键帽并且更换。

Mac / Windows




1 系统切换

请确保键盘左上角的系统拨片切换到对应系统，
如果没有选择正确，
部分功能将无法使用。




2 更改键盘背光模式以及快速关闭/开启键盘背光

组合fn+Q键，更改键盘背光模式。




组合fn+tab键，可快速关闭/开启键盘背光。




3 调整键盘背光亮度

组合fn+W键,提高键盘背光亮度。




组合fn+S键,减少键盘背光亮度。




4 调整背光速度

组合fn+T键,增加光效速度。



组合fn+G键,降低光效速度。



5 关于Keychron Launcher App


请访问launcher.keychron.com 使用在线Launcher app。
该软件可以映射按键, 调节按键触发点, 设置一键多重命令,
体验游戏手柄模式等功能。
如果Launcher app不能识别你的键盘,
请联系我们以获得技术支持。



*在线Launcher app只能在最新版本的Chrome, Edge和Opera浏览器中运行。

6 关于键盘键层说明

键盘有四层按键设置。
层0和层1是用于Mac系统。
层2和层3是用于Windows系统。




如果您的系统拨片切换到Mac档位,
层0将被激活。



如果您的系统拨片切换到Windows,
那么层2将被激活。
如果您在Windows系统模式下使用,
请对层2进行更改, 而不是层0。
否则无法进行按键映射操作。



7 恢复出厂模式&更新固件



如果键盘出现了故障, 不知道怎么办?

恢复出厂设置

1. 打开键盘。
2. 按住 fn + J + Z (持续 3 秒)。键盘背光灯会呈红色快速闪烁 3 秒, 表示键盘已重置。

刷新键盘固件

1. 访问 launcher.keychron.com 打开在线 Launcher web app。
 2. 确保键盘处于Cable或者有线模式, 并插入电源线。
 3. 在Launcher上找到“固件更新”选项, 并将键盘与其连接。
 4. 按照Launcher提示, 完成固件更新。
- *在 keychron.com 上搜索关键字“Firmware”可以找到步骤指南。

8 保修




由于Q3 HE 8K 客制化键盘是可高度定制且易于组装的, 所以键盘的任何一个部件出了问题, 我们只会更换键盘有问题的部件而不是整个键盘。



Q3 HE 8K 键盘规格


规格	
布局	TKL
开关类型	磁轴
宽度	137 mm
长度	365.17 mm
键盘上沿高度	31.30 mm (不含键帽) 44.93 mm (含键帽高度)
键盘下沿高度	20.60 mm (不含键帽) 30.22 mm (含键帽高度)
键盘脚垫高度	1.24 mm
键盘倾斜角度	5.26°

Q3 HE 8K 键盘概述




- ① 旋钮
- ② 大小写指示灯
- ③ 三段拨动开关
- ④ Win Mac (系统切换开关)
- ⑤ Type-C 接口

层2:当您的系统拨片切到Windows档位的时候,层2将被激活使用。



LWin = Left Windows LAlt = Left Alt RWin = Right Windows RAlt = Right Alt RCtrl = Right Ctrl

层3:当您的系统拨片切到Windows档位并组合fn/MO(3)键的时候,层3将被激活使用。



Q3 HE 8K客制化磁轴键盘多媒体按键说明

按键说明		按键说明		按键说明	
Scr-	屏幕亮度-	RGBMD-	上一个RGB灯光模式	MCtl	调度中心
Scr+	屏幕亮度+	Hue+	下一个灯光颜色		
Bright-	键盘背光亮度-	Hue-	上一个灯光颜色		
Bright+	键盘背光亮度+	RGB SPI	RGB灯光速度+		
Prvs	上一曲	RGB SPD	RGB灯光速度-		
Play	播放/暂停	MO(1)	按住MO(1),层1将被激活		
Next	下一曲	MO(3)	按住MO(3),层3将被激活		
Mute	静音	Sat+	饱和度+		
Vol-	音量-	Sat-	饱和度-		
Vol+	音量+	NKRO	全键无冲		
RGB Toggle	关闭/开启键盘背光	File	文件管理器		
RGBMD+	下一个RGB灯光模式	LPad	启动台		

LED状态显示如下

LED位置	功能	状态
大小写指示灯	大小写	白灯—大写 熄灭—小写

背光灯

- 短按组合键“fn+tab”或“fn+旋钮(按压)”可关闭/开启键盘背光。
- 短按组合键“fn+Q”/“fn+A”可切换背光效果。

三段配置层切换开关/三段回报率切换开关

默认功能

三段开关默认用于在不同配置层之间切换(配置层1/配置层2/配置层3)。
配置层切换只能通过三段开关进行, Launcher软件支持编辑配置层参数,但不支持切换不同配置层。

可自定义功能

通过Launcher软件可将三段开关定义为配置层切换开关(配置层1/2/3)或回报率切换开关(1K/2K/8K)。键盘默认回报率为8K。

如果设置为三段回报率切换开关,每个开关位置的回报率值可在Launcher软件中单独自定义(支持0.125K、0.25K、0.5K、1K、2K、4K、8K)。

*自定义设置可在断电后保留。

恢复出厂设置

三段开关恢复为配置层切换开关(配置1/配置2/配置3),键盘回报率恢复为8K。

系统切换

1 — MacOS / iOS

连接到Mac或iOS操作系统时,请将键盘上方系统开关拨至Mac/iOS。

2 — WINDOWS / 安卓

当键盘连接到 Windows 或 Android 操作系统时,请将键盘上方系统开关拨至Win/Android。


注:由于Windows/安卓OS的兼容性、版本、品牌和驱动程序,某些多媒体键的功能可能不能被使用。我们还建议不要频繁切换操作系统,因为它可能会影响键盘的操作。

第三方输入工具与键盘不兼容

答：由于Windows / Android 系统的兼容性、版本、品牌和驱动程序，第三方输入工具在使用键盘时或被影响。请确保你的作业系统和驱动程序为最新版本。

某些多媒体键或功能键在设备上不起作用。

答：由于设备的兼容性，系统版本，驱动程序等原因，某些多媒体键或者功能键可能无法使用。

*多媒体键：

功能键：

安全预防措施：

防止儿童接触到产品、附件和包装部件，以防止任何意外和窒息的危险。

保持产品干燥，避免腐蚀。

不要将产品暴露在低于-10°C (14°F) 或高于50°C (122°F) 的极端温度下，以保持键盘的寿命。

Keychron, Inc.

Dover, DE 19901, United States

<https://www.keychron.com>

通过以下方式与我们联系

Support@keychron.com

 @keychron

 @keychron

 @keychronMK

Keychron设计

中国制造

中国区总代：渴创技术（深圳）有限公司

执行标准：GB/T 14081-2010

售后热线：400-0766268

地 址：深圳市龙岗区坂田街道大发埔社区
大发路24号文坑工业区2栋201

