



MCHOSE



— Jet 75 User Manual —
Hall Effect Magnetic Switch Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.



Web Driver: www.mchose.io
Note: Open the URL in a browser, click on **【Initialize Device】** > **【Allow Browser Access】**, and then select the corresponding product model to connect.

• FN KEY COMBINATIONS

Fn +	O	P	Esc	A	S
	Windows System	Mac System	Hold down 3S to restore factory defaults	Backlight brightness +	Backlight brightness -
	D	F	G	Z	X
	Backlight Mode Switch	Backlight Color Switch	Backlight Speed Cycle Adjustment	LOGO Light Brightness +	LOGO Light Brightness -
	C	V	B	Delete	Home
	LOGO Light Mode Switch	LOGO Light Color Switch	LOGO Light Speed Switch	Ins	End

• FN KEY COMBINATIONS

Key Button	F1	F2	F3	F4	F5	F6
Single Press	F1	F2	F3	F4	F5	F6
Fn Combination	Screen Brightness -	Screen Brightness +	/	/	/	/

Key Button	F7	F8	F9	F10	F11	F12
Single Press	F7	F8	F9	F10	F11	F12
Fn Combination	Previous Song	Play/Pause	Next Song	Mute	Volume -	Volume +

* Supports Windows generic keyboard functions; compatible with MacOS standard key functions, but special function keys are not supported.

WARRANTY CARD


Thank you for purchasing our product. Please contact us if there are any quality issues within the warranty period. Please provide this warranty card so we can provide comprehensive after-sales service.

Product Items: _____ Customer Name: _____

Serial NO. : _____ Address: _____

Purchase Date: _____ TEL / E-mail: _____

Purchase Channel: _____ Postal Code: _____



Executive standard: GB4943.1-2022