



USER MANUAL
HAIR DRYER KAMARI

CONTENTS

INTENDED USE	3
SAFETY PRECAUTIONS.....	3
SPECIFICATIONS.....	4
PACKAGE CONTENTS.....	5
DEVICE DIAGRAM.....	6
OPERATING INSTRUCTIONS.....	7
Getting Started.....	7
Speed Adjustment.....	7
Temperature Adjustment.....	7
Cold Air Function	7
Lock Position.....	7
Memory Function.....	8
MAINTENANCE AND CARE.....	8
Self-Cleaning Function.....	8
Manual Cleaning.....	9
ERROR CODES	10
RULES AND CONDITIONS FOR INSTALLATION, STORAGE, TRANSPORTATION, SALE (DISTRIBUTION), AND DISPOSAL.....	11
WARRANTY INFORMATION	12
ADDITIONAL INFORMATION	12

Thank you for choosing SHEO!

In creating our devices, we strive to understand your needs and anticipate your expectations. We hope that our products will become a pleasant addition to your daily self-care ritual.

This manual contains instructions for the proper use and care of the product, as well as guidelines for quick and safe device setup. Please read each section carefully to get the most out of this model. Please keep this manual in a safe place and use it as a reference for future operation of the product.

INTENDED USE

The hair dryer is designed for drying and styling hair at home.

SAFETY PRECAUTIONS

- Before plug in, make sure that the voltage of your home power source corresponds to the device specifications. Plug the device only into a grounded outlet.
- Do not use the device near sources of water or other liquids. Never place the device under running water or immerse it in water.
- Do not touch the device with wet hands.
- Always turn off the device before unplugging it. To disconnect, grasp the plug — do not pull the cord itself.
- Do not pull or move the device by the cord. Do not bend or wrap the cord around the device. Also ensure the power cord does not bend over the edge of the countertop or come into contact with hot surfaces or sharp edges.
- Always unplug the device from the power outlet immediately after use. Before storing the device, wait until it has cooled down completely.
- Use only the accessories supplied with the device. Using of any other accessories may pose a risk to life and health and will void your warranty.
- Be cautious when handling the device, as some parts may become extremely hot during operation. Hold the device only by the handle and avoid contact of hot parts with skin.
- Do not use the device near flammable gases, liquids, or materials.

- Never cover the device (e.g., with a towel or clothing) while it is still hot.
- Never insert foreign objects into the air inlet or outlet vents. Clean them regularly to prevent clogging.
- Immediately disconnect the device from the power supply in the event of a malfunction. Do not turn on the device if there is visible damage, or if the power cord or plug is damaged. Contact an authorized service center.
- Do not disassemble the device yourself to avoid electric shock. This device contains no user-serviceable parts. Maintenance and repairs should only be performed by qualified technicians at an authorized service center.
- Ensure that hair does not enter the air inlet vents.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.
- This device is not intended for commercial use.
- Place the device only on heat-resistant, stable, and flat surfaces. Ensure that the hot parts do not come into contact with any flammable materials.

SPECIFICATIONS


- Model: Kamari
- Trademark: Sheo
- Power: 2000 W
- Power supply: 220–240 V, 50/60 Hz
- Number of temperature settings: 3
- Number of speed settings: 3
- Cold air function
- Overheat protection
- Ion generator
- BLDC motor

- Self-cleaning function
- Power cord length: 3 m
- Cord type: Z
- Protection class: II
- IP code: IPX0
- Scope of application: Domestic

PACKAGE CONTENTS

- Hair dryer
- Concentrator nozzle
- Diffuser nozzle
- Storage bag
- User manual

DEVICE DIAGRAM



1. Handle
2. Speed switch
3. Temperature switch
4. Cold air button
5. Indicators
6. Air intake vents

7. Back cover
8. Power / button lock switch
9. Power cable
10. Concentrator nozzle
11. Diffuser nozzle

OPERATING INSTRUCTIONS

Getting Started

1. Attach the concentrator or diffuser nozzle to the device, depending on your desired airflow style.
2. Plug the device into the power outlet, then set the power switch to the « — » position.
3. When first turned on, the hairdryer will start operating at the lowest temperature and lowest speed settings, with one indicator light lit next to the corresponding adjustment buttons.

Speed Adjustment

Press the speed button to select the desired airflow speed. The number of blue indicator lights shows the current speed level: one — low, two — medium, three — high.

Temperature Adjustment

Press the temperature button to select the desired temperature. The number of red indicator lights shows the current temperature level: one — low, two — medium, three — high.

Cold Air Function

You can use the cold air function to set your hairstyle. To activate cold air, press the corresponding button — the indicator next to the button will light up, and the red temperature indicators will turn off. To return to the previous settings, press the button again.

Lock Position

To lock the selected airflow speed and temperature settings, move the power switch to the "  " position — return the switch to its previous position to allow the settings to be changed again.

Memory Function

This hair dryer is equipped with a memory function that saves the set settings. If you adjust the desired temperature and airflow speed and then turn off the hair dryer, it will resume operation with the same settings when turned on again.

MAINTENANCE AND CARE

CAUTION:


- To ensure efficient operation and extend the service life of the device, it is important to keep it clean. Regularly clean the filter of dust and hair.
- Do not use abrasive cleaning agents to clean the device housing, and never immerse the device in water.

Self-Cleaning Function

This hair dryer includes a self-cleaning function that cleans its internal components.


To perform self-cleaning::

1. Plug the hair dryer into a power source, but do not turn it on.
2. Turn the filter cover counterclockwise and gently pull it off to remove it. Remove the external filter.
3. Press and hold the cold air button for 5 seconds — the motor will start, and



the hair dryer will blow air in reverse direction. The self-cleaning cycle will last for 15 seconds, during which all buttons will be inactive.

4. Once the self-cleaning cycle is complete, reattach the external filter and cover, then use the hair dryer as usual.



Note:


If you move the power switch to the ON position during the self-cleaning cycle, the self-cleaning will be interrupted.

Manual Cleaning

- It is recommended to periodically clean the filter manually to remove heavy dirt, dust, and hair.
- Remove the filter as described above, then clean it using a damp cloth or sponge. Ensure there is no foreign debris blocking the filter openings.
- Before reinstalling the filter, wipe it completely dry.

ERROR CODES

This device is equipped with an automatic error detection function. If a malfunction is detected during operation, the device will stop working, and the indicator lights on the handle will start flashing to display an error code. To determine the possible cause of the malfunction, refer to the table below:



Cause	LED1	LED2	LED3	LED4	LED5	LED6
Overcurrent	Flashes	OFF	OFF	OFF	OFF	OFF
Thermistor out of operating range	OFF	Flashes	OFF	OFF	OFF	OFF
Firmware error	Flashes	Flashes	OFF	OFF	OFF	OFF
Overvoltage	Flashes	Flashes	Flashes	OFF	OFF	OFF
Undervoltage	Flashes	Flashes	Flashes	Flashes	OFF	OFF
Motor malfunction	Flashes	Flashes	Flashes	Flashes	Flashes	OFF
Phase loss	Flashes	Flashes	Flashes	Flashes	Flashes	Flashes
Other	Flashes	OFF	Flashes	OFF	Flashes	OFF

RULES AND CONDITIONS FOR INSTALLATION, STORAGE, TRANSPORTATION, SALE (DISTRIBUTION), AND DISPOSAL

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

WARRANTY INFORMATION

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 36 months

Service Life: 36 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

ADDITIONAL INFORMATION

Manufacturer: Ningbo Ryaca Electrical Co., Ltd.

#298, Ankang Road, Kanxi Industrial Zone, Kandun Street, Cixi, Ningbo City, ZheJiang Province, P.R. China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1



