INSTALLATION GUIDE

This installation guide is applicable for NEPTWIN Series



NEPTWIN

PRODUCT SCHEMATIC DRAWING



❶	Nut	4 pcs	❷	Insulation Pillar	4 pcs	❸	Screw Bolt	4 pcs	❹	Mounting Bracket(Intel)	2 pcs	❺	De-Vibration Buckle	4 pcs
❻	Retention Plate	1 pc	❼	Back Plate	1 pc	❽	Mounting Bracket(AMD)	2 pcs	❾	Insulating Washer (For LGA775 only)	1 pc	❿	Double-screw Bolt (For LGA20XX only)	4 pcs
⓫	Thermal Grease	1 pc	⓬	Heatsink set	1 pc	⓭	Double-screw Bolt (For AM4 only)	4 pcs						







www.deepcool.com

Brands and designs are trademarks from Beijing Deepcool Industries Co., Ltd.
Devices not included
All rights reserved

Beijing Deepcool Industries Co., Ltd.
MADE IN CHINA

九州风神

安装说明书

此说明书适用于九州风神大霜塔系列。



大霜塔

产品示意图



❶	螺母	4 个	❷	绝缘柱	4 个	❸	螺柱	4 个	❹	Intel转接架	2 个	❺	减震扣	4 个
❻	扣具	1 个	❼	背板	1 个	❽	AMD转接架	2 个	❾	绝缘垫(LGA775专用)	1 个	❿	双头螺栓(LGA20XX专用)	4 个
⓫	导热膏	1 个	⓬	散热器主体	1 个	⓭	双头螺栓 (AM4专用)	4 个						







www.deepcool.com

九州风神公司2017版权所有。
手册中提及的其他商标或品牌等知识产权由相关权利人所有。

出品：北京市九州风神科技有限公司
地址：北京市海淀区知春路9号世纪10号楼
中国制造