VIRTUOSO PRO
QUICK START GUIDE




IN THIS GUIDE

GETTING TO KNOW YOUR HEADSET
- CONTROLS AND FEATURES
- MICROPHONE CONTROL (G)
- EAR PADS
- SPEAKER TAGS
- HEADBAND CUSHION

COPYRIGHT / LEGAL INFORMATION

GETTING TO KNOW YOUR HEADSET




A. LEFT 3.5MM PORT
B. RIGHT 3.5MM PORT
C. SPEAKER TAGS
D. HEADBAND CUSHION
E. EAR CUPS
F. MICROPHONE MUTE TOGGLE
G. 3.5MM TO DUAL 3.5MM AUDIO CABLE WITH MIC BOOM
H. 3.5MM TO DUAL 3.5MM AUDIO CABLE
I. Y-ADAPTER CABLE

CONTROLS AND FEATURES

The VIRTUOSO PRO features a balanced audio design and uses a dual 3.5mm cable on the headset side which requires both connections to function. An "L" and "R" are indicated on the inside of the headband and the corresponding 3.5mm jack. The microphone boom (G) connects to the left 3.5mm port (A).



Included is an optional audio cable without a microphone boom (H) should you wish to use the headset with a standalone microphone.



A balanced audio cable is an available option that allows for connecting the VIRTUOSO PRO to a 4.4mm balanced audio source. The balanced audio cable is sold separately at CORSAIR.com.

You can connect the VIRTUOSO PRO using the 3.5mm jack to any PC, Mac, PlayStation 4/5, XBOX Series*, Nintendo Switch, or mobile device using the 3.5mm headphone jack.

For devices that have individual headphone and microphone inputs, you can use the included Y-Adapter cable (I).

Place the headset on your head and adjust the headband for a comfortable fit.

The plush memory foam ear pads enable the VIRTUOSO PRO headset to fit comfortably, so you can play and listen for hours without fatigue.

*May require Microsoft adapter (sold separately).

NOTE: Prolonged listening at high volumes may adversely affect your hearing. Take breaks between sessions and always begin with the volume at a low level before increasing.

MICROPHONE CONTROL (G)

Slide down on the microphone mute toggle to mute. Slide up on the microphone mute toggle to unmute (F). For best performance, bend the flexible microphone boom to best fit near the left corner of your mouth. We've found that a 30-degree bend is a good place to start, but feel free to increase or decrease this if your mic is too loud or too soft.

EAR PADS

The ear pads for the VIRTUOSO PRO are user-replaceable. Twist the ear pads to detach. Twist the ear pads in reverse to attach.



SPEAKER TAGS

The speaker tags for the VIRTUOSO PRO are user-replaceable. To remove the speaker tag, locate the notch at the bottom of the headphone cup. Gently pull the speaker tag away from the headphone cup housing.




To attach the speaker tags, align the arrows on the speaker tag with the arrow on the inside of the headphone cup housing and press gently to install.

HEADBAND CUSHION

The headband cushion is user-replaceable. The cushion is attached with clips at the ends and in the center. Compress the headband slightly and pull the headband cushion downwards with both hands.

To attach the headband cushion, slightly compress the headband first. Align both pairs of clips on the left and right of the headband with the slots in the cushion. Push the headband cushion up and snap the middle of the headband together.

The top outer CORSAIR Logo band slides off from right-to-left.



COPYRIGHT / LEGAL INFORMATION

© 2023 CORSAIR MEMORY, Inc. All rights reserved. CORSAIR and the sails logo are registered trademarks of CORSAIR in the United States and/or other countries. All other trademarks are the property of their respective owners. Product may vary slightly from those pictured.