

尺寸:100*100mm
材质:100克双胶纸
双面印刷

MCHOSE



— G98 User Manual —

MECHANICAL KEYBOARD



Keyboard turning off: Switch the toggle to【OFF】and unplug the cable to disconnect.
Keyboard polling rate: 1000Hz in wired mode, 1000Hz in 2.4GHz mode, 125Hz in wireless mode.

Attention: The images in this manual are all schematic diagrams and may deviate from the actual product. Please refer to the actual product for accuracy.


·2.4GHZ CONNECTION



① Switch the toggle to【2.4G】to enter the 2.4GHz mode.
② Open the nameplate cover from the top right corner of the keyboard and take out the USB dongle from the dongle compartment.
③ Insert the USB dongle into the USB port on your computer. The keyboard is now ready for use.

Manual pairing dongle: Switch the toggle to the position【2.4G】to enter 2.4GHz mode. Press【FN+`~】and hold for 3 ss. The indicator will quickly flash cyan to enter the pairing mode. Plug the included dongle into the desired device.【Indicator light】will flash cyan for 2s and become normal when the 2.4GHz wireless mode connect successful.
Note: The dongle is default paired.


·WIRELESS CONNECTION



① Switch the toggle to【B】to enter the wireless mode.
② Press the combination key to switch to wireless1 and hold for about 3 seconds until the blue light flashes quickly to activate wireless pairing.
③ Search for the wireless device name【MCHOSE G98 3.0】or【MCHOSE G98 5.0】on your device, and click to connect, the wireless indicator light will go back to normal after successful pairing.

The wireless device names for channels 1, 2, and 3 are【MCHOSE G98 3.0】or【MCHOSE G98 5.0】.
·The combination key of wireless channel 2 is【FN+2 @】Indicate light is blue.
·The combination key of wireless channel 3 is【FN+3 #】Indicate light is blue.
Press the combination key and hold for about 3 seconds until the corresponding wireless channel indicator light flashes quickly, indicating that the keyboard has entered detect pairing or search mode, and can be paired and connected to the device;
·Press the combination key "Fn" +number keys "1!", "2@", or "3#" to switch devices.

·WIRED CONNECTION



① Switch the toggle to【OFF】to enter the wired mode.
② Connect the cable to Type-C port of the keyboard.
③ Connect the cable to the USB port of the computer. The keyboard is ready to use.

·POWER SAVING MODE

In 2.4GHz wireless mode, the keyboard backlight will turn off after 1 minute of inactivity. The keyboard 2.4G /Wireless mode will be disconnected after 30 minutes of inactivity.Press any key to active it.

• BACKLIGHT EFFECT

Press the combination key【FN+\】to switch 16 backlights.
In combination with the drive and RGB lighting effects with music rhythm, you can choose from 10 lighting modes.

• FN KEY COMBINATION DESCRIPTION (LIGHTING FUNCTION)

Fn +	ESC	~`	1!	2@	3#
	Reset	2.4GHz pairing	wireless device 1	wireless device 2	wireless device 3
	Q	W	E	R	|
	Android system	Win system	Mac system	IOS system	Switch backlight mode
	TAB	↑	↓	←	→
	Switch backlight color	backlight brightness+	backlight brightness-	backlight speed-	backlight speed+
	Right Shift	/?	B	Right Alt	Right Ctrl
	Switch atmosphere lighting mode	Switch atmosphere lighting color	Switch ambient light strip to power mode	Cycle switch ambient light strip brightness evels	Cycle switch ambient light strip speed levels
	WIN	DEL	U	I	O
	Lock/Unlock WIN	INS	PRTSC	SCRLK	PAUSE

FN+ WIN: Locks or unlocks the Win key. In Windows systems, the indicator light remains lit when the Win key is locked, and the Win key becomes inactive.
When switched to Mac System from Windows, the functions of the WIN key and Left ALT key are interchanged. Additionally, F1-F12 keys will function as multimedia keys.

WINDOWS SYSTEM F-ZONE SINGLE PRESS FUNCTION AND FN COMBINATION FUNCTION

Key	F1	F2	F3	F4	F5	F6
Press with FN combination key	Home page	Email	Switch window	Open the Explorer	backlight brightness-	backlight brightness+
Press the single key	F1	F2	F3	F4	F5	F6
Key	F7	F8	F9	F10	F11	F12
Press the single key	Previous song	Play / Pause	Next song	Mute	Volume-	Volume+
Press with FN combination key	F7	F8	F9	F10	F11	F12

MAC SYSTEM F-ZONE SINGLE PRESS FUNCTION AND FN COMBINATION FUNCTION

Key position	F1	F2	F3	F4	F5	F6
Press the single key	Screen brightness -	Screen brightness +	Switch window	Back to desktop	backlight brightness-	backlight brightness+
Press with FN combination key	F1	F2	F3	F4	F5	F6
Key position	F7	F8	F9	F10	F11	F12
Press the single key	Previous song	play / Pause	Next song	Mute	volume-	volume+
Press with FN combination key	F7	F8	F9	F10	F11	F12

* When switched to Mac System from Windows, the functions of the WIN key and Left ALT key are interchanged.

ANDROID SYSTEM F-ZONE SINGLE PRESS FUNCTION AND FN COMBINATION FUNCTION

Key position	F1	F2	F3	F4	F5	F6
Press the single key	Screen brightness -	Screen brightness +	Switch window	Back to desktop	backlight brightness-	backlight brightness+
Press with FN combination key	F1	F2	F3	F4	F5	F6
Key position	F7	F8	F9	F10	F11	F12
Press the single key	Previous song	play / Pause	Next song	Mute	volume-	volume+
Press with FN combination key	F7	F8	F9	F10	F11	F12

IOS SYSTEM F-ZONE SINGLE PRESS FUNCTION AND FN COMBINATION FUNCTION

Key position	F1	F2	F3	F4	F5	F6
Press the single key	Screen brightness -	Screen brightness +	Switch window	Back to desktop	backlight brightness-	backlight brightness+
Press with FN combination key	F1	F2	F3	F4	F5	F6
Key position	F7	F8	F9	F10	F11	F12
Press the single key	Previous song	play / Pause	Next song	Mute	volume-	volume+
Press with FN combination key	F7	F8	F9	F10	F11	F12

* When switched to IOS System from Windows, the functions of the WIN key and Left ALT key are interchanged.


POWER DISPLAY



1.Indicator light in red for low power.
2.Indicator light in green for full power.

In 2.4GHz/wireless mode (without connecting the USB cable), press FN+B to display the power status. A green light indicates full power, while the light strip decreases when power decreases. When in low power, the light turns red.

CHARGING INSTRUCTION



By connecting the keyboard to the computer with the provided USB cable, the keyboard will charge. During the charging process, the status indicator light will flash continuously. Once fully charged, the status indicator light will turn green. When the ambient light turn red, please charge the keyboard in time.

·SPECIFICATIONS

Product model: G98
Connectivity: wireless/2.4GHz/Wired
Charging interface: Type-C
Charging voltage/current: DC 5V ⎓ 1.5A

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are
designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates, uses and can radiate radio
frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
–Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
–Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

⚠ CHARGING INSTRUCTIONS

1. It is recommended to only use the computer USB interface to charge the keyboard;
2. Do not use a fast charging mobile phone charger to charge the keyboard;
3. Do not use inferior non-standard power adapters to charge the keyboard;
4. Do not use an overvoltage and overcurrent power adapter to charge the keyboard;
5. Please stay away from high-temperature equipment when charging;
6. Please turn off the power switch when not in use for a long time.

The above charging instructions also apply to other devices with charging functions (keyboard/mouse/headphones/speakers, etc.)

WARRANTY CARD

Thank you for purchasing our product. If there are any quality issues within the warranty period, please contact us. Meanwhile, please provide this warranty card so that we could offer you after-sales service.


Product Items: _____ Customer Name: _____

Serial NO. : _____ Warranty Address: _____

Purchase Date: _____ Warranty Contact: _____

Purchase Channel: _____ TEL / E-mail: _____

Sales: _____ Postal Code: _____



Executive standard: GB4943.1-2022