封底

Please read the instructions carefully before using this product and keep it well for reference.

Made in China

封面


USER MANUAL

NEON
Gaming mouse

T-TGM205 V1

Button Instructions

1. Left mouse button.
2. Right mouse button.
3. Middle button.
4. Side button (defaulted to Forward).
5. Side button (defaulted to backward).
6. DPI + button: DPI increase(Default to speed up the cursor).
7. DPI – button: DPI decrease (Default to slow down the cursor).
8. Light mode switch button.



T-TGM205 V1

Light Instructions

Corresponding color and DPI gear are as below:

1. Red – 800 DPI
2. Blue – 1600 DPI
3. Green – 2400 DPI
4. Purple – 3200 DPI
5. Yellow – 4800 DPI
6. Cyan – 12800 DPI

Back-lighting Instructions

Light patterns: Flow, Full light, Breathing, 9 color wave, Neon, Rainbow, 9 colorwheel, OFF.

Software Instructions

Users can adjust the following settings through the software after downloading and installing it.

1. Adjust the DPI of the mouse. Speed (range: 800-12800DPI).
2. Report rate, sensitivity, scroll speed, double click speed.
3. LED Lighting: Adjust mouse lighting options.
4. Customize 7 mouse buttons.


FAQ

1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computer USB port, or try another USB port.
2. If the cursor is moving slowly, jumping or intermittent, please try another surface. Surfaces that are dark, dirty, not flat, or bright may affect the performance of the mouse. Use of a mouse pad is recommended.

T-TGM205 V1

Описание кнопок

1. Левая кнопка мыши.
2. Правая кнопка мыши.
3. Средняя кнопка.
4. Боковая кнопка (по умолчанию, перемещение вперед).
5. Боковая кнопка (по умолчанию, перемещение назад).
6. Кнопка DPI +: Увеличение DPI (по умолчанию, для ускорения курсора).
7. Кнопка DPI -: Уменьшение DPI (по умолчанию для замедления курсора).
8. Кнопка выбора режима подсветки.



T-TGM205 V1

Инструкции для настройки цвета

Ниже описаны цвет и передача (уровень) DPI:

1. Красный – 800 DPI
2. Синий – 1600 DPI
3. Зеленый – 2400 DPI
4. Фиолетовый – 3200 DPI
5. Желтый – 4800 DPI
6. Голубой – 128000 DPI

Инструкции по выбору типа подсветки:

Режимы подсветки: Поток, Горит постоянно, Пульсация, 9-цветная волна, Неон, Радуга, 9-цветное колесо, Выкл.

Инструкции к программному обеспечению

Пользователь может настроить следующие параметры после загрузки и установки ПО.

1. Разрешение DPI мыши. Скорость (диапазон: 800-12800DPI).
2. Частота опросов, чувствительность, скорость прокрутки, скорость двойного нажатия.
3. Светодиодная подсветка: Настройка параметров подсветки мыши.
4. Возможность настройки до 7 кнопок мыши.

Часто задаваемые вопросы

1. Если мышь не отвечает, убедитесь в том, что мышь подключена правильно в соответствующий USB-порт на компьютере, также попробуйте использовать другой USB-порт.
2. Если курсор движется медленно, прыжками или прерывисто, попробуйте использовать другую поверхность. Слишком темные, грязные, не плоские или яркие поверхности могут повлиять на работу мыши. Рекомендуется использовать коврик для мыши.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

型号	JAL T-TGM205 V1 2802		备注：尺寸：L100*W100 材质：80克书纸，风琴折 印刷：单黑印刷				
名称	说明书						
日期	2024-4-9						
页码	1 OF 1		文件编号				
绘图	冯丽廷	审核	香敏琪	核准		版本	A.0