AJAZZ AF84 DUAL MODE MEMBRANE KEYBOARD

User Manual

Thank you very much for choosing our AJAZZ AF84 dual-mode membrane keyboard. This product has various cool functions and lighting effects, and we hope it can bring you a brand new operating experience. For more operations, you can go to the official website of AJAZZ to download the driver.

1.Basic parameters



Product brand: AJAZZ

Product model: AF84

Transmission mode: dual-mode (BT5.0/2.4G)

Product size: 348.9x203.3x32.1mm

Product weight: ≈ 680g

Shell material: ABS injection molding

Battery: AAA * 2 cells

Lighting effect: No light

Working voltage: 3.0V

Key layout: 84 keys

Supported systems: Suitable for Windows 8.0 and above, Mac OS 10.10 and above in Bluetooth mode Andord

Using WinXP in 2.4G mode, Vista，Win7/8/10

2. Indicator light description

2.1. "A": Caps lock indicator light

Press the Caps lock key and keep the red light on to turn on uppercase, then press the Caps lock key again to turn off the red light and restore lowercase.



2.2."📶" 2.4G indicator light

FN+Del key switches to 2.4G mode, the indicator light goes out to indicate

2.3. "BT1/BT2 ": BT channel indicator light

FN+BT1/BT2 switch BT channel, and the corresponding channel indicator light remains green after switching, indicating

2.4."⚡" Low battery indicator light

Flashing red light indicates low power on the keyboard

3. Mode switching description

1. BT mode

① BT1 channel name: AF84-1

Press FN+BT1 to switch channels, press FN+BT1 key for 3s to enter the pairing mode and the indicator light flashes green slowly

② BT2 channel name: AF84-2

Press FN+BT2 to switch channels, press FN+BT1 key for 3s to enter the pairing mode and the indicator light flashes green slowly

2. 2.4G mode

Insert the 2.4G receiver into the USB port of the computer host (the 2.4G receiver is paired by default at the factory)

FN+Del key switches to 2.4G mode

4. Key composite function description

COMB	Function	COMB	Function
FN+F1	Cut	FN+F7	Play/pause
FN+F2	Copy	FN+F8	Next song
FN+F3	Paste	FN+F9	Mute
FN+F4	Switch language	FN+F10	Volume-
FN+F5	Search for	FN+F11	Volume+
FN+F6	Previous song	FN+F12	Lock screen (black screen)
FN+Q	Switch to Android system	FN+E	Switch to IOS system
FN+W	Switch to Windows system (system default)		

Note: Combination keys on Android and iOS systems do not need to be used in conjunction with the FN key