ATK GEAR


ATK A87 User Manual

Models:ATK A87/ATK A87 PRO

ATK GEAR

A87 SERIES

使用指南
USER MANUAL



01 **CAPS INDICATOR:** Shows the status of Caps Lock. The light stays on when Caps Lock is active.

02 **WIN INDICATOR:** Shows the lock status of the Windows key. When locked, the light stays on and the key is disabled.

03 **SCROLL INDICATOR:** Shows scroll lock status. The light stays on when enabled.

04 **MODE SWITCH:**2.4G/Wired/BT

05 **PORT TYPE:**Type-C

06 **SYSTEM SWITCH:**Win/macOS Mode Switch

WIN **WIN KEY:**
Disabled when locked; functions as the Option key in macOS mode.

ALT **ALT KEY:**
Functions as the Command key in macOS mode.

2.4GHz Wireless Mode

❶ Press FN + R to activate 2.4G mode, the R key will flash blue rapidly. Plug in the USB receiver-it will automatically pair and install the necessary drivers. After successful pairing, the key light flashes slowly three times and reverts to default lighting. ❷ Switch the Mode toggle to 2.4G. ❸ Take out the receiver from the top storage slot. ❹ Insert the receiver into the computer's USB port.

Bluetooth Mode

❶ Switch the Mode toggle to Bluetooth. ❷ Press and hold FN + Q/W/E to start pairing. The indicator will flash rapidly in cyan, pink, or yellow depending on the key. ❸ Supports pairing with a maximum of 3 devices. Press FN + Q/W/E to switch between devices.

Wired Mode

❶ Insert the USB-C cable into the keyboard's port. ❷ Connect the cable to your computer. ❸ Switch the Mode toggle to Wired mode.

Note: During 2.4G or Bluetooth pairing and reconnection, the backlight turns off; only the key indicators will flash. After successful reconnection, the backlight restores to its normal lighting effect.

03 BATTERY INFORMATION

Battery Level Check

Press FN+Right ALT: The indicators show battery percentage. Release to restore default lighting effects.

- 100% : Keys 1 –10 light up green
- 90% : Keys 1 –9 light up green
- 80% : Keys 1 –8 light up green
- 70% : Keys 1 –7 light up green
- 60% : Keys 1 –6 light up green
- 50% : Keys 1 –5 light up green
- 40% : Keys 1 – 4 light up yellow
- 30% : Keys 1 – 3 light up yellow
- 20% : Keys 1 – 3 light up red
- 10% : Keys 1 – 2 light up red
- Below 10%: Key 1 lights up red

Low Power Warning

When the battery is below 25%, the light bar will flash red.

Charging Method

Connect the keyboard to your PC using the supplied cable in any mode to charge.

Breathing green light: Charging

Solid green light: Fully charged

Sleeping Mode

In Bluetooth and 2.4G modes, the keyboard enters level 1 sleeping mode after 3 minutes of inactivity(backlight off). After 10 minutes, it enters level 2 sleeping mode, disconnecting Bluetooth/2.4G. Press any key to reconnect instantly.



+

Multimedia Shortcuts		
Key	**Windows System**	**MAC System**
ESC	Press and hold for 3 seconds to restore factory settings	
F1	Decrease screen brightness	Decrease screen brightness
F2	Increase screen brightness	Increase screen brightness
F3	Calculator	Task manager
F4	Computer	Siri
F5	Media player	Mission control
F6	Previous track	Search
F7	Next track	Previous track
F8	Pause/Play	Pause/Play
F9	Stop	Next track
F10	Mute	Mute
F11	Volume down	Volume down
F12	Volume up	Volume up
1	Gaming Mode 1(FPS)-ASDW/Arrow keys light up	
2	Gaming Mode 2(CF) ASDW/CTRL/SHIFT/ALT/SPACE/RGQEB/1-5 keys light up	
3	Gaming Mode 3(COD) -WRASD/SHIFT/ALT/Arrow keys light up	
WIN	Press FN + WIN to lock/unlock the WIN key	
Lighting Controls		
| \	Switch lighting effects	
END	Light bar effect mode switch (Rainbow/Seven Colors/Monochrome Breathing/Monochrome Solid/Off)	
HOME	Switch light bar color	
DEL	Switch lighting colors (Red/Green/Blue/Yellow/Pink/Cyan/White/Mixed Color)	
Backspace	Turn off all lights	
←	Slow down lighting speed	
→	Speed up lighting speed	
↑	Increase backlight brightness	
↓	Decrease backlight brightness	

Q Why is my WIN key not working?

A The WIN key is locked when you press FN + WIN. The WIN indicator light will be on. Press FN + WIN again to unlock it.

Q Why are the WIN and ALT keys swapped, and F1–F12 not working?

A If the system switch is set to macOS, the WIN and ALT keys are swapped and F1–F12 become function keys. Switch back to Windows mode using the System toggle.

Q How can I customize the keys, use macros, and modify more RGB lighting effects?

A You can download the latest driver from ATKGEAR.COM to customize keys, edit macros, and adjust RGB lighting effects to experience the full keyboard functionality.

Scan the QR code on DISCORD for more information

ATK A87

Scan the QR code on YOUTUBE for more information

ATK A87

Scan the QR code on X for more information

ATK A87

*All product details are subject to the information published on ATKGEAR.COM

Li-ion
Removal Instruction for Battery Recycling

驱动下载
Software Download
DESKTOP.ATKGEAR.COM

ATK GEAR

FC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following

measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/tv technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

微信扫码关注
了解更多咨询

ATKGEAR.COM

ALL FOR GAMING.