AJAZZ × NACODEX

AJAZZ AK980MAX MAGNETIC AXIS MECHAICAL KEYBOARD

User Manual

Thank you very much for purchasing our AJAZZ AK980MAX Mechanical Keyboard. This product has various cool functions and lighting effects. I hope it can bring you a new operating experience. For more operations, you can go to the AJAZZ official website to download the driver.

1. Basic parameters

Product brand: AJAZZ

Product model: AK980 MAX

Transmission method: USB wired

Interface type: Keyline separated Type-C interface

Product size: 416.7 * 148 * 19.4mm

Product weight: ≈ 978g

Shell material: ABS

Wire length: 1.6M

Lighting effects: RGB, 20 types of lighting effects

Button layout: 101 keys

Matrix: All keys have no impact

Supported systems: Windows Vista/XP/7/8/10/11, MAC and other system devices



2. Indicator light description

2.1. Win lock indicator: (Key indicator light: WIN key)

Press FN+WIN to keep the white light on, indicating locking. Press unlock again to turn off the white light, and the light effect follows the system.

2.2. Caps indicator light: (Key indicator light: CAPS key)

Press the Caps lock button to keep the white light on, indicating that uppercase is turned on. Press the Caps lock button again to turn off the white light, indicating that lowercase is restored. Unlock the light effect following system

2.3. Num indicator light: (Key indicator light: Num key)

Key indicator light (NUM key): When the Num key is pressed, the white light remains on, and when the white light is pressed again, it goes out to unlock. Unlock the light effect following system

2.4. Scrk indicator light: (Key indicator light: Scrk key)

Key indicator light (Scrk key): When the Scrk key is pressed, the white light stays on, and when it is pressed again, the white light goes out to unlock. Unlock the light effect following system

2.5. "A" RGB flowing light indicator light

FN+Z press to turn off, then press to turn on, factory default on

3. Light mode operation instructions

FN+\ | :Light Effect Switching, 20 Light Effects

FN+1!: Default FPS mode:W/A/S/D/↑/↓/←/→

FN+2@: Default LOL mode:Q/W/E/R/D/G/F/B/V/L-Ctrl/L-Alt/Tab/Space/1-6/Esc

FN+3#: Default 37 key office mode：A-Z 26 letters/[/]/;/' /./,///↑/↓/←/→

FN+~: Select one of the three game modes for lighting effects, press the FN+~key to record the lighting mode. When recording, press the key once for one color, for a total of 8 colors. Press the key again to turn off the lights. After recording, press the FN+~key again to save

FN+↑: Increase in light brightness (5 levels)

FN+↓: Decreased brightness of the lights (5 levels)

FN+←: Dynamic Light Direction Switching

FN+→: Switch backlight color

FN+=+: Light speed increase (5 levels)

FN+-_: Slow down the light speed (5 levels)

FN+X: Turn off the lights \ Turn on the lights

FN+Space: Press for 3 seconds, the keyboard light will flash 3 times, clear the light effect, and restore the factory settings (highest priority)

4. Key Composite Function Description

COMB	WIN	MAC	COMB	WIN	MAC
FN+F1	Media player	Brightness-	FN+F7	play/pause	Previous song
FN+F2	Volume-	Brightness+	FN+F8	Next song	play/pause
FN+F3	Volume+	mission control	FN+F9	mail	Next song
FN+F4	mute	console	FN+F10	browser	mute
FN+F5	Player stops play	Keyboard brightness-	FN+F11	My Computer	Volume-
FN+F6	Previous song	Keyboard brightness+	FN+F12	calculator	Volume+
FN+S	Switch to Win system mode		FN+A	Switch to Mac system mode	

5.Hot-swap operation steps

Hot plug: can replace different shafts, customize your favorite tactile and auditory feedback, and easily replace the compatible magnetic shaft body. (The pictures are for reference only, subject to the actual product)

①. Use a key puller to pull out the keycaps

②. Use the switch puller to clamp the upper and lower buckles at the bottom of the switch, and then pull the switch up

③. Check the pins and holes of the new switch

④. Press the switch vertically