AJAZZ ALUX60 RGB WIRED VERSION MECHANICAL KEYBOARD

User Manual

Thank you very much for choosing our AJAZZ ALUX60 RGB wired version Mechanical Keyboard. This product has various cool features and lighting effects, and we hope it can bring you a brand new operating experience. For more operations, you can go to the official website of AJAZZ to download the driver.

1. Basic parameters

Product brand: AJAZZ

Product model: ALUX60


Transmission method: USB wired

Interface type: Keyline separated Type-C interface

Product size: 304x112.8x41.5mm

Product weight: ≈ 950g

Shell material: Aluminum alloy



Wire length: 1.6M

Lighting effect: RGB color light (driver software can adjust 18 sets of lighting effects+custom lighting effects)

Key layout: 61 key layout

Support system: Windows Vista/XP/7/8/10/11, Mac

2. Indicator light description

2.1. Caps lock indicator light: (Key indicator light: CAPS)

Press the Caps lock key to turn on white light and enable uppercase, then press to restore lowercase and restore the light effect.

2.2. Lock win indicator light: (Key indicator light: Win)

Press the FN+WIN key to turn on the white light lock, then press unlock to restore the light effect.

3.Light mode operation instructions

FN+\|: Light Effect Switch, 18 Light Effects Cycle in Sequence

FN+ ‘’ “”: Increase in brightness of lights (five levels)

FN+;: Reduce the brightness of lights (five levels)

FN+。》: Switch backlight color

FN+【{: Reduce light speed (five gears) (factory default three gears)

FN+】}: Increase light speed (five levels) (default three levels at the factory)

FN+X： Turn off the lights \ Turn on the lights

FN+Space: Press 3s, the keyboard light will flash 3 times, clear the light effect, and restore the factory settings

4.Function Description of Combination Keys

COMB	WIN/MAC	COMB	WIN/MAC
FN+1!	F1	FN+7&	F7
FN+2@	F2	FN+8*	F8
FN+3#	F3	FN+9(	F9
FN+4$	F4	FN+0)	F10
FN+5%	F5	FN+-_	F11
FN+6^	F6	FN++=	F12
FN+Esc	·`	FN+Shift+Esc	~
FN+A	Switch MAC System	FN+S	Switch WIN System
FN+/?	Direction ↑	FN+Right Alt	Direction ←
FN+MENU	Direction ↓	FN+Right CTRL	Direction →
FN+Left CTRL	Press to switch from "1!" to "=+" in the numeric keypad to F1-12, then press to switch back to the numeric keypad (default numeric keypad at factory)		

5. Instructions for hot plug operation steps

Hot plug: can replace different shafts, customize your favorite tactile and auditory feedback, and easily replace the compatible magnetic shaft body. (The pictures are for reference only, subject to the actual product)

① Use a key puller to remove the keycap

②. Use the switch puller to clamp the upper and lower buckles at the bottom of the switch, and then pull the switch up

③New switch calibration pin and hole position

④Press the shaft vertically