MCHOSE



— Ace 68 *Turbo* Series User Manual —

Hall Effect Magnetic Switch Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

· PRODUCT OVERVIEW



· DRIVER INTRODUCTION

Web Driver: https://www.mchose.store/pages/firmware-2
Note: Open the URL in a browser, click on **[Open M HUB WEB]** > **[Initialize Device]** > **[Allow Browser Access]**, and then select the corresponding product model to connect.

Desktop App Driver: https://www.mchose.store/pages/firmware-2
Note: Open the URL in a browser, click on **Download M HUB Driver** and then download and install it.

Note: The MHUB desktop app driver currently supports only Windows 10 and above; Windows 7 and macOS are not supported at this time.

· COMBINATION KEY FUNCTIONS

Fn +

O	Windows System (Default)
P	Mac System
1!	F1
2@	F2
3#	F3
4$	F4
5%	F5
6^	F6
7&	F7
8*	F8
9(	F9
0)	F10
-_	F11
=+	F12

· COMBINATION KEY FUNCTIONS

Fn +

Esc	~
]}	Pause
[{	Print
Ins	Home
Del	End
Z	Previous Song
X	Next Song
C	Play/Pause
V	Stop
B	Mute
N	Volume-
M	Volume+
Win	Lock / Unlock Windows Key
Space	Restore Default Settings

W	Switch Lightbar Lighting Mode
E	Lightbar Brightness -
R	Lightbar Brightness +
A	Switch Lightbar Lighting Color
T	Turn Off / On (Control all keyboard LEDs)
Y	Switch Backlight Color
U	Switch Backlight Effect
F	Backlight Brightness -
G	Backlight Brightness +
H	Backlight Speed -
J	Backlight Speed +