MCHOSE



K7 V2 Gaming Wireless Mouse

User Manual

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

• English

PRODUCT FUNCTION DESCRIPTION







CHARGING / WIRED CONNECTION



• Plug the included USB cable into the computer's USB port, and the Type-C end into the mouse's corresponding port. The mouse will then switch to wired mode and begin charging.

MAGNETIC WIRELESS CHARGING DOCK CHARGING



• Plug the standard USB cable into the computer's USB port, and the Type-C end into the magnetic wireless charging dock. Place the mouse properly on the magnetic wireless charging dock; the indicator light will stay solid red to indicate charging.Once fully charged, the indicator light will stay solid green.
* When both wired and wireless charging are connected simultaneously, wired charging takes priority.

2.4G CONNECTION



• Connection method 1 (Recommended): Insert the provided data cable into the computer's USB 2.0/3.0 or higher port①, plug the USB-C end of the cable into the USB-C port of the magnetic wireless charging dock②, and insert the receiver③ into the USB-A port of the magnetic wireless charging base. After inserting the receiver into the magnetic wireless charging dock, place it on the desktop. Keep the distance between the receiver and the mouse within 30 cm.
• Connection method 2: Insert the receiver③ into the computer's USB 2.0/3.0 or higher port①.
* Magnetic wireless charging dock: Ensures no signal degradation over long distances and improves stability.
* The 2.4G receiver is pre-installed in the magnetic wireless charging dock by default.

MCHOSE

YOUNG'S CHOICE

WIRELESS CONNECTION



• Switch the power button to [B], then press and hold the mouse's [Left + Middle + Right] buttons simultaneously for about 5 seconds until the indicator light flashes blue rapidly to enter pairing mode. Search for the pairing name **MCHOSE K7 V2.** Once connected successfully, the indicator light will turn off.

DPI ADJUSTMENT



DRIVER INTRODUCTION

Web Driver: https://www.mchose.store/pages/mchose-hub
Note: Open the URL in a browser, click on **[Open M HUB WEB] > [Initialize Device] > [Allow Browser Access]**, and then select the corresponding product model to connect.

Desktop App Driver: https://www.mchose.store/pages/mchose-hub
Open the URL in a browser, click on **Download M HUB Driver** and then download and install it.
Note: The MHUB desktop app driver currently supports only Windows 10 and above; Windows 7 and macOS are not supported at this time.

PRODUCT SPECIFICATIONS

Mouse:
Radio Frequency: 2.4 GHz
Operating Frequency: 2402-2480MHz
Max Output power: ≤10dBm

Radio Frequency: BT
Operating Frequency: 2400-2483.5MHz
Max Output power: ≤10dBm

Wireless Dongle:
Radio Frequency: 2.4 GHz
Operating Frequency: 2402-2480MHz
Max Output power: ≤10dBm

BATTERY STATUS INDICATOR



NOTICE

This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This device generates, uses, and can radiate radio frequency energy, and if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device on and off), we encourage the user to try one or more of the following measures to correct the interference:
• Reorient or relocate the receiving antenna.
• Increase the distance between the device and receiver.
• Connect the device to a different circuit from the one to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.
The operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via the computer's USB port.
2. Do not use fast-charging phone chargers to charge the mouse.
3. Do not use low-quality, non-standard power adapters to charge the mouse.
4. Do not use over-voltage or over-current power adapters to charge the mouse.
5. Keep the mouse away from high-temperature devices during charging.
6. Turn off the power switch when the mouse is not in use for an extended period.

The above charging instructions also apply to other rechargeable devices (keyboard, mouse, headset, speakers, etc.).

WARRANTY & SUPPORT

Thank you for choosing MCHOSE.
This product is covered by a limited 2-year warranty. Warranty terms and coverage periods may vary by country or region. For detailed information, please visit our official website.
During the warranty period, this warranty covers defects in materials, workmanship, and functional issues under normal use.
This warranty applies only to products purchased through official MCHOSE channels or authorized resellers.
For warranty support, please contact MCHOSE or your original seller and provide:
• Product model, purchase date & channel
• Name, email, phone number, and shipping address
• If the product was purchased through a local distributor or reseller, please contact them directly for after-sales support.

Exclusions
• This warranty does not cover damage caused by misuse, accidents, unauthorized modification or repair, improper use, or normal wear and tear.
• Products without valid proof of purchase may be treated as unauthorized products, and MCHOSE reserves the right to deny warranty or support service.

Statement of compliance with EU directive
2014/53/EU
2011/65/EU & 2015/863/EU

MCHOSE COMPLIANCE AND DOCUMENTS OF CONFORMITY

Hereby, Zhishi Intelligent Technology (Dongguan) Co., Ltd. declares that the radio equipment type, wireless mouse, model A7V3, is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: https://support.mchose.store/hc/en-us/articles/5197658385102B-MCHOSE-Compliance-and-Documents-of-Conformity

Manufacturer: Zhishi Intelligent Technology (Dongguan) Co., Ltd.
Address: Room 301, Building 2, No.6, Daji 3rd Road, Hengshan, Shipai Town, Dongguan City, Guangdong Province, China
Company: Shenzhen Zhishi Intelligent Technology Co., Ltd
Address: A3401, Rongde Times Square, Huaqiao New Village, Henggang Street, Longgang District, Shenzhen, Guangdong, China
Website: www.mchose.store