CREATE THE AMAZING

beyerdynamic GmbH & Co. KG
Theresienstraße 8 · 74072 Heilbronn / Germany
Phone +49 7131 617-300 · **E-Mail** info@beyerdynamic.de
www.beyerdynamic.com

For further distributors worldwide, please go to www.beyerdynamic.com
Non-contractual illustrations. Subject to change without notice.

EN 2 | MMX 150 | 691.836 | (02.22)

beyerdynamic

MMX 150

USB GAMING HEADSET

MANUAL

Congratulations to your Meta Pick! We hope you will enjoy your MMX 150 USB Headset from beyerdynamic.

Please take some time to read carefully through this manual before using the product.

ENJOY THE SOUND!

Your beyerdynamic Team

SAFETY INSTRUCTIONS

Risk of injury

- We would like to point out that excessively high volumes and long listening times may cause hearing damage. Hearing defects always constitute an irreversible impairment of hearing ability. If you suffer from tinnitus, do not use headphones or reduce the volume.
- When connecting the headset, please ensure that the volume is turned down to minimum. Adjust the volume after putting on the headset.


Danger to life

- Headphones drastically reduce perception of external sounds. Using headphones in road traffic can be potentially dangerous. The user's hearing must not be impaired to the extent that it causes road safety risks. Please also make sure that you do not use the headphones in traffic, especially within an area of potentially dangerous machines and tools.
- Furthermore, avoid using headphones in situations where hearing must not be affected, especially when crossing a railway crossing or at a construction site.


Liability / intended use

- Do not use the product for any application which is not described in this product information.
- beyerdynamic is not liable for improper use of the product and its accessories.

CONNECT THE MICROPHONE TO THE HEADSET




CONNECT THE CABLE TO THE HEADSET




CONNECT THE CABLE TO YOUR DEVICE

- Using the USB-C to USB-A cable, connect the headset (USB-C) and the other end (USB-A) to your device (e.g. computer / console).
- For devices with USB-C ports, please use a third-party USB-A to USB-C adapter or cable.
- Once the headset is connected, it will automatically install the drivers. This may take a few seconds. It should now be ready and selected as the main device. The lightguide around the control wheel will illuminate orange.
- Please also check your systems audio settings and select the MMX 150 as input and output device, if it's not already selected.



CONNECT THE HEADSET TO AN ANALOGUE JACK SOCKET (GAME CONTROLLER, SOUNDCARD, MOBILE ETC.)

- Connect the USB cable as previously described and connect it to your device's jack socket. The output signal should now be played back by the MMX 150, as well as input signals that will be picked up by the microphone. When on a computer please also check your systems audio setting and select your computers sound card as input and output device.
- **Please note:** The control elements and Augmented Mode are **not** available when using this cable, since there is no power supply.
- **Caution: Connect the jack connector of the cable to a headphone socket only!** If you connect the headset to any other jack socket, the headset could be damaged.




HEADSET CONNECTED TO A DEVICE

- The lightguide will illuminate orange, when the headset is connected to a device (e.g. computer / console) and nothing else has been activated.



CHANGING THE VOLUME

- The headphone volume can easily be increased by turning the control wheel up.
- To decrease the volume, turn the control wheel down.



FUNCTIONS AVAILABLE WHEN CONNECTED VIA USB

MUTE AND UN-MUTE THE MICROPHONE


- Press the control wheel briefly to mute the microphone.
  A high sound will indicate the mute status and a red light at the end of the microphone, as well as around the control wheel, will illuminate.
- Press the control wheel briefly again to un-mute the microphone. A deep sound will indicate the un-muted status and the red light will go off.






AUGMENTED MODE


- Using the Augmented Mode, your headphones works as if they were open i.e. you can hear your surroundings such as people talking to you or the doorbell, and you will not hear yourself muffled.
- Press and hold the control wheel (2 seconds). The Augmented Mode is enabled when you hear the voice prompt. The lightguide around the control wheel will illuminate turquoise.
- To disable the Augmented Mode, press and hold the control wheel again for 2 seconds. The turquoise light will go off.





REPLACING THE EAR PADS

- To remove the ear pad, gently turn it counter-clockwise and pull it off.
- To attach the ear pad, place it onto the orange housing and gently turn it clockwise until it sits tight.





MAINTENANCE

- Use a soft cloth moistened with water to clean the surface.
- Make sure that no water enters the headset.
- Do not use cleaning agents containing solvents.
- **Never** use a **vacuum cleaner** for cleaning the headset, as this may cause irreparable damage.

SERVICE

- If you require service, please contact qualified service personnel or directly:
  beyerdynamic Service- und Logistik Center
  E-mail: service@beyerdynamic.de
- Dismantling the headset yourself will invalidate the guarantee.

SUPPLIED ACCESSORIES

- 1 x USB-C to USB-A cable, 2.4 m (7.9 ft), to connect the headset to a computer
- 1 x USB-C to 4-pole Jack (CTIA) cable, 1.2 m (3.9 ft), to connect the headset to analogue/mobile devices*
- 1 x Microphone pop shield

ACCESSORIES / REPLACEMENT PARTS

- Accessories and replacement equipment can be found at: **www.beyerdynamic.com**
- If you have technical questions while using the headset or need further guidance, please visit our FAQ website at: **support.beyerdynamic.com**

*Control elements and Augmented Mode are not available when using this cable

DISPOSAL

- At the end of its operating life this product may not be disposed of along with normal household waste. Please take it to a designated recycling point for electric and electronic appliances.
- This is indicated by the symbol on the product, the operating instructions or the packaging.



TRADEMARK

- USB Type-A, USB Type-B and USB Type-C are trademarks of USB Implementers.

DE
Eine ausführliche Bedienungsanleitung in Ihrer Sprache finden Sie unter:
www.beyerdynamic.com/mmx150

FR
Vous pouvez télécharger la notice d'utilisation dans votre langue respective sur:
www.beyerdynamic.com/mmx150

ES
Podrá descargar el manual de instrucciones en su idioma desde:
www.beyerdynamic.com/mmx150

IT
Le istruzioni per l'uso dettagliate nella vostra lingua sono reperibili al sito:
www.beyerdynamic.com/mmx150

SV
En utförlig bruksanvisning hittar du på:
www.beyerdynamic.com/mmx150

RU
Руководство по эксплуатации на Вашем языке Вы можете загрузить здесь:
www.beyerdynamic.com/mmx150

JA
各国の言語の取扱説明書は次のホームページからダウンロードしてください。
www.beyerdynamic.com/mmx150

KO
원하는 언어로 된 안내 설명서를 다운로드하세요:
www.beyerdynamic.com/mmx150

ZH
您可以在www.beyerdynamic.com/mmx150下载所需语言的操作说明书。

MAINTENANCE

- Use a soft cloth moistened with water to clean the surface.
- Make sure that no water enters the headset.
- Do not use cleaning agents containing solvents.
- **Never** use a **vacuum cleaner** for cleaning the headset, as this may cause irreparable damage.

SERVICE

- If you require service, please contact qualified service personnel or directly:
  beyerdynamic Service- und Logistik Center
  E-mail: service@beyerdynamic.de
- Dismantling the headset yourself will invalidate the guarantee.

SUPPLIED ACCESSORIES

- 1 x USB-C to USB-A cable, 2.4 m (7.9 ft), to connect the headset to a computer
- 1 x USB-C to 4-pole Jack (CTIA) cable, 1.2 m (3.9 ft), to connect the headset to analogue/mobile devices*
- 1 x Microphone pop shield

ACCESSORIES / REPLACEMENT PARTS

- Accessories and replacement equipment can be found at: **www.beyerdynamic.com**
- If you have technical questions while using the headset or need further guidance, please visit our FAQ website at: **support.beyerdynamic.com**

*Control elements and Augmented Mode are not available when using this cable

DISPOSAL

- At the end of its operating life this product may not be disposed of along with normal household waste. Please take it to a designated recycling point for electric and electronic appliances.
- This is indicated by the symbol on the product, the operating instructions or the packaging.



TRADEMARK

- USB Type-A, USB Type-B and USB Type-C are trademarks of USB Implementers.

DE
Eine ausführliche Bedienungsanleitung in Ihrer Sprache finden Sie unter:
www.beyerdynamic.com/mmx150

IT
Le istruzioni per l'uso dettagliate nella vostra lingua sono reperibili al sito:
www.beyerdynamic.com/mmx150

JA
各国の言語の取扱説明書は次のホームページからダウンロードしてください。
www.beyerdynamic.com/mmx150

FR
Vous pouvez télécharger la notice d'utilisation dans votre langue respective sur:
www.beyerdynamic.com/mmx150

SV
En utförlig bruksanvisning hittar du på:
www.beyerdynamic.com/mmx150

KO
원하는 언어로 된 안내 설명서를 다운로드하세요:
www.beyerdynamic.com/mmx150

ES
Podrá descargar el manual de instrucciones en su idioma desde:
www.beyerdynamic.com/mmx150

RU
Руководство по эксплуатации на Вашем языке Вы можете загрузить здесь:
www.beyerdynamic.com/mmx150

ZH
您可以在www.beyerdynamic.com/mmx150下载所需语言的操作说明书。