Use & care manual

ZENET

MASSAGE MATTRESS ZET-836



Note: The specifications and/or components of this appliance are subject to change without prior notice.

SAVE THESE INSTRUCTIONS

Important Safety Instructions

WHEN USING ELECTRICAL PRODUCTS, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ ALL INSTRUCTIONS BEFORE USING.

DANGER – TO REDUCE THE RISK OF ELECTRIC SHOCK:

- ALWAYS unplug the unit from the electrical outlet immediately after using and before cleaning.
- DO NOT reach for a unit that has fallen into water. Unplug it immediately.
- Never use pins or other metallic fasteners with this appliance.
- DO NOT place or store appliance where it can fall or be pulled into a tub or sink.
- DO NOT place in or drop into water or other liquid.
- DO NOT use while bathing or in a shower.
- Carefully examine the covering before each use. Discard the appliance if the covering shows any sign of deterioration, such as checking , blistering,or cracking.
- Keep Dry - Do not operate in a wet or moist condition.

WARNING – TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:

- An appliance should never be left unattended when plugged in. Unplug from outlet when not in use and before putting on or taking off parts or attachments.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Comfier ; specifically any attachments not provided with the unit.
- NEVER operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to service center for examination and repair.
- Keep the cord away from heated surfaces.
- NEVER drop or insert any object into any opening.
- DO NOT operate where aerosol (spray) products are being used or where oxygen is being administered.
- DO NOT operate under a blanket or pillow.Excessive heating can occur and cause fire, electric shock, or injury to persons.
- DO NOT use this massager in close proximity to loose clothing or jewelry.
- Keep long hair away from massager while in use.
- DO NOT carry this appliance by the supply cord or use cord as a handle.

- To disconnect, turn all controls to the “off” position, then remove plug from outlet.
- DO NOT use outdoors.
- NEVER operate the appliance with the air openings blocked. Keep the air openings free of lint, hair, and the like.
- Use heated surfaces carefully. May cause serious burns.Do not use over insensitive skin areas or in the presence of poor circulation.The unattended use of heat by children or incapacitated persons may be dangerous.
- Temperatures sufficiently high to cause burns may occur regardless of the control setting. Do not use on an infant or invalid or on a sleeping or unconscious person. Do not use on insensitive skin or on a person with poor blood circulation .Check the skin in contact with the heated area of the appliance frequently to reduce the risk of blistering.
- Do Not Crush - Avoid sharp folds.

CAUTION – PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING.

- This product is not intended for medical use. It is intended only to provide a luxurious massage.
- Consult your doctor prior to using this product if:
  - You are pregnant
  - You have a pacemaker
  - You have any concerns regarding your health
- Not recommended for use by diabetics.
- Never leave the appliance unattended, especially if children are present.
- Never cover the appliance when it is in operation.
- Do not use this product for more than 15 minutes at a time.
- Extensive use could lead to the product's excessive heating and shorter life. Should this occur, discontinue use and allow the unit to cool before operating.
- Never use this product directly on swollen or inflamed areas or skin eruptions.
- DO NOT use this prouduct as a substitute for medical attention.
- DO NOT use this prouduct before bedtime. The massage has a stimulating effect and can delay sleep.
- NEVER use this product while in bed.
- This product should NEVER be used by any individual suffering from any physical ailment that would limit the user’s capacity to operate the controls or who has sensory deficiencies in the lower half of their body.
- NEVER use this product in automobiles.
- This appliance is intended for household use only.
- This appliance is designed for personal, non-professional use.

Instruction

Congratulations on your purchase of the Comfier Massager. It combines 10 Invigorating Massage motors and four heating pads target four heating zones to provide you with a soothing gentle Warmth and vibrating massage for your full body. You will feel more relaxed and rejuvenated.

Please read all instructions carefully before using this product.
Please retain this manual for future reference.

CONTENTS

- 10-Motor Massage Mat With Heat
- Home adapter






TECHNICAL DATA

Measurements:	67 x 24.4 inches
Weight:	4.3lbs
Voltage:	Input: AC 100-240V ~50/60Hz Output: 12VDC 2500mA
Nominal Power:	max. 30 Watt
Automatic runtime:	30 minutes

Please read all the safety instructions and warnings in manual before using this product.

Setup and Operation

1. If needed, fasten the strap around the back of a chair or other support.
2. Connect the adapter cable to the corresponding cable at the side of the mat.



Cushion side


Adaptor side

3. Plug the adapter into an outlet.
4. Turn on the device using the controller (instructions on page 6).

- Remove the adapter from the outlet when not in use.
- Do not setup or use the massager in a bathroom or similary wet / damp areas.

- For your own safety we equip the massage mattress with a protection against over-heating.Heat is created in the motors when placed under great stress and excessive pressure. Before this could create any risk and after a runtime of 30 Minutes. The massager will switch off automatically and will only allow switching on again after an appropriate downtime.

- Likewise, you should allow your body some rest periods. To avoid straining your muscles too much, we recommend to not exceed a continuous massage of 30 Minutes.



Massage Regions:
Each massage regions may be turned off or on as desired by press the button for any combination of regions and while any of the five MODES are active.
NOTE: the "LEG" button controls the leg and feet regions.

MODE indicators
Five Preprogrammed massage modes

Intensity indicators:
Low, Medium, High

ON/OFF:
Press to turn the massage mat on or off.

HEAT:
Press to activate heat, the heat can be used independently

INTENSITY:
Press to choose Low, Medium, High intensity of vibration.

MODE:
Press to change the MODE from M1 to M5.

Maintenance

1. Do not wash in washing machine or immerse the product or the adapter in water.
2. Always switch off before cleaning and remove the adapter from the socket with clean, dry hands.
3. The massager should be wiped with a slightly moist cloth and dried thoroughly. Do not wipe the product with alcohol or harsh chemicals such as thinner or bleach.
4. Keep away from heat, fire or exposure to direct sunlight.
5. Store the massager in a cool, dry place out of reach of children.
6. Avoid contact with sharp edges or pointed objects which might cut or puncture the fabric surface.

TROUBLESHOOTING GUIDE

Fault	Solutions
The massage is not active in all regions.	The massage motor for that region may have been switched off. Press the button that corresponds to that region to activate.
Device switches off suddenly	The device will switch off when the timer runs out.Continue using by pressing the 'Power' button. If the device has run for 60 mins., turn back on after resting the unit for 15 mins.
	Over-heat protection function activated. Device is switched off for your safety . Please rest device for 15-30mins before restarting.
Device fail to start	Check if device has been used for more than 30 mins.If so, let device rest for 15 mins before continuing. Device may require longer time to cool in warmer environments.
	Check if adapter is plugged into socket.
	Check if adapter output is connected to device power inlet wire.
Jerky motion of vibrations from device	Excessive pressure may have been applied onto the device. Reduce the load and try again.

MASSAGE MATRATZE ZET-836

GEBRAUCHSANLEITUNG

Spannung 220V

Leistung 14.4W

Sehr geehrter Kunde,

Vielen Dank, dass Sie sich für eines der ZENET-Massagemodelle entschieden haben.

Bitte lesen Sie die Bedienungsanleitung und speichern Sie sie für die zukünftige Verwendung.

BESCHREIBUNG:

Die Massagematratze ist mit Massagevibromotoren ausgestattet. Die Heilwirkung wird durch die Heizfunktion stark verstärkt. In Kombination mit der Erwärmung der Bewegung der Vibromotoren entspannen sie die Muskeln und beseitigen ihre Krämpfe. Dies ist eine zusätzliche Möglichkeit, die Durchblutung und das Lymphsystem zu stimulieren.

EIGENSCHAFTEN:

1.Ein Kissen im Bereich des Kopfes der Matratze für Komfort.
2.Die Matratze besteht aus weichem und angenehmem Stoff.
3.Wärmefunktion während der Massage.
4.Gibt es fünf Massageprogramme.
5.acht Massageköpfe - zwei für jede Zone.
6.Eine entspannende Vibrationsmassage für den ganzen Körper.

BETRIEBSHANDBUCH:

1.Schließen Sie den Adapter mit dem Gerät an eine Stromquelle an.
2.Die Taste «POWER» schaltet das Massagegerät ein und aus.
3.Kopf- und Nackenmassage – die Taste «NECK»
4.Die Taste «BACK» aktiviert die Rückenmassagefunktion.
5.Die Taste «THIGHS» aktiviert die Massagefunktion der Hüften und des Gesäßbereichs.
6.Die Taste «HEAT» aktiviert die Heizfunktion und die entsprechende Anzeige leuchtet auf.

GARANTIE VERBINDLICHKEITEN:

1.Garantieleistung des Geräts gemäß den Betriebsregeln - 1 Jahr ab Verkaufsdatum.

2.Während der Garantiezeit muss das Gerät ausgetauscht werden, wenn vom Hersteller verursachte Mängel festgestellt werden. Das Verkaufsdatum und der Stempel der Handelsorganisation sind erforderlich.

3.Die Garantie gilt nicht für Geräte mit:
- mechanische Beschädigung;
- mängel, die durch einen Verstoß gegen die Nutzungsbedingungen oder durch fehlerhafte Handlungen des Besitzers des Geräts entstanden sind;
- mängel infolge von Naturkatastrophen;
- mängel, die durch das Eindringen von Fremdkörpern und Flüssigkeiten infolge der Selbstreparatur oder Selbsteinführung von Strukturveränderungen entstanden sind;
- für gewerbliche oder industrielle Zwecke verwendet.

Masażowy Materac ZET-836

INSTRUKCJA OBSŁUGI

Napięcie 220V

Moc 14.4W

Szanowny klient!

Dziękujemy za zakup jednej z modeli masażera Zenet.

Prosimy przeczytać instrukcę z obsługi i zachować w celu późniejszego użycia.

OPISANIE:

Masażowy materac jest wyposażony masażowymi silnikami wibracyjnymi. Leczniczy efekt znacznie nasileje za pomocą funkcji grzania. W kompleksie z grzaniem ruchu silniki wibracyjne rozluźniają mięśnie i usuwają ich spazmy, jest dodatkową możliwością stymulacji cyrkulacji krwi i pracy limfatycznego systemu.

OSOBŁIWOŚCI:

1. Poduszka w obwodzie głowy materaca dla komfortu
2. Materac zrobiony z miękkiej i przyjemnej na dotyk tkaniny.
3. Cieplna funkcja podczas masaża.
4. 5 rodzajów programów masażowych.
5. 8 masażowych główek – po 2 na każdą strefę.
6. Rozluźniający wibracyjny masaż dla całego ciała.

EKSPLOATACJA:

1. Należy podłączyć adapter z masażerem do źródła żywienia.
2." POWER" włącza i wyłącza masażer.
3. Przycisk " SHOULDER" masaż głowy i szyi.
4. Przycisk " BACK", aktywuje funkcję masaża pleców.
5. Przycisk " THI GHS", aktywuje funkcję masaża bioder i pośladków.
6. Przycisk " HEAT", aktywuje funkcję grzania, i zapali się odpowiedni wskaźnik.

GWARANCYJNE ZOBOWIAZANIA:

1. Gwarancyjna obsługa przyrządu, pod warunkiem dotrzymania reguł eksploatacji - 1 rok od daty sprzedaży.

2. W ciągu gwarancyjnego terminu przyrząd podporządkowuje się zamianie przy wykryciu defektów, powstałych z winy producenta. Notatka o dacie sprzedaży i sztampa handlowej organizacji jest obowiązkowa.

3. Gwarancja nie rozprzestrzenia się na przyrządy, mające :
- mechaniczne uszkodzenie;
- defekty, powstałe wskutek naruszenia warunków i reguł eksploatacji czy wskutek błędnych działań właściciela przyrządu;
- defekty, powstałe wskutek klęsek żywiołowych;
- defekty, powstałe wskutek trafienia do środka postronnych przedmiotów, płynów, wskutek samodzielnego remontu, samodzielnego wnoszenia konstruktywnych przemian;
- wykorzystywane w komercyjnych czy przemysłowych celach.

МАССАЖНЫЙ МАТРАС ZET-836

ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

Напряжение 220V

Мощность 14.4W

Уважаемый покупатель,

Благодарим Вас за покупку одной из моделей массажеров ZENET.

Просим Вас прочитать инструкцию по эксплуатации и сохранить ее для дальнейшего использования.

ОПИСАНИЕ:

Массажный матрас оснащен массажными вибромоторами. Лечебный эффект значительно усиливается с помощью функции нагрева. В комплексе с нагревом движения вибромоторов расслабляют мышцы и устраняют их спазмы, являются дополнительной возможностью стимулирования циркуляции крови и работы лимфатической системы.

ОСОБЕННОСТИ:

1. Подушка в области головы матраса для удобства.
2. Матрас изготовлен из мягкой и приятной на ощупь такни.
3. Тепловая функция во время массажа.
4. 5 массажных программ.
5. 8 массажных головок – по 2 на каждую зону.
6. Расслабляющий вибрационный массаж для всего тела.

ЭКСПЛУАТАЦИЯ:

1. Подключите адаптер с устройством к источнику питания.
2. «POWER» включает и выключает массажёр.
3. Массаж головы и шеи – кнопка «NECK» .
4. Кнопка «BACK» активирует функцию массажа спины.
5. Кнопка «THIGHS» активирует функцию массажа бёдер и ягодичной зоны.
6. Кнопка « HEAT» активирует функцию нагрева и «загорится соответствующий индикатор».

ГАРАНТИЙНЫЕ ОБЯЗАТЕЛЬСТВА:

1. Гарантийное обслуживание прибора, при условии соблюдения правил эксплуатации - 1 год от даты продажи.

2. В течение гарантийного срока прибор подлежит замене при обнаружении дефектов, возникших по вине производителя. Отметка о дате продажи и штамп торговой организации обязательны.

3. Гарантия не распространяется на приборы, имеющие:
- механические повреждения;
- дефекты, возникшие вследствие нарушения условий и правил эксплуатации или вследствие ошибочных действий владельца прибора;
- дефекты, возникшие вследствие стихийных бедствий;
- дефекты, возникшие вследствие попадания внутрь посторонних предметов, жидкостей, вследствие самостоятельного ремонта самостоятельного внесения конструктивных изменений;
- используемые в коммерческих или промышленных целях.

HAND MASSAGERS



Zet-711



Zet-717



Zet-718

MASSAGE COVERS



Zet-814



Zet-832



Zet-842

MASSAGE MATTRESS, NECK MASSAGERS



Zet-780



Zet-757



Zet-759

FOOT MASSAGERS



Zet-763



Zet-762

PANEL HEATERS / CLIMATE COMPLEXES



Zet-526



Zet-531



Zet-483



Zet-485

SUPER PLUS AIR CLEANERS



Eco-S



Turbo



Bio

SALT LAMPS







ZENET

MASSAGE MATTRESS ZET-836



www.zenet-shop.com