


Cartridge AM-069H Y, AM-069H M, AM-069H C, AM-069H BK

Installation



Remove the black protective film from the cartridge.



Shake the cartridge 5–6 times as shown in the illustration on the left.



Remove the sealing tape by gently pulling the tab.



Firmly insert the cartridge into the printer.



Close the printer cover.

Troubleshooting Guide

- This cartridge uses a chip that does not display the remaining toner level. If printouts become lighter, check the toner level in the cartridge manually.
- After installing a new cartridge, the printer screen may show a message indicating the product may be counterfeit. For instructions on how to address this, refer to the printer's user manual.

Safety Precautions

- **Environmental Requirements:** Cartridge installation must be performed at an ambient temperature of 10°C to 30°C and relative humidity of 20–80%. Failure to comply with these conditions may significantly impair print quality. If the cartridge has been stored outside the recommended temperature range for an extended period, allow both the cartridge and the printer to acclimatize under the required conditions for 2 hours before resuming printing.
- Select the correct paper type and thickness for printing. Do not use damaged, excessively thick paper, or paper with staples, as this may damage the photosensitive drum and cause white lines, deformed characters, or a gray background in printouts.
- Avoid touching the photosensitive drum with bare hands or exposing it to direct sunlight. This may shorten the drum's lifespan and lead to print defects.
- When printing on special media, use the manual feed slot and the nearest output tray to reduce the paper path and prevent paper jams.
- When replacing the cartridge, clean the cartridge compartment of dust and debris with a soft, dry cloth. To avoid dull colors, it is recommended to periodically wipe the electronic sensor contacts in the cartridge compartment with a specialized alcohol wipe for electronics.
- During initial printing with a new cartridge, minor defects may occur (e.g., dull or overly saturated colors, streaks). If such issues appear, print 10 consecutive pages; print quality should normalize afterward.
- When a low toner warning appears, remove the cartridge and shake it. This will allow you to print approximately 40–50 additional pages.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information

about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.

- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Additional Information

Manufacturer: ZHUHAI JIALIANXIN IMAGING PRODUCTS CO., LTD.

2/3/4F, No.1 Jiaxin Technology Building, No.2 Dingwan Nine Road, Sanzao Town, Jinwan District, Zhuhai City, Guangdong Province, P.R. China.

Made in China..



The date of manufacture, as well as the warranty and service life periods, are indicated on the packaging.