

User Manual

Wireless Keyboard and
Mouse Set
DKM-110WH

DEXP

Contents

- Intended Use.....3**
- Safety Precautions 3**
- Specifications.....4**
 - Keyboard 4
 - Mouse 4
 - General.....4
- Package Contents.....4**
- Device Diagram 5**
 - Keyboard 5
 - Mouse 6
- Operating Instructions 7**
 - Keyboard Connection.....7
 - Keyboard Sleep Mode 7
 - Keyboard LED Indicators 7
 - Key Abbreviation Legend 7
 - Multimedia Keys.....8
 - Mouse Connection 8
 - Pairing 8
 - Mouse Sleep Mode 8
 - DPI Adjustment 8
- Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal.....9**
- Warranty Information 10**
- Additional Information 10**

Dear Customer,

Thank you for choosing our products.

We are pleased to offer you products and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the product, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

Intended Use

- The keyboard is an input device designed for typing text and issuing commands to the computer.
- The mouse is a device for controlling the cursor and issuing various commands to the computer.

Safety Precautions

- Do not make any modifications to the device design.
- To avoid short circuits, do not allow the device to come into contact with any liquids, and do not place open containers with liquids near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by children or persons with reduced physical, sensory, or mental capabilities, unless they are supervised by a person responsible for their safety. Do not allow children to play with the device.

Specifications

Keyboard

- Model: DKM-110WH.
- Trademark: DEXP.
- Key mechanism: Membrane.
- Total number of keys: 112.
- Numeric keypad.
- Material: Plastic.
- Power supply: 1 × AA.
- Power parameters: 1.1–1.5 V =.
- Weight: 640 g.
- Dimensions (W × D × H): 452 × 198 × 26 mm.

Mouse

- Model: DKM-110WH.
- Trademark: DEXP.
- Type: Optical (LED).
- Sensor resolution: 800 / 1600 / 2400 / 3200 / 4000 dpi.
- Number of buttons: 6.
- Material: Plastic.
- Polling rate: 125 Hz.
- Power supply: 1 × AA.
- Power parameters: 1.1–1.5 V =.

General


- Compatibility: Windows, macOS.
- 2.4G radio channel characteristics:
 - Wireless standard: IEEE 802.15.
 - Frequency range: 2400–2483 MHz.
 - Transmitter power: Up to 100 mW.
- Scope of application: Domestic.

Package Contents

- Keyboard.
- Mouse.
- 2.4G receiver.
- AA batteries (2 pcs).
- User manual.


Device Diagram

Keyboard



1. NumLock indicator.
2. CapsLock indicator.
3. Battery charge indicator.
4. Power switch.
5. Windows key.
6. Rubber feet.
7. Kickstand feet.
8. Battery compartment.

Mouse



1. Scroll wheel / middle button.
2. Left mouse button.
3. Right mouse button.
4. «Forward» button.
5. «Back» button.
6. DPI button.
7. Pairing indicator.
8. Low battery indicator.
9. Power switch.
10. Optical sensor.
11. Battery and receiver compartment.

Operating Instructions

Keyboard Connection

1. Insert the battery (included) into the battery compartment on the bottom of the device. Close the compartment cover.
2. Move the power switch to the «On» position.
3. Take the receiver out of the keyboard compartment and connect it to the computer's USB port. The receiver is paired with the device by default, so the connection will occur automatically.

Notes

- If a connection failure occurs, simultaneously press and hold the ESC + K keys to enter re-pairing mode. To complete the connection, reinsert the receiver into the USB port.
- The next time the receiver is connected, re-pairing is not required.

Keyboard Sleep Mode

- The keyboard will enter sleep mode after 10 seconds of inactivity, and the indicators will turn off.
- To exit sleep mode, press any key.

Keyboard LED Indicators

Indicator	Function	Description
Num A Off On		
Num	NumLock	Lights up when NumLock is enabled
A	CapsLock	Lights up when CapsLock is enabled
	Battery charge indicator	Flashes when the battery is running low
		Flashes during pairing
		Lights up when the keyboard is turned on

Key Abbreviation Legend

- **PrtSc**: Print Screen.
- **SysRq**: System Request.

Multimedia Keys

Key	Description
	Task view (= Win + Tab)
	Switch between desktop and open windows (= Win + D)
	Email
	• Open default browser; • Home
	Back: • the previous page in the browser; • to the previous folder in File Explorer; • «Cancel» or «Back» in other applications
	This PC
	Calculator

Mouse Connection

1. Open the battery and receiver compartment.
2. Take out the receiver.
3. Insert the battery (included) into the compartment. Close the compartment cover.
4. Move the power switch on the back of the mouse to the upper position.
5. Connect the receiver to the computer's USB port. The receiver is paired with the device by default, so the connection will occur automatically.
6. The device is ready for use.

Note: The next time the receiver is connected, re-pairing is not required.

Pairing

1. Press and hold the middle and right buttons, then move the power switch on the back of the mouse to the upper position to turn it on. The pairing indicator will start flashing, indicating the start of pairing.
2. Insert the USB receiver into the corresponding port of the device you are connecting the mouse to.
3. If pairing is successful, the indicator will turn off. The mouse is ready for use.

Mouse Sleep Mode

- The mouse will enter sleep mode after 10 seconds of inactivity, and the indicators will turn off.
- To exit sleep mode, move the mouse or press any button.

DPI Adjustment

- DPI levels: 800 / 1600 / 2400 / 3200 / 4000.
- Default DPI level: 1600.
- Press the DPI switch button on the top of the mouse to sequentially change the DPI level.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- The device does not require installation or permanent mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported under dry conditions.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- Upon expiration of the service life of batteries supplied with the device, do not dispose of them with other household waste. Batteries must be disposed of in accordance with local waste recycling regulations to prevent potential environmental harm resulting from uncontrolled waste disposal.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 12 months

Service Life: 24 months

For the up-to-date list of authorized service centers, please visit:

<https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: Dongguan Haofeng Electronic Technology Co.,Ltd.

Room 102, Building 1, No. 179 Chaoheng Road, Chashan Town, Dongguan City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.



Production date (mm.yyyy): _____ v.1

