

# **aceline**

## User Manual

---

Wireless Mouse  
WM-104

# Contents

Intended Use.....	3
Safety Precautions .....	3
Battery Handling Recommendations (Li-pol/Li-ion).....	3
Device Diagram .....	4
Specifications .....	5
Package Contents.....	5
Operating Instructions.....	6
Switch Positions .....	6
Connecting via 2.4GHz band .....	6
Connecting via Bluetooth.....	6
Charging.....	6
Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal .....	7
Warranty Information .....	8
Additional Information .....	8

## Dear Customer,

Thank you for choosing our products.

We are pleased to offer you appliances and devices designed and manufactured to the highest standards of quality, functionality, and design. Before using the device, please read this manual carefully. It contains important information regarding your safety, as well as recommendations for the proper use and care of the product. Please keep this manual in a safe place and use it as a reference guide during future operation of the product.

## Intended Use

The mouse is a device for controlling the cursor and issuing various commands to the computer.


## Safety Precautions

- Do not make any modifications to the device.
- To avoid short circuits, do not expose the device to any liquids, and do not place open containers of liquid near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.

## Battery Handling Recommendations (Li-pol/Li-ion)

- Use only the original charger.
- Observe the temperature requirements. Batteries should be stored in a charged state at temperatures between +15°C and +35°C with normal humidity. Batteries do not perform well when operated for extended periods in extremely high (above +40°C) or low (below -10°C) ambient temperatures. Do not leave the battery in direct sunlight.
- Do not disassemble, incinerate, or use batteries that show signs of damage.

## Device Diagram



1. Left button.
2. Scroll wheel.
3. DPI button.

4. Right button.
5. Power switch.
6. USB dongle.

## Specifications

- Model: WM-104.
- Trademark: Aceline.
- Power supply: 3,7 V = 16 mA / 500 mA.
- Battery type: Built-in, Li-ion.
- Battery capacity: 500 mAh.
- Mouse type: LED sensor.
- N buttons: 4.
- Sensor resolution: 800 — 1200 — 1600 dpi.
- Material: Plastic.
- Connection: 2.4GHz band, Bluetooth.
- 2.4 GHz band radio specifications:
  - Wireless standard: IEEE 802.15.
  - Radio spectrum: 2402–2480 MHz.
  - Transmit power: 0 dBm.
- Bluetooth radio specifications:
  - Wireless standard: IEEE 802.15.
  - Radio spectrum: 2402–2480 MHz.
  - Transmit power: 0 dBm.
- Compatible OS: Windows/Mac OS/Chrome OS/Android.
- Charging time: 3.5 hours.
- Battery life: 50 hours.
- IP code: IPX0.
- Scope of application: Domestic.

## Package Contents

- Device.
- USB Type A — USB Type C cable.
- User manual.
- USB dongle.

# Operating Instructions

## Switch Positions

- Upper position: 2.4GHz band mode.
- Middle position: Mouse is turned off.
- Lower position: Bluetooth mode.

## Connecting via 2.4GHz band

1. Remove the USB dongle from the bottom of the mouse.
2. Plug the dongle into a USB port on your computer.
3. Turn on the mouse by sliding the switch to the top position.
4. Wait for the device installation wizard to complete on your computer.
5. The mouse is ready for use.

## Connecting via Bluetooth

1. Turn on the mouse by sliding the switch to the bottom position.
2. Find the mouse model in the list of available devices and pair with it.
3. The mouse is now ready for use.

**Note:** While connecting via Bluetooth, the indicator light flashes blue.

### If the mouse does not connect:

- Check if another mouse is connected to your computer and disconnect it.
- If this does not resolve the issue, contact an authorized service center.

## Charging

- During charging, the indicator lights up green.
- Once fully charged, the indicator turns off.

## Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.

## Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

**Warranty Period:** 12 months.

**Service Life:** 18 months.

For the up-to-date list of authorized service centers, please visit:  
<https://www.dns-shop.ru/service-center/>

## Additional Information

**Manufacturer:** SHENZHEN YUANYICHANG TECHNOLOGY CO., LTD.  
Building B, No.60, Zhuang Village Road, Xiner Industrial Park,  
Xinqiao Street, Bao'an District, Shenzhen City, Guangdong  
Province, China.

Made in China.

The product meets the requirements of the CU TR (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products..



Production date (mm.yyyy): \_\_\_\_\_ v.1

**aceline**