

IMPACT

WIRELESS GAMING MOUSE



Contents

Intended use.....	3
Safety Precautions	3
Rechargeable Battery Guidelines (Li-pol/Li-ion).....	4
Specifications	7
Device Diagram	8
Package Contents.....	9
Connecting the Mouse	9
Software	10
DPI Settings and Indication	11
Polling Rate.....	11
Charging.....	11
Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal	12
Warranty Information.....	13
Additional Information	13

Wireless Mouse ARDOR GAMING Impact

User Manual

Dear Customer,

Thank you for your trust!

Our team fully shares your passion for computer games, which is why we put all our efforts into making your gaming experience unforgettable with our accessories for gamers. Wishing you new victories and the brightest impressions ahead!

Intended use

The wireless mouse is a device for controlling the cursor and issuing various commands to the computer.

Safety Precautions


- Do not make any modifications to the device's design.
- To avoid a short circuit, do not expose the device to any liquids, and do not place open containers of liquid near it.
- Do not expose the device to electromagnetic radiation.
- This device is not intended for commercial use.
- This device is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the device.

Rechargeable Battery Guidelines (Li-pol/Li-ion)

Dear Customer, please note that this device uses a lithium-based rechargeable battery as its power source. Please carefully read the information below to help extend the life of your battery and prevent undesirable consequences during its operation.

Battery Capacity and Charge-Discharge Cycles

During prolonged storage and use, the rechargeable battery (hereinafter referred to as «the battery») tends to lose its charge and capacity. After 300 charge-discharge cycles (approximately one year of device use), the battery capacity may decrease to 80% of its nominal value. After 400 charge-discharge cycles, the battery capacity may decrease to 60% of its nominal capacity. Partial capacity reduction within these limits and time frames is natural battery wear and is not considered a defect.



Natural Battery Wear

The battery loses charge even when stored separately from the device. The self-discharge rate is approximately 5% per month. Due to their design, batteries are not durable and constantly degrade regardless of whether they are in use. This degradation accelerates at higher temperatures and when the charge level deviates from the «optimal» storage level, which is generally considered to be 40%. In other words, if the battery is not in use, it is advisable to keep the charge level between 40% and 50%.

Use Only the Original Charger

The battery's charge and discharge capability is controlled by its built-in Battery Management System (BMS). Forced «fast charging» modes using external chargers for Li-ion batteries are strictly not recommended, as charge and discharge currents are limited. Li-ion batteries do not have a so-called «memory effect» You can start charging or discharging the battery from any charge level.

Most devices have charge and discharge limits—the controller may prevent the battery charging if, for example, the charge is already above 90%. It will also prevent the battery from fully discharging, protecting the cells from damage. Even if the device is powered by the electrical grids, the Li-ion battery should undergo a full charge/discharge cycle at least once a month (until the «low battery» warning appears). Never let the battery discharge completely. A Li-ion battery degrades quickly if stored in a discharged state for a prolonged period. If this happens, charge it immediately. If the battery remains in a discharged state for two weeks or more, irreversible capacity loss occurs in the cells, which will ultimately lead to battery failure.

Observe the Temperature Requirements

Batteries must be stored in a charged state at temperatures between +15 °C and +35 °C with normal humidity. Batteries do not perform well prolonged operation in very high (above +40 °C) or very low (below -10 °C) ambient temperatures. Do not leave the battery in direct sunlight.

Do Not Disassemble, Burn, or Use Damaged Batteries

Under no circumstances should you attempt to disassemble the battery or charge its individual cells. For repair or maintenance, please contact an authorized service center.

Puncturing or crushing the cells can cause an internal short circuit, leading to fire and explosion. Melting of lithium due to high temperatures can also cause an explosion. If the seal is broken, water or condensed atmospheric moisture can enter the cell, potentially triggering a reaction that releases hydrogen and causes a fire. You can check the current battery status using the battery indicator, which is available on almost all devices (please check its location and operation method at the time of purchase).




CAUTION:

- Be careful — damaged batteries may release harmful substances.
- If the battery is replaceable (removable), and you discover problems with its performance, contact a service center (see the warranty period in the warranty information). If the battery is built-in (an integral part of the device), the warranty applies to the device itself. You should also contact a service center. The sooner you bring a malfunctioning battery in for repair, the more likely it can be restored with minimal cost.
- Battery operating time depends on many other factors, and the actual operating time may differ from the stated value.
- Rechargeable batteries have a limited number of charge cycles and may eventually need replacement (see the limited warranty conditions for the battery in the warranty information). Battery operating time depends on the usage mode and settings.

Specifications

- Model: ARDW-IMT3325-WT
- Trademark: ARDOR GAMING
- Mouse type: Wireless/Wired
- LED sensor: PixArt PMW3325
- DPI modes: 400 / 800 / 1600 / 3200 / 5000 DPI (max. 10000 DPI)
- Mouse acceleration: 20 G
- Encoder: F-Switch
- Battery: Li-ion 300 mAh
- Charging time: Up to 1.5 hours
- Battery life:
 - Up to 80 hours (at 125 Hz polling rate)
 - Up to 30 hours (at 1000 Hz polling rate)
- Polling rate: 125 / 250 / 500 / 1000 Hz
- Switches: HUANO 20 M
- Connection: Type-C, 2.4GHz band
- Type-C cable: Paracord, 1.8 m
- Wireless standard: IEEE 802.15.4
- Radio spectrum: 2402–2480 MHz
- Transmit power: 0 dBm
- Material: Plastic
- Compatibility: Windows
- Scope of application: Domestic

Device Diagram



1. Left mouse button
2. Middle button
3. Right mouse button
4. Forward button
5. Back button

6. LED indicator
7. USB Type-C connector
8. Power switch
9. DPI switch

Package Contents

- Device
- USB dongle
- Charging cable
- Set of PTFE mouse feet
- User manual

Connecting the Mouse

2.4GHz Band Connection

1. Remove the USB dongle from the packaging.
2. Connect the dongle to a USB connector on your computer.
3. Turn on the mouse by sliding the power switch to the appropriate position.
4. Wait for the hardware installation wizard to complete on your computer.
5. The mouse is ready to use.

CAUTION:

If the mouse does not connect via 2.4GHz, make sure that the dongle is plugged into a USB connector on your computer and that the switch on the mouse is set to the «ON» position. If the mouse still does not connect after checking, open the device connection menu, select pairing, and press and hold the left, middle, and right mouse buttons simultaneously for 3 seconds. LED indicator on the left side of the mouse will flash yellow, and the mouse will connect wirelessly. If the mouse still does not connect, contact an authorized service center.

Wired Mode

- Connect one end of the cable to the corresponding connector on the mouse, and the other end to a USB connector on your computer.
- If the mouse is in wireless mode and you connect it to the computer using the cable, it will automatically switch to wired mode.

Software

1. This mouse comes with software that allows you to customise its settings.
2. You can download the software from <https://www.dns-shop.ru/> on the product page.
3. Before downloading the software, make sure you are downloading it from the correct product card (to do this, enter the alphanumeric model name indicated on the box, in the user manual, or on the back of the mouse).
4. Using the software, you can reassign buttons to your desired commands using macros, as well as change the default button assignments.

Note:

If the software does not detect the mouse: Check if any other software is open on your desktop. You need to close all third-party software. If more than one mouse is connected to your computer, disconnect the other mouse first.

If no third-party software is open and only one mouse is connected: Try uninstalling the software, temporarily disable your antivirus protection, download the software again according to the instructions provided, and check the connection between the mouse and the software. If the measures described above do not help, contact technical support.

DPI Settings and Indication

1. DPI modes: 400 / 800 / 1600 / 3200 / 5000.
2. Press the «DPI» switch on the bottom of the mouse to cycle through the DPI levels sequentially.
3. The indicator on the left side of the mouse will indicate the current DPI level:
 - 400 DPI: Red.
 - 800 DPI: Blue.
 - 1600 DPI: Green.
 - 3200 DPI: White.
 - 5000 DPI: Yellow.

Note:

DPI can also be adjusted using the software. The maximum available DPI value is 10000.

Polling Rate

The default value is 1000 Hz. The values of 125–250–500–1000 Hz can be configured using the software.

Charging

- When the battery is low (charge below 20%), the LED indicator on the left side of the mouse will flash red. Connect the mouse to a power source to charge it.
- During charging, the LED indicator on the left side of the mouse will flash yellow. After charging is complete, the LED indicator will turn solid green.

Rules and Conditions for Installation, Storage, Transportation, Sale (Distribution), and Disposal

- This device requires no assembly or mounting.
- The device must be stored in its original packaging, on heated premises, both at the manufacturer's and at the consumer's sites. The ambient temperature should be between +5 °C and +40 °C, and the relative humidity should not exceed 80% (non-condensing). The storage area must be free from aggressive contaminants (e.g., acid or alkali vapors) that could cause corrosion.
- The device must be transported in a dry place.
- The device requires careful handling. Protect it from exposure to dust, dirt, impact, moisture, fire, and other hazards.
- Sale or distribution of the device must be carried out in accordance with local legislation.
- If a device malfunction is detected, immediately contact an authorized service center or dispose of the device.
- Upon expiration of the device's service life, it must not be disposed of with unsorted household waste. Instead, it must be taken to an authorized collection point for electrical and electronic equipment for subsequent recycling and disposal in accordance with federal or local legislation. By ensuring proper disposal of this product, you help conserve natural resources and prevent potential harm to the environment and human health that may result from improper handling. For more detailed information about collection and disposal points for this product, please contact your local municipal authorities or your household waste disposal service.

Warranty Information

The manufacturer guarantees the device will function properly throughout the warranty period and be free from defects in materials and assembly. The warranty period commences on the date of purchase and applies to new products only. Warranty service includes free repair or replacement of defective parts that fail during the warranty period, provided the failure is not caused by consumer misuse and the product is operated in accordance with the user manual. Repairs or part replacements shall be performed at authorized service centers.

Warranty Period: 24 months.

Service Life: 24 months.

For the up-to-date list of authorized service centers, please visit: <https://www.dns-shop.ru/service-center/>

Additional Information

Manufacturer: SHENZHEN YUANYICHANG TECHNOLOGY CO., LTD.

Building B, No.60, Zhuang Village Road, Xiner Industrial Park, Xinqiao Street, Bao'an District, Shenzhen City, Guangdong Province, China.

Made in China.

The product meets the requirements of the technical regulations of the TR CU (EAEU).

Product specifications, information and appearance are subject to change without prior notice, for quality improvement of our products.

Production date (mm.yyyy): _____ v.1





LEARN MORE:

ARDOR-GAMING.COM
VK.COM/ARDOR_GAMING

