



**BTP-2650S**



**I KEY INTRODUCTION**

- 1** LOGO Button
- 2** TURBO
- 3** BACK
- 4** START
- 5** SHIFT
- 6** Left Joystick /LS(Press Down)
- 7** Sensivety Knob
- 8** ABXY
- 9** D-Pad
- 10** Indicator Light
- 11** Right Joystick /RS-(Press Down)
- 12** Sensivety Knob




- 13** RT
- 14** LT
- 15** Trigger Lock
- 16** Trigger Lock
- 17** M1 Custom Button
- 18** M1 Custom Button
- 19** Type-C Port
- 20** Reset

**II POWER ON/OFF****① [ Power on ]**

Press the BEITONG Logo button to turn on the Controller

**② [ Power off ]**

Press and hold the Back + B button for about 3 seconds, the Controller will be turned off

**③ [ Forced shutdown situation ]**

※Under disconnected state:

Automatically shut down if the controller isn't connected successfully within 120s

※Under connected state:

Automatically shutdown if the controller isn't operated within 10 min

※Automatically shutdown if the controller is in low battery

**Tips:** Press RB Button + BACK Button + RS Button + HOME Button in the power off state, pairing information can be actively cleared.


**III CONNECT TO PC/ANDROID TV****[ WIRELESS CONNECTION ]**

① Insert the wireless receiver into the USB interface of the device

Indicator lights flashes slowly while the wireless receiver pairing

- ② Press the BEITONG Logo button to turn controller on, it will automatically connect with the device

The connection is completed when the controller vibrates and the indicator light turns normally on



- ③ Press and hold BEITONG Logo button for 3s to switch the controller mode

[PC360 mode]: The green light on the upper half is on for 3s

[BFM mode] : The green light on the lower half is on for 3s

- ④ Automatically paired for connection when the receiver is used again, while you press BEITONG Logo (Home Button) to start up

### [ WIRE CONNECTION ]



- ① Connect the controller with device directly through USB cable. If the indicator light flash slowly, the controller is in charging state

- ② The connection is completed when the controller vibrates and the indicator light turns normally on

**IV FEATURES FOR CONTROLLER**


**[ SENSIVETITY KNOB OPERATION ]**



① **Joystick sensitivity adjustable in real time :**

A higher/lower gear could be adjusted when you rotate the knob three times each, while the three indicator lights are in the same color

② **Indicator lights color & corresponding sensitivity**



### ③ Knob Operations

※[Left knob] :Adjust the left stick. The indicator light flows to the left:indicator lights 1.3.4

※[Right knob] :Adjust the right stick. The indicator light flows to the right:indicator lights 2.3.4

※[Sensitivity enhance] :Rotate the knob clockwise. The indicator lights flows from the bottom up

※[Sensitivity weaken] :Rotate the knob counterclockwise. The indicator lights flows from the top down

※ [Left/Right stick reset to default] : Press and hold [SHIFT] then press down the left/right stick,reset to default when the left/right side indicator light turns white for 3s

※[Reset to default simultaneously]: Press and hold [SHIFT] for 3s, the sensitivities of left and right sticks are reset to default when the indicator light 3 & 4 are off for 3s

### [ COUNTERWEIGHT & RECEIVER STORAGE ]



① Handles of the controller can be opened along the gap, [7g] and [15g] counterweight blocks can be added to both sides, which can increase the weight for gripping hand feel

② In addition, the counterweight bin can be used as a [wireless receiver storage ]

### [ TRIGGER STROKE ADJUSTMENT ]

The trigger stroke of the LT/RT keys can be directly switched through the trigger lock on the back of the controller

※Long stroke: 19°, suitable for racing games

※Medium stroke: 11°, suitable for RPG games

※Short stroke: 5°, suitable for shooting and action games



**V SOFTWARE SUPPORT**

\*About the assistant software, it supports personalized function setting/key test/firmware upgrade.  
It's recommended to download according to gamer's needs, but do not affect basic use of the controller without downloading.

**[BEITONG Gamepad Assistant For PC]**

① Download the software "BEITONG Gamepad Assistant" from BEITONG official website:

<https://www.betop-cn.com/en/#/down>

( Note: If you enter the Chinese Official Website, please set the language in the upper right corner to English, and then click the DOWNLOAD enter into the download page.)




② In order to use the BEITONG Gamepad Assistant normally, the controller must be connected to the computer with USB cable

Press the BEITONG logo button to turn controller on and it'll be connected automatically

- ③ Run the software "BEITONG Gamepad Assistant" to set up the Controller function

**NOTE:**

- 1.It's recommended to confirm upgrade if prompted for a firmware upgrade, to experience any updated features.
- 2.In order to use the BEITONG Gamepad Assistant normally, the Gamepad must be connected to the computer with USB cable.
- 3.Please feel free to run our secure program,if it can't be downloaded and run normally, try again after closing the antivirus software.
- 4.If the firmware upgrade fails due to factors such as signal disconnection, disconnection or poor contact, please unplug the USB cable and then re-plug again to resume the firmware upgrade.

**[ Asura 3S NS PC Gamepad Assistant Introduction ]**

**① Lighting adjustment**

**[ Change configuration name ]**

**[ Change indicator light's flicker mode ]:**

※ Normal: All lights are on ※ Breath: All lights change in breathing state

※ Drip: Light flows from the top down

**[ Change light color ]** : 9 colors can be selected totally

**[ Switch color flow direction ]**: according to the color table order

※ Single color: All lights are normally on in a single color

※ Clockwise: All lights switch in clockwise colors

※ Counterclockwise: All lights switch in counterclockwise colors

**[ Brightness adjust of lights ]**: 5 levels are optional

**[ Frequency adjust of lights switching ]**: 5 levels are optional


**② Vibration adjustment**

**[ Intensity ]** : Adjust the intensity of vibration feedback of the gamepad

### ③ Key functions setting

※LB, RB, M1 and M2 keys can be customized to set macro and mapping for other keys

※Other keys on the gamepad can only be customized to set mapping



#### [ Key value mapping ]

For example, Key A is mapped to Key B to trigger the action of B when A is pressed.

Click the input box after the arrow of Key [A] to delete the key value;

Press Key B on the gamepad to map Key [ A] to Key [ B]

#### [ Macro Programmable ]


LB, RB, M1, M2 keys can be set for macro programming

One button can be set to have a maximum of 32 actions


You can record the [Action], [Duration] and [Interval] between each action in combo operations in real-time, and fine-tune them in milliseconds.

**④ Joystick Sensitivity Setting**

The sensitivity curve can be viewed in real time, which can be achieved by rotating the speed control knob of stick or knob + custom key.



**⑤ Joystick & Trigger Calibration**



**[Joystick Calibration]**

Rotate the left and right joysticks one turn simultaneously

**[Trigger Lock Calibration]**

Turn the trigger lock on both sides from long stroke to shortest stroke, press B twice to calibrate.

**[Trigger Calibration]**

Three strokes, each stroke press down the two triggers to the end

**VI OTHER FUNCTIONS AND BATTERY****[ TURBO FUNCTION ]**

[ TURBO + Action Key ]

**① Enable:**

Press and hold [Action Key] and then press [TURBO Key].

When the gamepad vibrates once, it indicates that running fire is enabled

**② Disable:**

Press and hold [Action Key] that enabled the running fire, and then press [TURBO Key]

**[ JOYSTICK D-PAD SWITCH ]**

[SHIFT Key] To Switch

Press gently [SHIFT Key] to enable/disable the function of switching between the joystick and direction keys

**[ CHARGING & BATTERY LIFE ]****① Battery Life**

Built-in 950mAh lithium battery, with TYPE-C USB data cable attached to the package

Battery life is up to 80 h when the controller is fully charged and about 40h when the it is in normal use

**② Charging Mode**

[Charging by connecting to the computer / TV with a cable]

[Charging with a phone charger]

When you play a game with a cable connected to the computer/TV, the gamepad will be charged synchronously

**③ Charging Indicator Light Prompt**

The indicator light will be in breathing state when charging, and in normally on state when fully charged

※Power on state: None

※Power off state: Color flows clockwise, frequency is level 3

※0-25% Power: Indicator light 1,2,3,4 flow

※ 25%-50% Power: Indicator light 1 normally on, 2,3,4 flow

※50%-75% Power: Indicator light 1,2 normally on, 3,4 flow

※75%-99% Power: Indicator light 1,2,3 normally on, 4 breathing

※Full charge: Indicator light 1,2,3,4 normally on in white

When the battery power is lower than 20%, the indicator lights 1 and 2 will flicker in red quickly

## FAQ

**Q** How to upgrade the firmware ?

- A**
1. Visit the download page of BEITONG official website.
  2. Click [BEITONG Gamepad Assistant] to download the program.
  3. Connect controller & PC by USB cable, run betopgame.exe program to start the Gamepad Assistant
  4. Confirm firmware upgrade and wait.

**Q** How to troubleshoot when it cannot be turned on normally?

- A**
1. Please confirm whether the power of the controller is sufficient.
  2. Connect the power supply through the data cable and observe whether the indicator light of the controller is flashing.
  3. Connect the computer with the data cable to confirm the status of the controller.
  4. If none of the above methods can solve the problem, please contact customer service.

## Product Specification

<b>Name</b>	BEITONG Asura 3S Wireless Gamepad
<b>Model</b>	BTP-2650S
<b>Power Supply</b>	950mAh Rechargeable Lithium Ion Battery
<b>Connection</b>	2.4G Wireless, USB Cable
<b>Size</b>	155*110*62mm
<b>Weight</b>	About 244G
<b>Adaptation platform</b>	PC Window 7 and later, Android TV
<b>Package Include</b>	Gamepad x 1, USB Cable x 1, Receiver x 1, Replaceable D-pad x 1, Counterweight x 4, User Manual x 1

## Customer Service

Dear customer,

Thanks for using BEITONG gaming peripheral products.

We focus on providing gamer with a better gaming experience, please provide the information through your email for customer service:

a. Purchasing Channel   b. Buyer ID   c. Order Number   d. Product Model

Please provide the below information for us according to the product situation :

1. Please provide service reason

a. Function is not good   b. Bad appearance   c. Can not use in my device

d. Can not play the game i want to play   e. Other reason

2. Please provide the service you need

a.Replacement   b. Repairing   c. Return   d. Other

**Customer service contact:** [beitong-oversea@betop-cn.com](mailto:beitong-oversea@betop-cn.com)

We also welcome our customer to provide suggestion so that to improve and upgrade our product. Any good idea for our products, please feel free to contact us. It's very grateful. Meanwhile we'll select the customer who in high-quality advice to experience our new products for free opportunity.

Sincerely

BEITONG Customer Service Team

### ABOUT BEITONG

Leading brand of smart gaming peripherals in China  
Been focusing on game controller and software development more than 25 years  
Sticking on quality, function and innovation  
Customizing professional control solutions for different types of games  
Creating the stronger experience of game control for gamers

### CUSTOMER SERVICE

Official website: <https://www.betop-cn.com/en>

Service Email: [beitong-oversea@betop-cn.com](mailto:beitong-oversea@betop-cn.com)

More products and game information, please follow BEITONG official social media accounts.



Official YouTube



Official Amazon



Official Website